

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oxygenics](#) /

› [Oxygenics 88446 Power Massage Hand Held Showerhead Instruction Manual](#)

Oxygenics 88446

Oxygenics Power Massage Hand Held Showerhead

Model: 88446

PRODUCT OVERVIEW

The Oxygenics 88446 Power Massage Hand Held Showerhead is designed to provide an intensely satisfying shower experience while conserving water. Featuring advanced amplifying technology and oxygen-infused water, this showerhead delivers powerful spray performance even with lower water pressure. Its durable construction and easy-clean nozzles ensure long-lasting, clog-free operation.



Figure 1: Oxygenics 88446 Power Massage Hand Held Showerhead, showcasing its brushed nickel finish and spray face.

Key Features:

- **5 Spray Settings:** Customize your shower experience from a gentle rinse to a powerful massage.
- **Amplifying Technology:** Infuses water with oxygen to create a more powerful spray, enhancing pressure and coverage.
- **Oxygen-Infused Water:** Provides a revitalizing and invigorating shower.
- **Durable Brushed Nickel Finish:** Resists corrosion and tarnishing, maintaining its aesthetic appeal.
- **Non-Stick Internal Parts:** Engineered to prevent mineral buildup and clogging, ensuring consistent performance.
- **Easy-Clean Nozzles:** Simple to wipe clean, preventing limescale accumulation.
- **Standard 1/2 inch Connection:** Compatible with most standard shower arms.
- **60-Inch Hose:** Provides extended reach and flexibility for handheld use.

SETUP AND INSTALLATION

This showerhead is designed for quick and easy installation, typically taking only a few minutes. No specialized tools are required beyond what is commonly found in a household.

What's Included:

- Oxygenics Handheld Showerhead
- 60" Shower Hose
- Shower Arm Diverter/Holder
- Plumber's Tape (Teflon Tape)

Installation Steps:

1. **Prepare the Shower Arm:** Ensure the water supply to your shower is turned off. Unscrew and remove your existing showerhead from the shower arm. Clean any residue from the shower arm threads.
2. **Apply Plumber's Tape:** Wrap plumber's tape (provided) clockwise around the threads of the shower arm 3-4 times. This helps create a watertight seal.
3. **Install the Diverter/Holder:** Screw the shower arm diverter/holder onto the taped shower arm threads. Hand-tighten only. Do not use tools, as this may damage the unit. Ensure the diverter is oriented correctly for the hose connection.
4. **Attach the Hose to the Diverter:** Apply plumber's tape to the threads of one end of the 60" shower hose. Screw this end onto the bottom outlet of the diverter/holder. Hand-tighten only.
5. **Attach the Showerhead to the Hose:** Apply plumber's tape to the threads of the showerhead's handle. Screw the other end of the 60" shower hose onto the showerhead handle. Hand-tighten only.
6. **Place Showerhead in Holder:** Insert the showerhead into the holder on the diverter.
7. **Test for Leaks:** Turn on the water supply and check for any leaks at all connection points. If leaks occur, turn off the water, re-tape the threads, and re-tighten the connections.

OPERATING INSTRUCTIONS

The Oxygenics Power Massage Hand Held Showerhead offers multiple spray settings for a customized showering experience.

Changing Spray Settings:

Locate the spray selector lever or dial on the face of the showerhead. Gently rotate or slide this selector to cycle through the 5 available spray patterns. Each setting provides a unique flow, from a wide, gentle spray to a concentrated, powerful massage.

Handheld Use:

The 60-inch hose allows for convenient handheld use, making it ideal for rinsing specific areas, cleaning the shower, or bathing children and pets.

MAINTENANCE

Regular maintenance will ensure your Oxygenics showerhead continues to perform optimally and remain clog-free.

Cleaning the Nozzles:

The easy-clean nozzles are designed to prevent mineral buildup. To clean, simply rub your finger or a soft cloth over the rubber nozzles on the showerhead face while water is flowing. This will dislodge any mineral deposits.

General Cleaning:

To clean the exterior of the showerhead and hose, use a soft cloth and mild soap or a non-abrasive bathroom cleaner. Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the brushed nickel finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low Water Pressure	Mineral buildup in nozzles; water restrictor; low household water pressure.	Clean nozzles by rubbing them. Ensure water restrictor (if present and removable per local codes) is not obstructed. Consult a plumber for persistent low household pressure.
Leaks at Connections	Insufficient plumber's tape; loose connection; damaged washer.	Turn off water, re-apply plumber's tape, and hand-tighten connections. Check that rubber washers are properly seated and not damaged. Replace if necessary.
Showerhead Clogging	Mineral deposits in nozzles.	Rub the rubber nozzles to dislodge deposits. The "NEVER CLOG!" warranty covers clogging due to mineral buildup.

SPECIFICATIONS

- **Model:** 88446
- **Brand:** Oxygenics
- **Shower Head Type:** Handheld
- **Finish:** Brushed Nickel
- **Material:** Nickel
- **Number of Spray Settings:** 5
- **Flow Rate:** 1.75 GPM (Gallons Per Minute)
- **Connection Size:** 1/2 inch (Standard)
- **Hose Length:** 60 Inches
- **Product Dimensions:** Approximately 5.4" L x 4.1" W (Showerhead face)
- **Item Weight:** 1.51 pounds

- **Style:** Modern
- **Special Feature:** Oxygenics spray with dual Oxygenics engines

WARRANTY AND SUPPORT

"NEVER CLOG!" Warranty:

Oxygenics showerheads are backed by a "NEVER CLOG!" warranty, providing limited lifetime performance warranty against clogging due to mineral buildup. This ensures your showerhead maintains its optimal spray performance for years to come.

Customer Support:

For technical assistance, warranty claims, or replacement parts, please contact Oxygenics Customer Support. Refer to the product packaging or the official Oxygenics website for the most current contact information.

Website: www.oxygenics.com

Phone: (Check Oxygenics website for current phone number)

© 2024 Oxygenics. All rights reserved.

This manual is for informational purposes only. Always follow local plumbing codes and safety guidelines during installation and use.

Related Documents - 88446

	<p><u>Oxygenics FORCE Shower Head: Easy Installation Guide</u></p> <p>Step-by-step instructions for installing the Oxygenics FORCE shower head. Includes troubleshooting, contact information, and product details.</p>
	<p><u>Oxygenics PowerSelect Shower Head Easy Installation Guide</u></p> <p>Step-by-step instructions for installing the Oxygenics PowerSelect shower head, including features, included parts, and customer support contact information.</p>

	<p>Oxygenics Contour Showerhead Easy Installation Guide</p> <p>Comprehensive, step-by-step installation instructions for the Oxygenics Contour showerhead, including details on spray selection, diverter use, and customer support. This guide ensures a smooth setup process.</p>
	<p>Oxygenics Fury RV Shower Head: Easy Installation Guide</p> <p>A comprehensive, step-by-step guide for installing the Oxygenics Fury RV shower head. Learn about spray selection, flow control, and access customer support.</p>
	<p>Oxygenics PowerMax Handheld Shower Installation Guide</p> <p>Step-by-step installation instructions for the Oxygenics PowerMax handheld showerhead, including comfort control and spray selection features. Contact information for support is provided.</p>
	<p>Oxygenics Spin + Advantage Shower Head Easy Installation Guide</p> <p>Step-by-step instructions for installing the Oxygenics Spin + Advantage shower head, including troubleshooting and contact information.</p>