

## Xavax 00111361

# Xavax Transport Trolley (Model 00111361) - Instruction Manual

For Washing Machines, Dryers, and Other Heavy Appliances

## 1. PRODUCT OVERVIEW

---

The Xavax Transport Trolley is designed to provide effortless mobility for heavy household appliances such as washing machines, dryers, and refrigerators. Its adjustable design allows it to accommodate various appliance sizes, making it a versatile tool for moving or cleaning under heavy items. The trolley features six plastic wheels and a braking system for secure positioning.

- **High Capacity:** Enables unlimited mobility for appliances like washing machines, dryers, and refrigerators.
- **Adjustable Design:** Easily adjusts to the dimensions and depth of large appliances using sliding bars.
- **Effortless Movement:** Appliances can be moved on flat surfaces without physical strain, ideal for transport or floor cleaning.
- **Versatile Use:** Suitable for furniture, plants, or storage boxes. Equipped with 6 plastic wheels.

## 2. SAFETY INSTRUCTIONS

---

Please read and understand all safety instructions before using the transport trolley. Failure to follow these instructions may result in injury or damage to property.

- **Weight Limit:** Do not exceed the maximum load capacity of 300 kg. Overloading can cause instability and damage.
- **Level Surfaces:** Always use the trolley on flat, level surfaces. Uneven surfaces can cause the appliance to tip over.
- **Brakes:** Ensure the braking system is engaged when the appliance is in its final position or when loading/unloading to prevent accidental movement.
- **Secure Placement:** Ensure the appliance is centered and stable on the trolley before moving.
- **Two-Person Operation:** For heavy appliances, it is recommended to have two people for safe loading and unloading.
- **Obstacles:** Clear the path of any obstacles before moving the trolley.
- **Children and Pets:** Keep children and pets away from the trolley during operation.

## 3. PACKAGE CONTENTS

---

Verify that all items are present in the package:

- 1x Xavax Transport Trolley
- 1x Instruction Manual

## 4. SETUP INSTRUCTIONS

---

Follow these steps to set up your Xavax Transport Trolley and place an appliance on it.

### 4.1 Adjusting the Trolley Dimensions

The trolley is adjustable to fit various appliance sizes. Locate the sliding bars and adjust them to match the width and depth of your appliance. Ensure the trolley is slightly smaller than the appliance base for a snug fit, but large enough to support the appliance's weight evenly.



**Image 1:** Detail of the trolley's adjustable corner and brake mechanism. The black lever engages the brake for stability.

### 4.2 Placing the Appliance on the Trolley

For safe placement, it is highly recommended to have two people. Ensure the trolley's brakes are engaged before attempting to load the appliance.

1. **Prepare the Area:** Clear the area where you intend to place the appliance and the trolley.
2. **Engage Brakes:** Ensure all brakes on the trolley are engaged to prevent movement during loading.

3. **Tilt Appliance:** Carefully tilt the appliance (e.g., washing machine) to one side.
4. **Slide Trolley:** While the appliance is tilted, slide one side of the adjusted trolley underneath the appliance.
5. **Lower Appliance:** Slowly lower the appliance onto the trolley, ensuring it is centered and stable on the support points.
6. **Verify Stability:** Gently push on the appliance to confirm it is securely seated on the trolley and does not wobble.



**Image 2:** A washing machine securely positioned on the Xavax Transport Trolley, demonstrating proper placement.



Image 3: An alternative angle of the washing machine on the trolley, showing the overall setup.

## 5. OPERATING INSTRUCTIONS

---

Once the appliance is securely placed on the trolley, you can move it as needed.

1. **Disengage Brakes:** Release the brakes on the trolley by lifting the black levers.
2. **Move Appliance:** Gently push or pull the appliance to its desired location. Ensure the path is clear and free of obstacles.
3. **Engage Brakes:** Once the appliance is in its new position, engage all brakes to secure it and prevent accidental movement.

**Note:** Always move the trolley slowly and deliberately, especially with heavy loads, to maintain control and prevent tipping.

## 6. MAINTENANCE

---

Regular maintenance ensures the longevity and safe operation of your transport trolley.

- **Cleaning:** Wipe the trolley with a damp cloth to remove dust and debris. Avoid abrasive cleaners.
- **Wheel Inspection:** Periodically check the wheels for any damage, wear, or obstructions. Ensure they rotate freely.
- **Brake Functionality:** Test the braking system regularly to ensure it engages and holds securely.
- **Structural Integrity:** Inspect the metal frame and sliding bars for any signs of bending, cracks, or corrosion.
- **Storage:** Store the trolley in a dry place when not in use.

## 7. TROUBLESHOOTING

---

If you encounter issues with your transport trolley, refer to the following common problems and solutions:

- **Problem:** Trolley is difficult to move.  
**Solution:** Check if the brakes are fully disengaged. Inspect wheels for obstructions (e.g., dirt, hair) or damage. Ensure the load is not exceeding the maximum capacity.
- **Problem:** Appliance feels unstable on the trolley.  
**Solution:** Ensure the appliance is centered on the trolley. Verify that the trolley's dimensions are correctly adjusted to the appliance's base. Make sure the surface is level.
- **Problem:** Brakes are not holding the trolley securely.  
**Solution:** Check if the brake levers are fully engaged. Inspect the brake mechanism for any damage or wear.

## 8. SPECIFICATIONS

---

<b>Brand</b>	Xavax
<b>Model Number</b>	00111361
<b>Color</b>	White / Black
<b>Material</b>	Metal (Steel)
<b>Minimum Length</b>	43 cm
<b>Maximum Length</b>	70 cm
<b>Minimum Width</b>	43 cm
<b>Maximum Width</b>	70 cm
<b>Maximum Height</b>	4.8 cm
<b>Product Dimensions (L x W x H)</b>	48.8 x 44.5 x 5 cm (approximate, as packaged)
<b>Item Weight</b>	3.15 kg
<b>Maximum Load Capacity</b>	300 kg
<b>Braking System</b>	Yes

<b>Wheels</b>	6 plastic wheels
---------------	------------------

## 9. WARRANTY AND SUPPORT

---

Specific warranty information for the Xavax Transport Trolley (Model 00111361) is not provided in this manual. Please refer to the retailer's purchase terms or the manufacturer's official website for detailed warranty conditions. For technical support, spare parts availability, or further assistance, please contact Xavax customer service or your point of purchase. Keep your proof of purchase for any warranty claims.

**Manufacturer:** Xavax