

[Manuals.plus](#) /

> [SONGMICS](#) /

> SONGMICS Trampoline Safety Pad User Manual

SONGMICS STP8FT

SONGMICS Trampoline Safety Pad User Manual

Model: STP8FT

1. INTRODUCTION

The SONGMICS Trampoline Safety Pad is designed to provide enhanced protection by covering the trampoline's springs and frame, preventing injuries during use. This replacement pad is UV-resistant and tear-resistant, ensuring durability and long-lasting performance. It is specifically designed for round trampolines with a diameter of 244 cm.



Image 1.1: The SONGMICS 244 cm Blue Trampoline Safety Pad, designed to cover the springs and frame for safety.

2. PRODUCT FEATURES

- **Enhanced Safety:** Replaces old or damaged trampoline edge covers, providing a safe barrier over springs and the frame to prevent injuries.
- **Premium Materials:** Constructed with a 310 g/m² (500D) PVC surface, 15 mm thick EPE foam padding, and a 130 g/m² PE bottom layer for superior quality and protection.
- **Durable and Weather-Resistant:** The spring cover is UV-resistant and waterproof, protecting your trampoline in various weather conditions. High-quality stitching prevents tearing even with frequent use.
- **360° Protection:** With a width of 300 mm and a thickness of 15 mm, this pad ensures comprehensive coverage, preventing painful landings on the trampoline springs.
- **Easy Installation:** Features simple straps underneath the safety mat for quick and secure attachment to your trampoline frame.



Image 2.1: A person enjoying the trampoline, demonstrating the safety pad in active use.



Image 2.2: A child resting on the trampoline, highlighting the soft and protective surface of the safety pad.



Image 2.3: A child on a trampoline, demonstrating the effective coverage and safety provided by the pad.



Image 2.4: Illustration of the multi-layered construction of the safety pad, highlighting the durable PVC surface, thick EPE foam, and PE bottom layer.



Image 2.5: Detailed view of the safety pad's robust material, the cushioning foam, and the integrated warning label for user awareness.

3. SPECIFICATIONS

Attribute	Value
Model Number	STP8FT
Color	Blue
Outer Diameter	244 cm (8 FT)
Inner Diameter	184 cm
Pad Width	300 mm (30 cm)
Pad Thickness	15 mm
Top Surface Material	PVC 500D (310 g/m ²)
Padding Material	EPE Foam
Bottom Surface Material	PE (130 g/m ²)
Weight	2.17 kg
Shape	Round



Image 3.1: Dimensional diagram illustrating the safety pad's diameter, width, and skirt width for different trampoline sizes.

4. SAFETY INFORMATION AND PRECAUTIONS

To ensure the safety of all users, please adhere to the following guidelines:

- Always verify the measurements of your trampoline before ordering a replacement pad to ensure compatibility. This pad is compatible with standard 244 cm (8 FT) diameter round trampolines.
- Strictly follow all trampoline usage instructions provided by the trampoline manufacturer.
- Regularly inspect the safety pad for any signs of wear, tear, or damage. Replace the pad immediately if any damage is observed to maintain safety.
- Ensure the safety pad is securely fastened to the trampoline frame at all times to prevent displacement during use.
- This product is a safety pad replacement only and does not include the trampoline itself.

5. INSTALLATION GUIDE

Installing your SONGMICS Trampoline Safety Pad is a straightforward process. Follow these steps for a secure fit:

1. **Prepare the Trampoline:** Ensure your trampoline is clean and free of debris. If replacing an old pad, remove it completely.
2. **Position the Pad:** Carefully place the new SONGMICS safety pad over the trampoline frame, ensuring it is centered and covers all springs.
3. **Secure the Straps:** Locate the attachment straps on the underside of the safety pad. Thread these straps around the trampoline frame and tie them securely. Ensure all straps are tightly fastened to prevent the pad from shifting during use.
4. **Final Check:** Once all straps are secured, gently pull on the pad in various places to confirm it is firmly attached and does not move.



Image 5.1: Step-by-step visual guide for installing the safety pad onto a trampoline frame, showing how it covers the springs.

6. MAINTENANCE

Proper maintenance will extend the life of your trampoline safety pad:

- **Cleaning:** Wipe the surface of the pad with a damp cloth and mild soap as needed. Rinse thoroughly with water and allow it to air dry completely before use. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check the pad for any signs of wear, fading, cracks, or tears, especially after periods of heavy use or extreme weather.
- **Storage:** If the trampoline is not in use for an extended period, especially during winter months, it is recommended to remove the safety pad and store it in a dry, sheltered area to protect it from harsh elements.

7. TROUBLESHOOTING

Here are some common issues and their solutions:

- **Pad Does Not Fit:** Ensure you have purchased the correct size pad for your trampoline's diameter. This pad is designed for 244 cm (8 FT) round trampolines. Double-check your trampoline's measurements.
- **Pad Shifts During Use:** Make sure all attachment straps are securely and tightly fastened to the trampoline frame. Re-tie any loose straps.
- **Pad Shows Premature Wear:** While the pad is UV and tear-resistant, extreme conditions or improper use can accelerate wear. Ensure it is not exposed to sharp objects. Consider storing it indoors during prolonged periods of non-use or harsh weather.

8. WARRANTY AND SUPPORT

For any questions regarding your SONGMICS Trampoline Safety Pad, or for warranty information, please contact SONGMICS customer support through their official website or the retailer where the product was purchased. Please have your model number (STP8FT) and purchase details ready when contacting support.

Visit the official SONGMICS store for more information: [SONGMICS Store](#)



