

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BRITAX](#) /
- › [Britax Boulevard ClickTight Convertible Car Seat Instruction Manual](#)

BRITAX E1A325Q

Britax Boulevard ClickTight Convertible Car Seat Instruction Manual

Brand: BRITAX | Model: E1A325Q

INTRODUCTION AND OVERVIEW

The Britax Boulevard ClickTight Convertible Car Seat is engineered for safety, comfort, and convenience, providing peace of mind for parents on the go. It features the patented ClickTight Installation System, an extra layer of side impact protection, and SafeCell Impact Protection. This convertible car seat is designed to grow with your child, supporting both rear-facing and forward-facing modes.

- **Easy Installation:** Patented ClickTight system simplifies car seat installation to buckling a seat belt.
- **No Rethreading:** Quick-adjust 14-position harness with Click & Safe Snug Indicator for proper tightness without rethreading.
- **Surrounded in Safety:** Features 2 layers of side impact protection, a steel frame, and an impact-absorbing base.
- **Versatile Use:** Suitable for rear-facing children from 5 to 40 pounds and forward-facing children from 20 to 65 pounds.



Image: The Britax Boulevard ClickTight Convertible Car Seat in Circa, showcasing its full design and harness system.

SETUP AND INSTALLATION

The ClickTight Installation System makes proper car seat installation as simple as buckling a seat belt. This system ensures a secure and confident installation every time.

ClickTight Installation Steps:

1. Push the dial, turn, and lift the car seat's front panel to open the ClickTight system.
2. Thread the vehicle's seat belt through the designated belt path (rear-facing or forward-facing) and buckle it.
3. Click the car seat's front panel closed. The system will automatically tension the seat belt for a secure fit.

INSTALL WITH CONFIDENCE EVERY TIME.

CLICK TIGHT INSTALLATION



**Push Dial,
Turn & Lift**



**Thread &
Buckle**



**Click It
Closed!**

Image: A visual guide demonstrating the three simple steps for installing the car seat using the ClickTight system.

Official Installation Video:

Your browser does not support the video tag.

Video: An official Britax video demonstrating the ClickTight installation process for both rear and forward-facing modes, highlighting the ease of use and safety features.

SAFETY FEATURES

The Boulevard ClickTight car seat is designed with multiple layers of protection to keep your child safe.

- **SafeCell Impact Protection:** This integrated system includes a steel frame, an energy-absorbing base, a V-shaped tether to minimize seat rotation, and staged-release stitches that slow and reduce forward movement in the event of a crash.
- **Side Impact Protection:** Two strong layers of side energy absorption, including a deep foam-lined shell and head protection, shield your child from side impacts.
- **Click & Safe Snug Harness Indicator:** Provides an audible click when the harness is pulled to the proper tightness, ensuring a secure fit every time.

Safety, Comfort & Convenience



Image: A close-up of the car seat illustrating the two layers of side impact protection and the plush, nap-friendly padding.

Safety, Comfort & Convenience



Image: The rear view of the car seat showing the high-strength steel frame and the patented V-shaped tether, key components of SafeCell Impact Protection.

COMFORT & CONVENIENCE

Beyond safety, the Boulevard ClickTight offers features designed for your child's comfort and your convenience.

- **7 Recline Positions:** Ensures premium comfort for your child in both rear and forward-facing modes. Easy-read level indicators help confirm the correct angle.
- **14-Position Easy Adjust Harness & Headrest:** Grows with your child, allowing you to change the height with just the push of a button, eliminating the need for rethreading.
- **Nanotex Fabric:** Resists stains and odors, keeping your child cool and comfortable.
- **Removable Cover & Flip-Forward Buckle:** The cover can be removed without disassembling the harness, and the buckle stays out of the way for easy loading and unloading.

Safety, Comfort & Convenience

14-Position, Quick-Adjust Harness & Headrest



Image: A view of the car seat's headrest and harness, demonstrating the 14 adjustable positions for growing children.



Safety, Comfort & Convenience

Removable Cover

Flip-Forward Buckle

Click & Safe
Harness Indicator

Image: A close-up of the car seat's harness and buckle area, pointing out the removable cover, flip-forward buckle, and the Click & Safe harness indicator.

USAGE MODES

The Britax Boulevard ClickTight Convertible Car Seat adapts to your child's growth, offering two primary usage modes:

Rear-Facing Mode:

For infants and toddlers weighing 5 to 40 pounds. Britax strongly recommends that children ride rear-facing to the highest weight or height specified by their car seat manufacturer. The American Academy of Pediatrics recommends that all infants and toddlers should ride in a rear-facing car seat until they are 2 years of age or until they reach the highest weight or height allowed by their car seat manufacturer.

Forward-Facing Mode:

For children weighing 20 to 65 pounds, with a standing height of 49 inches or less.

Rear-Facing
5 - 40lbs



Forward-Facing
20 - 65lbs



Image: A side-by-side comparison showing the car seat configured for rear-facing use (for children 5-40 lbs) and forward-facing use (for children 20-65 lbs).

SPECIFICATIONS

Feature	Detail
Product Dimensions	23 x 18.5 x 23.5 inches (LxWxH)
Item Model Number	E1A325Q
Target Gender	Unisex
Minimum Weight Recommendation	5 Pounds
Maximum Weight Recommendation	65 Pounds
Maximum Height Recommendation	49 Inches
Material Type	Alloy Steel
Number of Reclining Positions	7

Harness Type	5-Point
Item Weight	29.4 pounds
Installation Type	ClickTight Installation



Image: The car seat with its key dimensions (length, width, height) clearly marked.

MAINTENANCE

Regular cleaning and maintenance will help prolong the life of your car seat and ensure continued safety and comfort for your child.

- **Cleaning Fabric:** The Nanotex fabric is designed to resist stains and odors. For general cleaning, spot clean with mild soap and water. The seat cover is removable for more thorough cleaning. Refer to the full user manual for specific washing instructions.
- **Cleaning Harness:** Wipe the harness straps with a damp cloth. Do not machine wash or submerge harness straps in water, as this may weaken them.
- **Cleaning Shell:** The car seat shell can be wiped clean with a damp cloth and mild soap.
- **Inspection:** Periodically inspect the car seat for any signs of damage, wear, or missing parts. Ensure all components are securely attached.

TROUBLESHOOTING

If you encounter any issues with your Britax Boulevard ClickTight car seat, please refer to the following common troubleshooting tips or consult the full user manual for detailed guidance.

- **Difficulty with ClickTight Installation:** Ensure the vehicle's seat belt is fully extended and routed correctly through the designated belt path. Make sure there is no slack before closing the ClickTight panel.
- **Harness Too Loose/Tight:** Use the quick-adjust 14-position harness and the Click & Safe Snug Harness Indicator to achieve the proper fit. The indicator will click when the harness is adequately tightened.
- **Car Seat Not Level:** Utilize the 7 recline positions and the easy-read level indicators on the side of the car seat to ensure it is properly angled for your child's weight and mode of use.

For more complex issues or concerns, please contact Britax Customer Service or refer to the comprehensive user manual available for download.

WARRANTY AND SUPPORT

Britax offers a limited warranty on its car seats, covering defects in materials and workmanship. For specific warranty terms, registration, and support, please refer to the official Britax website or the user manual provided with your product.

You can download the full user manual for detailed instructions and safety information from the official Britax website or via this direct link: [User Manual \(PDF\)](#).