

## Jané Epic + Koos Travel System

# Jané Epic + Koos Travel System User Manual

Model: Epic + Koos Travel System

## 1. INTRODUCTION

This manual provides essential information for the safe and proper use, assembly, and maintenance of your Jané Epic + Koos Travel System. Please read this manual thoroughly before using the product and retain it for future reference.

The Jané Epic + Koos Travel System combines a versatile stroller with a lightweight infant car seat, designed for comfort, safety, and ease of use from birth up to 13 kg (approximately 18 months). Its urban and pioneering design features a robust tubular aluminum chassis, hardwearing PU tyres, and independent, long-travel suspension for excellent maneuverability and a smooth ride.

## 2. SAFETY INFORMATION

**WARNING: Failure to follow these instructions could result in serious injury or death.**

- Always secure your child with the harness system when using the stroller or car seat.
- Never leave your child unattended in the stroller or car seat.
- Ensure all locking devices are engaged before use.
- Do not overload the stroller with additional bags or accessories, as this may cause instability.
- The Koos car seat is designed for infants from birth up to 13 kg (Group 0+). Do not use for children exceeding this weight limit.
- Always install the Koos car seat correctly in your vehicle according to the car seat's specific instructions and your vehicle's manual. The Koos car seat includes an Anti-Rotation device for greater protection.
- Regularly inspect the product for loose parts, damaged components, or worn fabric. Discontinue use if any damage is found.
- Keep children away from moving parts during adjustment or folding.

## 3. COMPONENTS OVERVIEW

The Jané Epic + Koos Travel System includes the following main components:

- **Jané Epic Stroller:** Features a lightweight aluminum chassis, reversible seat, adjustable handlebar, and robust wheels with independent suspension.

- **Jané Koos Infant Car Seat:** A lightweight Group 0+ car seat with a 3-point harness, side impact protection, and a canopy.
- **Rain Cover:** (May be included depending on package) Provides protection from weather elements.



Figure 3.1: The Jané Epic + Koos Travel System, showing the stroller and infant car seat in a vibrant lime yellow color. The stroller features a sturdy frame and a comfortable seat, while the car seat is designed for infant safety and portability.



Figure 3.2: Close-up view of the Jané Koos Infant Car Seat, highlighting its ergonomic design and safety harness. The car seat is shown with its canopy extended, providing shade for the infant.

## 4. SETUP AND ASSEMBLY

### 4.1. Stroller Assembly (Jané Epic)

1. **Unfolding the Chassis:** Release the folding lock (if engaged) and lift the handlebar until the chassis clicks into place, indicating it is fully open.
2. **Attaching the Wheels:** Insert the front and rear wheels into their respective slots until they lock securely. Ensure they are firmly attached by pulling on them.
3. **Attaching the Seat Unit:** Align the seat unit with the chassis connectors. Push down firmly until you hear a click, confirming it is securely attached. The seat is reversible and can be faced forwards or backwards.
4. **Adjusting the Handlebar:** Press the buttons on the side of the handlebar to adjust it to your desired height.



Figure 4.1: The Jané Epic Stroller fully assembled with the seat unit attached. This image demonstrates the stroller's robust frame and wheel design, ready for use.

## 4.2. Car Seat Installation (Jané Koos)

The Koos car seat can be installed in a vehicle using the vehicle's 3-point seat belt or attached to the Epic stroller chassis using the Pro-Fix system.

### 4.2.1. Vehicle Installation

1. Place the Koos car seat on the vehicle seat, ensuring it faces rearward.
2. Route the vehicle's 3-point seat belt through the designated guides on the car seat.
3. Buckle the seat belt and pull it tight to remove any slack, ensuring the car seat is firmly secured and does not move more than 1 inch in any direction.
4. Refer to the separate Koos car seat manual for detailed vehicle installation instructions and compatibility.

### 4.2.2. Attaching to Stroller Chassis (Pro-Fix System)

1. Ensure the stroller chassis is fully unfolded and locked.
2. Remove the stroller seat unit if it is attached.
3. Align the Koos car seat with the Pro-Fix connectors on the stroller chassis.
4. Lower the car seat onto the connectors until it clicks securely into place. Verify it is locked by gently lifting the car seat.



Figure 4.2: The Jané Epic Stroller with the Koos Infant Car Seat securely attached to the chassis, demonstrating the travel system configuration. This setup allows for easy transition from car to stroller.

## 5. OPERATING INSTRUCTIONS

---

### 5.1. Using the Jané Epic Stroller

- **Harness System:** Always secure your child with the 5-point harness. Adjust the shoulder straps to the appropriate height and ensure the harness is snug but comfortable.
- **Reclining the Seat:** Use the recline mechanism (usually a lever or button on the back of the seat) to adjust the seat to multiple positions for your child's comfort.
- **Reversing the Seat:** To change the seat direction, disengage the seat from the chassis (as if removing it), turn it around, and re-attach it until it clicks.
- **Braking:** Engage the foot brake located near the rear wheels when the stroller is stationary. Ensure both wheels are locked.
- **Folding the Stroller:** The Epic features a patented folding system, making it 10% more compact. Typically, this involves pressing release buttons on the handlebar or chassis and collapsing the frame. The seat can often be folded with the chassis.
- **Suspension:** The stroller features independent, long-travel suspension with 2 shock absorbers on the rear wheels for a smooth ride.



Figure 5.1: A close-up view of the Jané Epic stroller's handlebar, featuring the 'epic' branding. This handle is designed for comfortable grip and often incorporates adjustment mechanisms.



Figure 5.2: A detailed view of the Jané Epic stroller's rear wheel suspension system, showing the red shock absorbers. This feature provides a smoother ride for the child over varied terrain.

## 5.2. Using the Jané Koos Infant Car Seat

- **Harness Adjustment:** The Koos car seat features a one-pull 3-point safety harness for easy adjustment of length. Ensure the harness straps are at or below your child's shoulders when rear-facing.
- **Carrying Handle:** The handle can be adjusted to multiple positions for carrying or stability when placed on the

ground.

- **Canopy:** Extend or retract the canopy to provide shade and protection for your infant.
- **Side Impact Protection:** The Koos car seat is designed with side impact protection for enhanced safety.



Figure 5.3: A close-up image highlighting the "SIDE IMPACT PROTECTION KOOS" label on the side of the Jané Koos car seat, indicating a key safety feature.

## 6. MAINTENANCE AND CARE

- **Cleaning Fabric:** The fabric covers can typically be removed and hand-washed with mild soap and cold water. Refer to the care labels for specific instructions. Do not machine wash or tumble dry unless specified.
- **Cleaning Frame:** Wipe the chassis and plastic parts with a damp cloth and mild soap. Dry thoroughly.
- **Wheel Maintenance:** Regularly check wheels for debris and ensure they rotate freely. Lubricate axles if necessary.
- **Storage:** Store the travel system in a clean, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all fasteners, rivets, and moving parts to ensure they are secure and functioning correctly.

## 7. TROUBLESHOOTING

- **Stroller not folding/unfolding smoothly:** Check for any obstructions in the folding mechanism. Ensure all locks are disengaged.
- **Wheels squeaking:** Clean the wheel axles and apply a silicone-based lubricant.
- **Harness difficult to adjust:** Ensure the straps are not twisted and the adjustment mechanism is free of debris.
- **Car seat not attaching to chassis:** Verify the Pro-Fix connectors are aligned correctly and push firmly until a click is heard. Ensure no fabric is obstructing the connection.

If you encounter issues not covered here, please contact Jané customer support.

## 8. SPECIFICATIONS

| Feature                                  | Specification  |
|--|--|
| Brand                                    | Jané   |
| Model                                    | Epic + Koos Travel System                                  |
| Maximum Weight Recommendation (Car Seat) | 13 Kilograms (Group 0+)                                    |
| Manufacturer Recommended Age             | 0 months and up  |
| Material (Stroller/Car Seat)             | Polyurethane (Tyres: Rubber)                               |
| Frame Material                           | Aluminium  |
| Harness Type                             | 3 Point (Koos Car Seat)                                    |
| Suspension                               | Fully Adjustable (Independent, long travel on rear wheels) |
| Wheel Type                               | Lockable & Removable                                       |
| Item Weight (Travel System)              | 12 kg  |
| Package Dimensions                       | 75.4 x 74.2 x 53.4 cm                                      |
| Koos Car Seat Weight                     | 2.50 kg  |

## 9. WARRANTY AND SUPPORT

Jané products are manufactured to high-quality standards. For warranty information, please refer to the documentation included with your purchase or visit the official Jané website. Keep your proof of purchase for warranty claims.


For technical support, spare parts, or further assistance, please contact your local Jané distributor or customer service. Contact details can typically be found on the Jané official website or product packaging.




**Manufacturer:** Jané S.A.

**Date First Available:** 9 November 2015

© 2023 Jané S.A. All rights reserved. This manual is for informational purposes only.

### Related Documents

|   |   |
|---|---|
|  | <p><a href="#">Jané Travel Baby Carrier: Instructions, Safety, and Usage Guide</a></p> <p>Comprehensive guide to using the Jané Travel baby carrier, including safety instructions, usage steps, washing care, and product specifications. Learn how to safely carry your baby in multiple positions.</p> |
|---|---|

|   |  |
|---|--|
|  | <p><a href="#">Jane Rider Pushchair User Manual and Instructions</a></p> <p>This document provides comprehensive instructions and safety information for the Jane Rider pushchair, detailing assembly, usage, maintenance, and warranty. It is available in multiple languages including English, Spanish, French, German, Italian, Portuguese, Polish, and Czech.</p> |
|  | <p><a href="#">Jané Muum Pro 2 Baby Stroller: Safety Instructions and Guidelines</a></p> <p>Comprehensive safety instructions, warnings, maintenance, and warranty information for the Jané Muum Pro 2 baby stroller. Ensure safe use and proper care for your child.</p>  |
|  | <p><a href="#">Jané Stroller Safety, Usage, and Maintenance Guide</a></p> <p>Comprehensive safety instructions, usage guidelines, maintenance tips, warranty information, and product registration details for the Jané stroller (Model IM 2511, 01).</p>  |