

Unicliffe Unicliffe-UL062

Unicliffe UL400 Submersible Water Pump Instruction Manual

Model: Unicliffe-UL062

1. INTRODUCTION

Thank you for choosing the Unicliffe UL400 Submersible Water Pump. This versatile pump is designed for a variety of applications, including aquariums, hydroponic systems, fish tanks, fountains, ponds, and statuary. Its compact size, adjustable flow, and quiet operation make it an ideal choice for both indoor and outdoor use. Please read this manual thoroughly before operation to ensure proper setup and maintenance.

Key Features:

- **Multiple Uses:** Suitable for indoor and outdoor applications like bird baths, sculpture cleaning, vase fountains, and aquariums.
- **Adjustable Water Flow:** Max flow rate of 400 GPH (1500 L/H) and a max lift height of 7 ft, with 25W power.
- **Detachable and Quiet:** Easy to clean without tools, featuring 4 strong suction cups for stable and quiet operation.
- **Long Life-span:** Engineered for over 20,000 hours of use, thanks to protective NdFeB magnets, an alumina ceramic impeller shaft, and epoxy resin.
- **Included Accessories:** Comes with a 6-foot UL listed waterproof power cord (US plug), an adjustable regulator, and two nozzles for 1/2" and 2/3" ID hoses.

2. SAFETY INFORMATION

To prevent personal injury or pump damage, please observe the following safety precautions:

- Read all instructions carefully before operating the pump.
- Ensure the power supply voltage (110V AC) and wattage (25W) match the pump's requirements.
- Always disconnect the power cord from the electrical outlet before handling, installing, or performing any maintenance on the pump.
- **DO NOT RUN DRY:** This pump is designed for submersible use only. Operating the pump out of water will cause permanent damage and void the warranty.
- Keep the pump and power cord away from heat sources and sharp objects.
- Do not use the pump with flammable or corrosive liquids.
- This pump is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Please check the package to ensure all items are present and in good condition:

- 1 x Uniclife UL400 Submersible Water Pump
- 1 x 6-foot UL Listed Power Cord (integrated)
- 1 x Adjustable Flow Regulator
- 2 x Nozzles (for 1/2" ID and 2/3" ID hoses)
- 4 x Suction Cups (pre-attached to pump base)

4. SETUP

Follow these steps to set up your Uniclife UL400 Submersible Water Pump:

1. **Attach Nozzle:** Select the appropriate nozzle (1/2" or 2/3" ID) for your hose and securely attach it to the pump's water outlet.
2. **Positioning:** Place the pump completely submerged in water. The four strong suction cups on the base can be used to secure the pump to a smooth surface, such as the bottom or side of an aquarium or fountain basin.
3. **Connect Hose:** Connect your hose to the attached nozzle. Ensure a tight fit to prevent leaks.
4. **Adjust Flow (Initial):** If desired, you can pre-adjust the water flow regulator on the front of the pump before powering it on.
5. **Power Connection:** Plug the 6-foot UL listed power cord into a suitable 110V AC power outlet.



Image: The Unicliffe UL400 Submersible Water Pump shown with its main body and two interchangeable nozzles.



Image: A diagram illustrating the compact dimensions of the pump (3.54"L x 2.36"W x 2.75"H) and the two included nozzle sizes (1/2" and 2/3" ID).

Your browser does not support the video tag.

Video: An official Uniclife video demonstrating the setup and initial operation of the 400 GPH submersible water pump, including a visual reminder not to run the pump dry.

5. OPERATING INSTRUCTIONS

Once the pump is properly set up, follow these instructions for operation:

1. **Ensure Submersion:** Before plugging in the pump, always confirm it is fully submerged in water. Running the pump dry will cause damage.
2. **Power On:** Connect the pump's power cord to a compatible 110V AC electrical outlet. The pump will immediately begin to circulate water.
3. **Adjust Water Flow:** Use the adjustable regulator dial located on the front of the pump to control the water flow rate. Turn the dial towards the '+' symbol to increase flow and towards the '-' symbol to decrease flow.

4. **Continuous Operation:** The Uniclife UL400 pump is designed for continuous operation in appropriate water environments.



ADJUSTABLE WATER FLOW

Precisely control water flow to meet your needs

MAX FLOW RATE :
360 GPH (1360 L / H)

MAX LIFT HEIGHT :
7 ft (2.1m)

POWER :
25 W

Image: The pump highlighting its adjustable water flow feature, showing the dial for controlling output.

6. MAINTENANCE

Regular cleaning and maintenance are crucial for the optimal performance and extended lifespan of your Uniclife UL400 pump. Neglecting maintenance can lead to reduced flow, increased noise, or pump failure.

1. **Disconnect Power:** Always unplug the pump from the electrical outlet before attempting any cleaning or maintenance.
2. **Disassemble:** The pump features a detachable design for easy access to internal components. Gently remove the front cover and then the impeller assembly.
3. **Clean Components:** Rinse all removed parts (front cover, impeller, impeller shaft, and pump housing interior) with clean water. Use a small brush or cotton swab to remove any accumulated debris, algae, or mineral deposits. Pay special attention to the impeller and its housing.

- 4. **Inspect Impeller:** Check the impeller for any signs of wear, cracks, or damage. Ensure it spins freely without obstruction.
- 5. **Reassemble:** Carefully reassemble the pump, ensuring all parts fit securely and are properly aligned.
- 6. **Frequency:** The frequency of cleaning depends on the water quality and the pump's usage. For aquariums, weekly or bi-weekly cleaning may be necessary. For outdoor fountains or ponds, monthly cleaning is often sufficient.

COMPACT SIZE

Suitable for both indoor and outdoor use



Image: A visual guide demonstrating how to detach the pump's front cover and remove the impeller for cleaning.

7. TROUBLESHOOTING

If you encounter issues with your Uniclife UL400 pump, refer to the table below for common problems and their solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Pump not operating	No power supply; Impeller jammed; Airlock; Timer malfunction (if applicable)	Check power connection and outlet; Disconnect power and clean impeller; Ensure pump is fully submerged and free of air bubbles; Verify external timer functionality.
Reduced water flow	Clogged intake or nozzle; Dirty impeller; Low water level	Clean pump intake and nozzle; Disconnect power and clean impeller; Add water to ensure pump is fully submerged.
Noisy operation	Air in pump; Debris in impeller; Pump not stable on surface	Ensure pump is fully submerged and free of air; Disconnect power and clean impeller; Secure pump firmly with suction cups to a smooth surface.
Pump stops intermittently	Power interruption; Overheating (unlikely for this model under normal use)	Check power connection and outlet; Ensure adequate water circulation around the pump.

8. SPECIFICATIONS

Feature	Detail
Brand	Unicliffe
Model Number	Unicliffe-UL062
Power	25 Watts
Voltage	110 Volts (AC)
Maximum Flow Rate	400 GPH (Gallons Per Hour) / 1500 L/H (Liters Per Hour)
Maximum Lifting Height	7 Feet
Product Dimensions (L x W x H)	3.54" x 2.36" x 2.75"
Material	Ceramic (impeller shaft), NdFeB magnets, Epoxy Resin
Power Cord Length	6 feet (UL Listed)
Nozzle Sizes Included	1/2" ID and 2/3" ID
Item Weight	1.12 pounds

9. WARRANTY AND SUPPORT

Warranty: The Uniclife UL400 Submersible Water Pump comes with a 12-month warranty from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects and does not cover damage caused by misuse, neglect, or running the pump dry.

Customer Support: For any questions, technical assistance, or warranty claims, please contact Uniclife customer support. You can find contact information on the product packaging or by visiting the official Uniclife website. For additional resources and products, please visit our Amazon store:

[Uniclife Amazon Store](#)