

[Manuals.plus](#) /

› [Dr. Brown's](#) /

› Dr. Brown's Deluxe Electric Sterilizer (Model AC045) Instruction Manual

Dr. Brown's AC045

Dr. Brown's Deluxe Electric Sterilizer (Model AC045) Instruction Manual

Model: AC045

INTRODUCTION

The Dr. Brown's Deluxe Electric Sterilizer is designed to efficiently sterilize baby bottles, bottle parts, pacifiers, and other baby essentials. This unit utilizes steam to eliminate 99.9% of bacteria, mold, and yeast, ensuring a hygienic environment for your baby's feeding accessories. Its user-friendly design includes easy-touch electronic controls, cycle indicators, and an automatic shut-off feature for safe and convenient operation.



Image: The Dr. Brown's Deluxe Electric Sterilizer, a white unit with a translucent grey top, featuring control buttons on the front.

SAFETY INFORMATION

- Always unplug the sterilizer from the outlet and allow it to cool for at least 60 minutes before cleaning or handling.
- **DO NOT IMMERSE THE BASE UNIT IN WATER.**
- The sterilizer features an automatic shut-off to prevent overheating once the cycle is complete.
- This product is made from BPA-free plastic.
- Sterilization eliminates 99.9% of bacteria, mold, and thrush-causing yeast.

PACKAGE CONTENTS

Your Dr. Brown's Deluxe Electric Sterilizer package includes:

- Dr. Brown's Deluxe Electric Sterilizer Base Unit
- Removable Bottle Tray

- Accessory Tray
- Measuring Cup
- Tongs

Safe Handling.

Features a removable tray, measuring cup and tongs, making it easy to handle sterilized bottles and parts.



Image: The removable bottle tray, measuring cup, and tongs, essential tools for operating the sterilizer.

SETUP

1. Place the sterilizer base unit on a flat, heat-resistant surface.
2. Ensure the unit is unplugged before adding water or loading items.
3. Remove the removable bottle tray and accessory tray from the unit.
4. Using the provided measuring cup, add the recommended amount of distilled water (refer to the water level markings on the measuring cup) directly onto the heating plate at the bottom of the sterilizer base.

OPERATING INSTRUCTIONS

Follow these steps to sterilize your baby's items:

1. **Prepare Items:** Wash all bottles, parts, pacifiers, and other items thoroughly before placing them in the sterilizer.
2. **Load Bottles:** Place up to six clean bottles upside down on the removable bottle tray. The design accommodates all Dr. Brown's bottles and most other brands.
3. **Load Accessories:** Place smaller items such as nipples, pacifiers, and bottle parts in the accessory tray. This tray is designed to hold various small items securely.
4. **Assemble:** Place the loaded removable bottle tray into the sterilizer base, followed by the accessory tray on top.
5. **Close Lid:** Securely close the sterilizer lid.
6. **Start Cycle:** Plug the unit into an electrical outlet. Press the power button, then press the start button. The cycle indicators (heat, cool down, ready) will illuminate to show the current stage of sterilization.
7. **Auto Shut-off:** The sterilizer will automatically turn off once the sterilization and cool-down cycles are complete.
8. **Remove Items:** Use the provided tongs to safely remove sterilized items from the unit, as they will be hot.

Save time.

Large capacity sterilizes
up to 6 baby bottles at once.



Image: The sterilizer interior showing six bottles placed upside down on the removable tray, ready for sterilization.

Newborn Essentials.

Convenient built-in accessory tray allows for all of baby's accessories to be sterilized at once.



Image: The accessory tray holding various small items like pacifiers and bottle parts, demonstrating its capacity.

Easy-to-operate

electronic controls feature cycle indicators and a convenient auto shut-off when cycle is complete.



Image: A close-up view of the easy-touch electronic controls with illuminated cycle indicators for heat, cool down, and ready states.

Video: An official product overview demonstrating the features and ease of use of the Dr. Brown's Deluxe Electric Sterilizer.

MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your sterilizer.

- **Cleaning the Base and Heating Plate:** Wipe all surfaces of the base and heating plate with a damp cloth or sponge. Ensure the unit is unplugged and completely cool before cleaning.
- **Frequency:** Clean the sterilizer at least once a week when in regular use.
- **Descaling:** Over time, mineral deposits from water may accumulate on the heating plate. To descale, mix 2 oz (60 ml) of white vinegar with 4 oz (120 ml) of distilled water. Pour the mixture onto the heating plate and let it stand for 30 minutes. Do not run a cycle with the descaling solution. Pour out the solution and rinse the heating plate thoroughly with clean water.
- **DO NOT IMMERSE THE BASE UNIT IN WATER.**
- **Dishwasher Safe:** The removable bottle tray, accessory tray, measuring cup, and tongs are not specified as

dishwasher safe. Hand wash these components with warm, soapy water and rinse thoroughly.

TROUBLESHOOTING

If you encounter any issues with your Dr. Brown's Deluxe Electric Sterilizer, please consider the following:

- **Unit Not Turning On:** Ensure the power cord is securely plugged into both the unit and a working electrical outlet.
- **Sterilization Cycle Not Starting:** Verify that the lid is properly closed and latched. Ensure sufficient water has been added to the heating plate.
- **Excessive Mineral Buildup:** Perform the descaling procedure as outlined in the Maintenance section. Using distilled water regularly can help prevent this.
- For further assistance, please refer to the full product manual or contact Dr. Brown's customer support.

SPECIFICATIONS

Product Dimensions	13.3 x 12.8 x 10 inches
Item Model Number	AC045
Material Type	Plastic (BPA Free)
Power Source	Corded Electric
Item Weight	5.6 pounds
Capacity	Up to 6 baby bottles
Additional Features	Automatic Shut Off, Sterilization eliminates 99.9% of bacteria, mold and thrush-causing yeast.

WARRANTY & SUPPORT

The warranty for the Dr. Brown's Deluxe Electric Sterilizer is valid in the US and Canada only. For specific warranty details, claims, or customer support, please refer to the warranty card included with your product or visit the official Dr. Brown's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question