

Manuals.plus /

- › Ellia /
- › Ellia Soothe Ultrasonic Essential Oil Diffuser (ARM-310WT) User Manual

Ellia ARM-310WT

Ellia Soothe Ultrasonic Essential Oil Diffuser (ARM-310WT) User Manual

INTRODUCTION

The Ellia Soothe Ultrasonic Essential Oil Diffuser utilizes high-frequency ultrasonic technology to convert water and essential oil into a fine mist. This mist is dispersed into the air, providing a subtle aroma and gentle humidity. The diffuser also features a color-changing light to enhance your environment, promoting relaxation and well-being.

Thank you for choosing the Ellia Soothe Diffuser. Please read this manual thoroughly before use to ensure proper operation and to maximize your experience.





The Ellia Soothe diffuser, a white cylindrical device with a translucent top, releases a gentle mist into the air.

IMPORTANT SAFEGUARDS

To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- Read all instructions before use.
- Always place the diffuser on a firm, flat, waterproof surface.
- Keep the diffuser away from heat sources and direct sunlight.
- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.

- Only use the AC adapter provided with the unit.
- Never operate the diffuser if the cord or plug is damaged.
- Do not immerse the base in water or other liquids.
- Unplug the unit during filling and cleaning.

SETUP

Follow these steps to set up your Ellia Soothe Diffuser:

1. Remove the outer cover from the base.
2. Remove the inner cover.
3. Pour clean tap water into the reservoir until it reaches the maximum fill line. Do not overfill.
4. Add 5-7 drops of your preferred essential oil directly into the water.
5. Replace the inner cover, then the outer cover, ensuring they are securely in place.
6. Plug the AC adapter into the diffuser's power input, then plug the adapter into a wall outlet.

EASY TO USE

Pour water into the reservoir until it reaches the max fill line, then add 5-7 drops of your favorite essential oil



A close-up view of a hand carefully pouring water into the open reservoir of the diffuser, illustrating the water-filling step.

PERSONALIZED AROMATHERAPY



Using the essential oil of your choice,
mix and match fragrances to create
your own **one-of-a-kind aroma**

This image displays the Ellia Soothe diffuser alongside several small bottles of essential oils and its power adapter, illustrating the components for personalized aromatherapy.

OPERATING INSTRUCTIONS

Power On/Off and Mist Control

- Press the **Power Button** once for **continuous mist**. The diffuser will run for approximately 6.5 hours.
- Press the **Power Button** a second time for **intermittent mist** (30 seconds on, 30 seconds off). The diffuser will run for approximately 13 hours.
- Press the **Power Button** a third time to turn the diffuser off.
- The unit will automatically shut off when the water reservoir is empty.

Light Control

- Press the **Light Button** once to turn on the **color-changing light**. The light will cycle through various colors.

- Press the **Light Button** a second time to pause the light on your preferred color.
- Press the **Light Button** a third time to turn the light off.



CONVENIENT CONTROLS

User-friendly operation with programmed controls makes it **effortless** to relax after a long day

This image provides a detailed view of the diffuser's top panel, showing the power button and the light control button for easy operation.

COLOR-CHANGING LIGHT



Relax in the ambient
color-changing light for up to
6.5 hours of continuous runtime

This image features three diffusers, each illuminated with a different color (pink, blue, green), demonstrating the color-changing light feature.



ULTRASONIC OPERATION

Provides a light, pleasant aroma while gently humidifying your space

The diffuser is shown on a bedside table next to a lamp, actively producing a visible mist, highlighting its ultrasonic operation in a home setting.

MAINTENANCE AND CLEANING

Regular cleaning is essential for optimal performance and to prevent mineral buildup. Always unplug the diffuser before cleaning.

- Empty any remaining water from the reservoir.
- Wipe the inside of the reservoir with a soft, damp cloth.
- For mineral buildup, use a 50/50 mixture of white vinegar and water. Let it soak for 5 minutes, then gently wipe clean with a soft cloth or brush.
- Do not use harsh chemicals or abrasive cleaners, as these can damage the unit.
- Wipe the exterior of the diffuser with a soft, dry cloth.
- Ensure the ultrasonic membrane is clean and free of residue.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or low mist output	Insufficient water level; Unit not plugged in; Mineral buildup on ultrasonic membrane; Covers not properly placed.	Ensure water level is between min/max lines; Check power connection; Clean ultrasonic membrane as per maintenance instructions; Verify inner and outer covers are secure.
Light not working	Diffuser not powered on; Light function turned off.	Ensure diffuser is powered on; Press the light button to cycle through light options.
Unit leaks	Water reservoir overfilled; Covers not securely in place.	Do not overfill the water reservoir beyond the max fill line; Ensure both inner and outer covers are securely fastened.

SPECIFICATIONS

Brand: Ellia

Model Name: Soothe Ultrasonic Diffuser

Item Model Number: ARM-310WT

Capacity: 100 Milliliters

Power Source: Corded Electric

Special Features: Corded, Auto Shutoff, Color-Changing Light

Material: Plastic

Approximate Dimensions: 10.25 x 4 x 4 inches (Package Dimensions)

Item Weight: 16 ounces



DURABLE DESIGN

Consciously crafted, this handsome design enhances any decor

The diffuser is placed on a small round table in a living room, next to a potted plant and a person reading, showcasing its integration into home decor.

WARRANTY AND SUPPORT

For detailed warranty information or product support, please refer to the warranty card included with your original purchase. You may also visit the official Ellia website for further assistance and contact information. Please retain your proof of purchase for any warranty claims.