

## Scanmarker BLE

# Scanmarker Air Reading Pen & Pen Scanner User Manual

Model: BLE

Brand: Scanmarker

## INTRODUCTION

The Scanmarker Air is a wireless digital highlighter and translator pen designed to enhance productivity for students and professionals. It allows for instant text capture from printed materials directly to your computer, smartphone, or tablet. Beyond scanning, it offers powerful language translation, text-to-speech functionality, and broad compatibility across various operating systems.

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Scanmarker Air device to ensure optimal performance.

Your browser does not support the video tag.

Official product overview of the Scanmarker Air Pen Scanner, highlighting its key features and wireless capabilities.

## WHAT'S IN THE BOX

Your Scanmarker Air package includes the following items:

- Scanmarker Air Pen Scanner
- USB Charging Cable
- Bluetooth Dongle (for Windows computers)
- Quick Guide
- Soft Carrying Pouch

## What's in the box



# COMPLETE SET

A visual representation of all components included in the Scanmarker Air retail package.

## SETUP

### 1. Charging Your Scanmarker Air

Before first use, it is recommended to fully charge your Scanmarker Air. Connect the provided USB charging cable to the micro-USB port on the pen and the other end to a USB power source (e.g., computer USB port, wall adapter). The battery indicator light will show charging status.

### 2. Turning On/Off

To turn on the Scanmarker Air, press the scanning tip firmly against a flat surface (like a table or book) for approximately 3 seconds. The blue Bluetooth light will illuminate, indicating it's powered on. To turn off, repeat the same action: press the scanning tip against a surface for 3 seconds until the lights turn off.

Your browser does not support the video tag.

Demonstration of how to power on the Scanmarker Air by pressing its tip against a surface.

### 3. App Installation & Connection

Download the 'Scanmarker Air' application from your device's app store (App Store for iOS, Google Play Store for Android, or Scanmarker's website for Windows/Mac). Once installed, open the app and follow the on-screen instructions to pair your device via Bluetooth 4.0 or higher. For Windows computers without built-in Bluetooth, use the provided Bluetooth dongle.

Your browser does not support the video tag.

A user's guide on the easy setup process for the Scanmarker Air, including app installation and initial connection.

## OPERATING INSTRUCTIONS

### 1. Scanning Text

Once connected, simply slide the Scanmarker Air across a line of printed text. Ensure the pen is held at a slight angle (approximately 60-degree angle) and maintain a steady, even pace for optimal accuracy. The scanned text will appear instantly on your connected device.

The infographic features a central image of the Scanmarker Air device, a black handheld scanner with orange accents. Surrounding the device are six circular icons, each connected to a feature by a line. The features are: Bluetooth connection for Mac, Windows, iOS & Android; Rechargeable lithium polymer battery; 20 times faster than typing; Scans & translates over 70 languages; Scans 3000 characters per minute; and App reads aloud the scanned text. Below the device, a black banner contains the text 'Digital scanner/highlighter & reader' and 'HIGH-QUALITY' in large, bold letters.

Bluetooth connection for Mac, Windows, iOS & Android

Rechargeable lithium polymer battery

20 times faster than typing

Scans & translates over 70 languages

Scans 3000 characters per minute

App reads aloud the scanned text

— Digital scanner/highlighter & reader —

# HIGH-QUALITY

The Scanmarker Air in action, demonstrating its ability to quickly capture text from a physical document to a digital screen.

## 2. Text-to-Speech Functionality

The Scanmarker app can read the scanned text aloud in real-time. This feature is particularly useful for memorization, reading comprehension, and as an assistive tool for individuals with reading difficulties like dyslexia. Adjust the volume and speed within the app settings.



Text to  
speech



# READ ALOUD

The app will read aloud the text in real-time

The text-to-speech feature of the Scanmarker Air, allowing users to listen to scanned text in real-time.

### 3. Language Translation

The Scanmarker Air supports translation into over 140 languages. Within the app, select your desired input and output languages. Scan the text, and the translation will appear on your screen. This is ideal for language learning or quick reference while traveling.





High-quality  
Bluetooth  
connection

**NO**  
Monthly Fee



# FAST & EASY

Scan any document to your computer or phone

The multi-lingual translation capability of the Scanmarker Air, translating scanned text into various languages.

Your browser does not support the video tag.

A quick demonstration of the Scanmarker Air's scanning and translation features.

## MAINTENANCE

### Cleaning the Scanner

To ensure optimal scanning performance, keep the scanning window clean. Gently wipe the transparent tip with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.

### Battery Care

The Scanmarker Air is equipped with a rechargeable Lithium Polymer battery. To prolong battery life, avoid fully discharging the device frequently. Charge the device when the battery indicator is low. Store the device in a cool, dry place when not in use for extended periods.

# TROUBLESHOOTING

## Common Issues and Solutions

- **Connection Issues:** Ensure Bluetooth is enabled on your device and the Scanmarker Air is powered on. Try restarting both the pen and your device. If using a Windows PC, ensure the Bluetooth dongle is properly inserted.
- **Inaccurate Scanning:** Ensure the scanning tip is clean. Hold the pen at the recommended 60-degree angle and maintain a steady, even pace. Scan on flat, non-glossy surfaces for best results.
- **Text Not Appearing:** Verify that the Scanmarker Air app is open and actively connected to the pen. Check if the input language in the app matches the language of the text being scanned.

## Support

For further assistance, free software updates, and 24/7 technical support, please visit the official Scanmarker website or contact their customer service. A comprehensive User Guide (PDF) is also available for download. Official User Guide (PDF): [Scanmarker Air User Guide](#)

# SPECIFICATIONS

Feature	Specification
Model Name	Scanmarker Air
Product Dimensions	5 x 0.9 x 0.7 inches
Item Weight	0.96 ounces (27.22 g)
Connectivity Technology	Bluetooth 4.0
Scanning Speed	3000 characters per minute
Resolution	300 dpi
Battery Type	1 Lithium Polymer (included)
Supported Languages	Over 140
Compatibility	Mac, Windows, iOS, Android
Interface	USB 2.0 (for charging)

## WARRANTY AND SUPPORT

Scanmarker offers a full one-year warranty on the Scanmarker Air Reading Pen & Pen Scanner, ensuring peace of mind with your purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For any questions, concerns, or technical assistance, Scanmarker provides free software updates and 24/7 technical support for the lifetime of your product. There are no hidden fees associated with support services.

Please refer to the official Scanmarker website for the most up-to-date warranty terms and contact information for support.