

[Manuals.plus](#) /

› [MINI LOP](#) /

› Nano Facial Mister User Manual

MINI LOP PWY-WHITE

Nano Facial Mister User Manual

Brand: **MINI LOP** | Model: **PWY-WHITE**

1. PRODUCT OVERVIEW

The MINI LOP Nano Facial Mister is a portable and compact device designed to moisturize and refresh your skin. Utilizing advanced nano atomization technology, it converts water into a fine mist that can be easily absorbed, providing deep hydration for your face, body, and even hair. It is suitable for all skin types and is particularly beneficial for soothing skin after sun exposure or facial treatments.

This handy sprayer is perfect for use in all seasons, offering a cooling sensation on hot days and helping to maintain skin hydration during dry winter months. Its pocket-sized design allows for convenient portability, fitting easily into handbags, purses, or schoolbags, ensuring you can enjoy a quick hydration boost anytime, anywhere.



Figure 1: The MINI LOP Nano Facial Mister.

Nano Facial Mister

Portable Mini Face Mist

Moisturize and Refresh your Skin: This small face nano mister is used for care of face, body, hair and other position. Suitable for all kinds of skin. Perfect for keeping your face hydrated and healthy

The image shows three Nano Facial Mister devices in different colors: red, grey, and white. They are all standing upright. To the right of the devices, a woman with blonde hair tied in a ponytail is shown in profile, holding her hands up and spraying water from the Nano Facial Mister onto her face. The background is a light blue gradient.

Figure 2: Product in use, demonstrating the fine mist.

2. SAFETY INFORMATION

- Always keep the facial mister away from children and pets.
- Allow the device to cool down completely before handling or refilling with water.
- Do not leave the device unattended while in operation to prevent potential burns or scalding.
- Do not use the mister with alcohol-based liquids, oils, or other non-water solutions, as this may damage the device or cause harm. Only use mineral water or distilled water.
- Avoid spraying directly into eyes or open wounds.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x MINI LOP Nano Facial Mister (White)
- 1 x USB Charging Cable
- 1 x User Manual

20ml-large water tank. Charge once, can spray about 50 times.



Figure 3: What's included in the box.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the Nano Facial Mister. A full charge can provide approximately 50 uses.

1. Locate the USB charging port on the device.
2. Connect the provided USB charging cable to the device and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The indicator light will illuminate during charging and turn off when fully charged.

4.2 Filling the Water Tank

The device features a 20ml water tank. For optimal performance and to prevent clogging, it is recommended to use mineral water. Avoid using tap water, purified water, or oily liquids.

1. Gently twist and pull the top cap of the mister to open the water tank.
2. Carefully fill the water tank with mineral water. Do not overfill.
3. Securely close the top cap by twisting it back into place until it clicks. Ensure it is tightly sealed to prevent leaks.



Figure 4: Steps for filling the water tank.

5. OPERATING INSTRUCTIONS

Using your Nano Facial Mister is simple and straightforward:

1. Hold the mister upright.
2. Slide down the front cover to activate the mist function. The blue indicator light will turn on, and a fine mist will begin to spray from the nozzle.
3. Hold the device approximately 5-10 inches (12-25 cm) away from your face or desired area.
4. Move the mister slowly in a circular motion to ensure even coverage.
5. To stop the mist, simply slide the front cover back up. The blue light will turn off.

The device automatically sends out a nice mist, perfect for a quick hydration boost. The nano ultrasonic technology splits water molecules into tiny nanometer particles for deep penetration and absorption into the skin.

Nano ultrasonic technology splits water molecules or the mixture of skincare lotion and water into tiny nanometer particles to make the effective component penetrate into the depth of skin by atomization processing



Figure 5: How nano technology works for skin hydration.



Figure 6: Proper distance for mist application.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your Nano Facial Mister:

- **Cleaning the Water Tank:** After each use, empty any remaining water from the tank. Periodically, clean the inside of the water tank with a soft, damp cloth to prevent mineral buildup.
- **Cleaning the Nozzle:** If you notice reduced mist output, gently wipe the misting nozzle with a cotton swab dampened with clean water. Do not use sharp objects to clean the nozzle.
- **External Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Do not immerse the device in water.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the water tank is empty before storing for extended periods.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist or weak mist	Low water level; Clogged nozzle; Low battery; Improper water type.	Refill water tank; Clean the nozzle; Charge the device; Use mineral water.
Device not turning on	Low battery; Front cover not fully slid down.	Charge the device; Ensure the front cover is fully slid down to activate.
Leaking from the device	Water tank not properly sealed; Overfilled water tank.	Ensure the top cap is securely twisted and sealed; Do not overfill the water tank.

8. SPECIFICATIONS

- **Model Name:** Nano Facial Mister
- **Item Model Number:** PWY-WHITE
- **Brand:** MINI LOP
- **Color:** White
- **Material:** Plastic
- **Product Dimensions (L x W x H):** 1.3 x 1.3 x 4 inches
- **Weight:** 2.47 ounces
- **Water Tank Capacity:** 20ml
- **Battery:** 1 Lithium Ion battery (included)
- **UPC:** 614024836745
- **Manufacturer:** Turui

9. WARRANTY AND SUPPORT

For any product-related inquiries, technical support, or warranty claims, please contact MINI LOP customer service through the retailer where you purchased the product. Please have your purchase receipt and product model number ready when contacting support.

For more information, visit the official MINI LOP brand page or contact your local distributor.

