

KLARSTEIN HZD2-Dr.Watson-XXLBR

Klarstein Dr. Watson XXL Electric Heated Blanket Instruction Manual

Brand: KLARSTEIN | Model: HZD2-Dr.Watson-XXLBR

1. INTRODUCTION

Thank you for choosing the Klarstein Dr. Watson XXL Electric Heated Blanket. This manual provides essential information for the safe and efficient use, maintenance, and care of your new heated blanket. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Klarstein Dr. Watson XXL Electric Heated Blanket, folded, with its detachable controller. The image highlights the soft texture and the integrated control unit.

2. SAFETY INSTRUCTIONS

WARNING: Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- The product is equipped with overheating protection and an automatic shut-off feature after 3 hours.
- Do not use for prolonged periods without interruption.
- Do not use by children or pregnant women without consulting a doctor.
- Ensure the blanket is spread flat and not folded or bunched up during operation to prevent overheating.
- Do not insert pins or other sharp objects into the blanket.
- Do not use if wet.
- Always disconnect the power cord from the outlet before cleaning or if not in use.
- Regularly inspect the blanket and power cord for any signs of damage. If damaged, do not use and contact customer support.

3. SETUP

3.1 Unpacking

- Carefully remove the heated blanket and its controller from the packaging.
- Check for any visible damage. If any damage is found, do not use the product and contact customer support.

3.2 Placement

The Klarstein Dr. Watson XXL Electric Heated Blanket is designed for use on beds or sofas. Ensure the blanket is spread out smoothly and evenly over the desired surface. Avoid folding or creasing the blanket while it is in use.

DIMENSIONI DALLA MASSIMA COMODITÀ: PERFETTA PER LE COCCOLE IN DUE





Ampio formato:
200 x 180 cm



Lunghezza del cavo
da 2,35 m



piacevole micro
peluche



Calore uniforme grazie allo strato
riscaldante interno

Image: A couple comfortably covered by the large 200 x 180 cm heated blanket, illustrating its generous size and soft micro plush material. The image also highlights uniform heat distribution.

4. OPERATING INSTRUCTIONS

4.1 Connecting the Controller

1. Ensure the blanket is properly laid out.
2. Connect the controller cable securely to the blanket's connector.
3. Plug the power cord into a suitable 220-240V electrical outlet.

4.2 Power On and Temperature Adjustment

The blanket features an LCD controller with a slider for temperature selection and an auto-off timer.



Image: A detailed view of the Klarstein heated blanket's controller, showing the LCD display, the slider for selecting temperature levels (0-3), and the 'Auto-Off' indicator. Temperature levels are indicated as Level 1: 35°C, Level 2: 40°C, Level 3: 45°C.

1. To turn on the blanket, slide the temperature selector to your desired heat level (1, 2, or 3). The LCD display will show the selected level.
2. **Level 1:** Approximately 35°C (Gentle warmth)
3. **Level 2:** Approximately 40°C (Medium warmth)
4. **Level 3:** Approximately 45°C (Maximum warmth)
5. The blanket will begin to heat up. It may take a few minutes to reach the desired temperature.

4.3 Automatic Shut-off Timer

For safety and energy saving, the blanket is equipped with an automatic shut-off timer that activates after 3 hours of continuous operation. After 3 hours, the blanket will gently turn off. To restart, simply slide the

temperature selector to '0' and then back to your desired heat level.

5. MAINTENANCE AND CLEANING

The Klarstein Dr. Watson XXL Electric Heated Blanket is designed for easy cleaning.



Image: The Klarstein heated blanket is shown folded next to a washing machine, emphasizing its machine-washable feature for hygiene and convenience. The image also shows the easily detachable electrical plug.

1. **Disconnect Power:** Always unplug the power cord from the wall outlet and then detach the controller from the blanket before cleaning.
2. **Machine Wash:** The blanket is machine washable. Use a gentle cycle at 30°C (86°F) with a mild detergent. A wool program is recommended.
3. **Drying:** Do not tumble dry. Air dry the blanket completely before reattaching the controller and using it again. Ensure all components are thoroughly dry.
4. **Storage:** When not in use, store the blanket in a cool, dry place, preferably in its original packaging or a breathable bag. Avoid placing heavy objects on top of the folded blanket.

6. TROUBLESHOOTING

If you experience any issues with your Klarstein Dr. Watson XXL Electric Heated Blanket, please check the following before contacting customer support:

- **Blanket not heating:** Ensure the power cord is securely plugged into a working outlet and the controller is firmly connected to the blanket. Check if the temperature setting is above '0'.
- **Controller display not working:** Verify the power connection. If the issue persists, the controller may be faulty.
- **Overheating:** The blanket has an automatic shut-off feature for overheating. If it turns off

unexpectedly, unplug it, let it cool down, and check if it was folded or bunched up. Spread it flat before restarting.

- **Unusual odors:** A new product may have a slight odor initially. This should dissipate with use. If a strong or burning odor occurs, immediately unplug the blanket and discontinue use.

For problems not resolved by the above steps, please contact Klarstein customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	KLARSTEIN
Model Number	HZD2-Dr.Watson-XXLBR
Dimensions (LxWxH)	200 x 180 x 2 cm
Weight	2.3 kg
Material	Micro Plush (Pile)
Power	120 W
Voltage	220 - 240 V
Temperature Settings	3 levels (approx. 35°C, 40°C, 45°C)
Automatic Shut-off	After 3 hours
Cable Length	2 m
Washable	Machine washable (30°C, wool program)

8. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Klarstein website. Please have your model number (HZD2-Dr.Watson-XXLBR) and purchase details ready when contacting support.