

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Prorelax](#) /

› Prorelax Manicure/Pedicure Set Deluxe Model 52248 Instruction Manual

Prorelax 52248

Prorelax Manicure/Pedicure Set Deluxe Instruction Manual

Model: 52248

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using the device. Retain this manual for future reference.

- Always wear eye protection when using the nail drill to prevent injury from flying debris.
- Exercise caution when handling the rotating bits to avoid accidental injury to skin or nails.
- Keep the device clean and dry when not in use to prevent electrical hazards and ensure proper function.
- Do not use the device on inflamed, injured, or infected skin. Consult a medical professional if you have any concerns.
- Keep out of reach of children. This device is not a toy.
- Ensure the power adapter is compatible with your local power supply before connecting.

2. PRODUCT OVERVIEW

The Prorelax Manicure/Pedicure Set Deluxe is designed for comprehensive hand and foot care at home. It features a powerful motor, adjustable speed, and a variety of high-quality attachments for various applications.



Figure 2.1: The complete Prorelax Manicure/Pedicure Set Deluxe, featuring the ergonomic main unit and a comprehensive collection of 15 high-quality attachments, all neatly organized within a durable aluminum carrying case.

2.1 Components

- Main Manicure/Pedicure Device with integrated LED light
- 15 High-Quality Attachments (Surgical Steel, Sapphire-coated, Felt)
- Power Adapter
- Dust Protection Cap
- Aluminum Storage Case

prorelax[®]



Maniküre- und
Pediküre-Set
DELUXE

BeautyCare

Figure 2.2: A detailed view of the 15 specialized attachments included in the set, made from surgical steel with sapphire coating and felt, designed for various nail and skin care applications.

3. SETUP

1. **Unpack the Device:** Carefully remove all components from the aluminum storage case. Inspect for any damage.
2. **Connect Power:** Insert the power adapter cable into the designated port on the main device. Plug the adapter into a suitable electrical outlet.
3. **Select and Attach Bit:** Choose the appropriate attachment for your desired application. Gently insert the attachment into the opening at the tip of the device until it clicks securely into place. Ensure the bit is fully seated before operation.
4. **Attach Dust Protection Cap (Optional):** For applications that generate significant dust, slide the transparent dust protection cap over the tip of the device.

4. OPERATING INSTRUCTIONS

The Prorelax Manicure/Pedicure Set offers precise control for effective and comfortable use.

prorelax[®]



Figure 4.1: The ergonomic Prorelax device shown in use, illustrating the integrated LED work light for enhanced visibility and the intuitive speed control buttons.

1. **Power On/Off:** Press the power button (often indicated by a circle with a vertical line) to turn the device on. Press again to turn it off. The integrated LED light will illuminate when the device is on.
2. **Adjust Speed:** Use the '+' and '-' buttons to adjust the rotation speed. The device offers a continuously adjustable speed range from 2000 to 5400 revolutions per minute (rpm). Start with a lower speed and gradually increase as needed.
3. **Change Rotation Direction:** The device supports both clockwise and anti-clockwise rotation. A dedicated button (often indicated by arrows) allows you to switch the direction, which can be useful for different applications and hand positions.
4. **Using Attachments:**
 - **Shaping and Filing:** Use sapphire-coated bits for precise shaping and filing of nails.
 - **Buffing and Polishing:** Felt attachments are ideal for buffing nails to a high shine.
 - **Callus and Corn Removal:** Coarser sapphire bits are effective for gently removing hardened skin, calluses, and corns. Apply light pressure and move the device continuously to avoid excessive friction in one spot.
 - **Cuticle Care:** Use fine-grained bits for careful work around the cuticles.
5. **LED Work Light:** The integrated LED light provides enhanced visibility of the treatment area, ensuring precision and safety.
6. **Dust Protection:** When using the dust protection cap, it will help collect nail dust and skin particles, keeping your workspace cleaner.

Note for Diabetics: This device is also recommended for diabetics. However, individuals with diabetes should use the device with extreme caution and consult their doctor or a podiatrist before use, especially when treating calluses or corns, to prevent injury.



Figure 4.2: The main unit with the transparent dust protection cap in place, designed to collect excess skin and nail dust during operation.

5. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and hygienic use of your Prorelax Manicure/Pedicure Set.

1. **Cleaning the Device:** Disconnect the device from the power supply before cleaning. Wipe the main unit with a soft, slightly damp cloth. Do not use abrasive cleaners or immerse the device in water.
2. **Cleaning Attachments:** After each use, remove the attachment from the device. Clean the attachments with a brush to remove any debris. The surgical steel attachments can be sterilized to prevent the reproduction of fungi and viruses. Follow standard sterilization procedures for medical instruments.
3. **Storage:** Store the device and all attachments in the provided aluminum case when not in use. This protects the components from dust and damage and keeps them organized. Store in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your Prorelax Manicure/Pedicure Set, refer to the following common solutions:

- **Device does not turn on:**
 - Ensure the power adapter is securely plugged into both the device and the electrical outlet.
 - Check if the electrical outlet is functioning correctly by testing it with another appliance.

- **Attachment is loose or falls out:**
 - Ensure the attachment is fully inserted into the device until it clicks into place.
 - Inspect the attachment and the device's receiving port for any damage or debris that might prevent a secure fit.

- **Reduced performance or unusual noise:**
 - Clean the attachment and the device thoroughly to remove any accumulated dust or debris.
 - Ensure you are not applying excessive pressure, which can strain the motor.

If the problem persists after attempting these solutions, please contact Prorelax customer support.

7. SPECIFICATIONS

Brand	Prorelax
Model Name	52248
Item Model Number	52248
Manufacturer	Prorelax
Material	Plastic, Stainless Steel
Power Source	Corded Electric
Voltage	230 Volts (2.3E+2 Volts)
Speed Range	2000 - 5400 rpm (continuously adjustable)
Attachments	15 high-quality, sapphire-coated and felt attachments
UPC	653341352248, 065334135224
ASIN	B075SWXN1J
Package Dimensions	10.55 x 7.13 x 3.35 inches; 2.25 Pounds

8. WARRANTY AND SUPPORT

The Prorelax Manicure/Pedicure Set Deluxe comes with a **2-Year Guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Prorelax customer service. Refer to the product packaging or the official Prorelax website for contact information.