

Urmet 1705/954

Urmet 1705/954 Bibus P/Monitor Artico User Manual

Model: 1705/954

1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Urmet 1705/954 Bibus P/Monitor Artico. Please read these instructions carefully before use to ensure proper functionality and safety.

2. SETUP AND INSTALLATION

The Urmet 1705/954 Bibus P/Monitor Artico is designed for easy integration into a Bibus video bus system.

2.1. Wiring Connections

- **Lock Button Input:** Connect the lock button to the designated input terminal.
- **Additional Bell Output:** An output on 2 wires is available for connecting an additional bell.
- **Second Monitor Connection:** A terminal strip is provided for connecting a second monitor without requiring an additional power supply.
- **Plug Connection:** The monitor features a plug connection for wiring, designed to avoid direct contact with the wiring during installation.

2.2. Power Supply

The monitor receives its power supply directly via the Bibus video bus, simplifying installation.

2.3. Mounting

The monitor features a white ABS plate with 4 elongated mounting holes, allowing for vertical adjustment during installation. The turntable is fully covered by the monitor, ensuring a slim profile.

2.4. Department Code Storage

The department code is stored automatically during the initial installation process.

3. OPERATING INSTRUCTIONS

The Urmet 1705/954 Bibus P/Monitor Artico offers several user-friendly functions.

3.1. Melody Selection

The monitor offers two distinct melodies out of six available options. These melodies can be selected and changed by the user to differentiate between calls (e.g., door, warehouse).

3.2. Auxiliary Functions

- **Call from Center:** Initiate a call from the central unit using the monitor's first auxiliary button.
- **Additional Remote Control:** Utilize the monitor's second button for additional remote control functions.

4. MAINTENANCE

The Urmet 1705/954 Bibus P/Monitor Artico requires minimal maintenance.

- **Cleaning:** Use a soft, dry cloth to clean the monitor's surface. Avoid abrasive cleaners or solvents.
- **Operating Conditions:** Ensure the monitor operates within the specified temperature range of 5 °C to +45 °C.

5. TROUBLESHOOTING

If you encounter issues with your Urmet 1705/954 Bibus P/Monitor Artico, please refer to the following common solutions:

- **No Power:** Verify that the Bibus video bus is supplying power correctly. Check all connections.
- **No Sound/Intermittent Sound:** Check the wiring for the additional bell and ensure all connections are secure.
- **Buttons Unresponsive:** Ensure the monitor is properly connected and receiving power. If the issue persists, consult a qualified technician.

6. SPECIFICATIONS

Feature	Detail
Brand	Urmet
Model Number	1705/954
Product Dimensions (H x W x D)	213 x 190 x 28 mm (8.39 x 7.48 x 1.10 inches)
Power Supply	Via Bibus video bus
Operating Temperature	5 °C to +45 °C (41 °F to 113 °F)
Material	White ABS plate
Melody Options	2 selectable from 6 available
Additional Connections	Input for lock button, output for additional bell, terminal strip for second monitor

7. WARRANTY AND SUPPORT

Warranty information and specific support details for the Urmet 1705/954 Bibus P/Monitor Artico are not provided in this manual. Please refer to the product packaging or contact Urmet customer service for further assistance.