

## Oxygenics 57288

# Oxygenics Marvel Chrome Rain Shower Head Instruction Manual

Model: 57288

## PRODUCT OVERVIEW

---

The Oxygenics Marvel Chrome Rain Shower Head (Model 57288) is designed to enhance your showering experience with its innovative features and robust construction. This fixed shower head offers 9 unique spray settings, including a distinctive Waterfall setting, and features a substantial 8-inch face for broad coverage. It is engineered to intensify water pressure, providing an efficient and satisfying flow.



Figure 1: Front view of the Oxygenics Marvel Chrome Rain Shower Head, showcasing its square design and multiple nozzles.

Key Features:

- **9 Unique Spray Settings:** Includes an innovative Waterfall setting for varied showering experiences.
- **Extended Reach:** Extends 7.5 inches from the shower arm, providing added versatility.
- **Pressure Boosting:** Multi-Oxygenics engine technology intensifies water pressure for enhanced efficiency.
- **Increased Height:** Increases shower height by 3 inches, accommodating various user heights.
- **Wide Coverage:** Substantial 8-inch face delivers extreme spray coverage.
- **Durable Construction:** Made from Acrylonitrile Butadiene Styrene with a polished chrome finish.

SPECIFICATIONS

Brand	Oxygenics
Model Number	57288

Style	Modern
Shape	Square
Material	Acrylonitrile Butadiene Styrene
Finish Type	Polished Chrome
Installation Type	Wall Mounted
Flow Rate	1.8 GPM (6.8 L/min) Maximum; 1.35 GPM (5.11 L/min) Minimum at 45 PSI
Color	Chrome
Product Dimensions	8.26"L x 8.02"W
Number of Settings	9
Item Weight	2 pounds
Included Components	Plumber's Tape, Rain Shower Head
UPC	010147572889

## SETUP AND INSTALLATION

---

This section provides general instructions for installing your Oxygenics Marvel Chrome Rain Shower Head. For specific plumbing configurations, consult a professional plumber.

### Tools and Materials Required (Not Included):

- Adjustable Wrench or Pliers
- Rag or Cloth (to protect finish)
- Thread Seal Tape (Plumber's Tape is included)

### Installation Steps:

1. **Prepare the Shower Arm:** Ensure the existing shower arm is clean and free of any old thread seal tape or debris. If replacing an old shower head, unscrew it counter-clockwise and remove it.
2. **Apply Thread Seal Tape:** Wrap the threads of the shower arm with the included plumber's tape. Wrap 3-4 times clockwise around the threads, ensuring a tight seal.
3. **Attach the Shower Head:** Carefully screw the Oxygenics Marvel Shower Head onto the taped threads of the shower arm. Turn clockwise by hand until it is finger-tight.
4. **Tighten with Wrench:** Using an adjustable wrench or pliers, gently tighten the shower head an additional quarter to half turn. Use a rag or cloth to protect the chrome finish from scratches. *Do not overtighten*, as this can damage the shower head or plumbing.
5. **Check for Leaks:** Turn on the water supply and check for any leaks around the connection point. If leaks occur, tighten slightly more or reapply thread seal tape.



Figure 2: The Oxygenics Marvel Shower Head properly installed on a standard shower arm, ready for use.

## OPERATING INSTRUCTIONS

---

The Oxygenics Marvel Shower Head features 9 distinct spray settings, allowing you to customize your showering experience. The settings are easily adjustable.

### Changing Spray Settings:

To change the spray pattern, locate the selector lever or dial on the perimeter of the shower head. Gently rotate this mechanism to cycle through the available settings. Each click or distinct position corresponds to a different spray pattern, including the unique Waterfall setting.



Figure 3: The shower head operating with a typical spray pattern, demonstrating water flow from multiple nozzles.





Figure 4: The shower head demonstrating its unique Waterfall spray setting, providing a broad, gentle cascade of water.



Figure 5: The shower head displaying a more concentrated spray pattern, ideal for targeted rinsing.

### Flow Rate Information:

The shower head operates at a maximum flow rate of 1.8 Gallons Per Minute (GPM) or 6.8 Liters Per Minute (LPM). At 45 PSI, the minimum flow rate is 1.35 GPM (5.11 LPM). This design ensures efficient water usage while maintaining powerful pressure.

### MAINTENANCE

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Oxygenics Marvel Shower Head.

#### Cleaning the Shower Head:

- **Regular Cleaning:** To maintain the polished chrome finish, wipe the shower head with a soft cloth and mild soap and water solution. Rinse thoroughly with clean water and dry immediately to prevent water spots.

- **Mineral Deposit Removal:** If mineral deposits (limescale) build up on the nozzles, gently rub them with your finger or a soft brush. For stubborn deposits, soak the shower head in a solution of equal parts white vinegar and water for 30 minutes to an hour. Rinse thoroughly after soaking.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or chemical solvents, as these can damage the chrome finish and the Acrylonitrile Butadiene Styrene material.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your shower head.

Problem	Possible Cause	Solution
Low Water Pressure	Mineral buildup in nozzles. Partially closed water valve. Water restrictor partially blocked (if applicable).	Clean nozzles as described in the Maintenance section. Ensure main water supply valve is fully open. Check for any debris in the shower arm or shower head inlet.
Leaking from Connection	Insufficient thread seal tape. Loose connection.	Remove shower head, reapply thread seal tape (3-4 wraps), and reattach. Gently tighten the connection with a wrench (do not overtighten).
Uneven Spray Pattern	Clogged nozzles due to mineral buildup.	Clean the nozzles to remove any obstructions.

## WARRANTY AND SUPPORT

For warranty information or technical support regarding your Oxygenics Marvel Chrome Rain Shower Head, please contact Oxygenics directly.

While specific warranty details are not provided in this manual, most Oxygenics products come with a manufacturer's warranty covering defects in materials and workmanship. Please retain your proof of purchase for warranty claims.

**Manufacturer:** Oxygenics

For the most current support contact information, please visit the official Oxygenics website or refer to the packaging that came with your product.

© 2023 Oxygenics. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

### Related Documents - 57288



 <p>The image shows the cover of the 'PowerSelect' shower head installation guide. It features a blue header with the Oxygenics logo and the product name. Below, it lists 'EASY INSTALLATION INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information. A 'EASY TWIST SPRAY SELECTION' diagram is also present.</p>	<p><a href="#">Oxygenics PowerSelect Shower Head Easy Installation Guide</a></p> <p>Step-by-step instructions for installing the Oxygenics PowerSelect shower head, including features, included parts, and customer support contact information.</p>
 <p>The image shows the cover of the 'Fury RV' shower head installation guide. It features a blue header with the Oxygenics logo and the product name. Below, it lists 'EASY INSTALLATION INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information. An 'ATTENTION!' note is also present.</p>	<p><a href="#">Oxygenics Fury RV Shower Head: Easy Installation Guide</a></p> <p>A comprehensive, step-by-step guide for installing the Oxygenics Fury RV shower head. Learn about spray selection, flow control, and access customer support.</p>
 <p>The image shows the cover of the 'VitalSpray' shower head installation guide. It features a blue header with the Oxygenics logo and the product name. Below, it lists 'EASY INSTALLATION INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information. A 'FILLING THE VITALSPRAY HEAD AND BODY WASH RESERVOIR' diagram is also present.</p>	<p><a href="#">Oxygenics VitalSpray Shower Head Installation Guide</a></p> <p>Detailed installation instructions for the Oxygenics VitalSpray handheld shower head, including steps for setup, reservoir filling, and customer support contact information. Learn how to easily install your new shower system.</p>
 <p>The image shows the cover of the 'Silk Cartridge Removal and Installation Instructions' guide. It features a black header with the Oxygenics logo and the product name. Below, it lists 'SILK CARTRIDGE REMOVAL INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information.</p>	<p><a href="#">Oxygenics Silk Cartridge Removal and Installation Instructions</a></p> <p>Step-by-step guide from Oxygenics on how to remove and install the Silk Cartridge for your Pure Shower Genius shower system.</p>
 <p>The image shows the cover of the 'PowerMax' handheld shower installation guide. It features a blue header with the Oxygenics logo and the product name. Below, it lists 'EASY INSTALLATION INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information. A 'EASY TWIST SPRAY SELECTION' diagram is also present.</p>	<p><a href="#">Oxygenics PowerMax Handheld Shower Installation Guide</a></p> <p>Step-by-step installation instructions for the Oxygenics PowerMax handheld showerhead, including comfort control and spray selection features. Contact information for support is provided.</p>
 <p>The image shows the cover of the 'Rogue' shower head installation and features guide. It features a blue header with the Oxygenics logo and the product name. Below, it lists 'EASY INSTALLATION INSTRUCTIONS' with four numbered steps (1-4) and a 'STOP! NEED HELP?' section with contact information. An 'ATTENTION!' note is also present.</p>	<p><a href="#">Oxygenics Rogue Shower Head Installation and Features Guide</a></p> <p>Comprehensive guide for installing the Oxygenics Rogue shower head, detailing easy twist spray selection, diverter operation, and customer support contact information.</p>