

## Walfront JDS2900

# JDS2900 Series DDS Function/Arbitrary Waveform Generator User Manual

Model: JDS2900 | Brand: Walfront

## 1. INTRODUCTION AND OVERVIEW

---

The Walfront JDS2900 series is a versatile and high-precision dual-channel DDS (Direct Digital Synthesis) function and arbitrary waveform generator. It integrates multiple functions including function signal generator, arbitrary waveform generator, pulse signal generator, noise generator, and counter. Utilizing advanced large-scale integrated circuits and SMT technology, it offers high reliability and excellent performance for a wide range of applications in scientific research, education, and engineering.

Key features include a 2.4-inch TFT color LCD display for intuitive operation, a high sampling rate of 266MSa/s, and a 14-bit vertical resolution for exquisite waveform generation. It supports various waveform types such as Sine, Square, Triangle, Pulse, Partial Sine, CMOS, DC level, Half-wave, Full-Wave, and user-defined waveforms. The device also provides precise control over parameters like frequency, amplitude, offset, and phase difference.



Figure 1.1: JDS2900 DDS Function Generator and its accessories, including power adapter, USB cable, and BNC cables.

## Portable Dual Channel DDS Function Arbitrary Waveform Generators




Figure 1.2: Overview of JDS2900 key features and capabilities.

## 2. SETUP

This section details the initial setup of your JDS2900 DDS Function Generator, including power connection and basic wiring.

### 2.1 Power Connection

Connect the provided AC adapter to the DC5V power input port on the rear panel of the device. Ensure the power switch is in the OFF position before connecting. Once connected, you can switch the device ON.

# Signal Generator Wiring Instructions




Figure 2.1: Rear panel connections, including power input and USB port.

Note: The product may ship with either a new or old type of power adapter. Both are compatible and function identically.




Figure 2.2: New and old power adapter types.

## 2.2 Signal Output and Measurement Connections

The JDS2900 features two independent signal output channels (CH1 and CH2) and dedicated inputs for analog and digital signal measurement.

- **Channel 1 Signal Output:** Connect your BNC cable to the CH1 output port for the primary waveform output.
- **Channel 2 Signal Output:** Connect your BNC cable to the CH2 output port for the secondary waveform output.
- **Analog Signal Measurement Input:** Use this port for measuring analog signals.
- **Digital Signal Measurement Input:** Use this port for measuring digital signals.
- **USB Communication:** Connect the device to a computer via the USB port for software control and arbitrary waveform generation.




Figure 2.3: Signal output and measurement ports on the rear panel.

### 3. OPERATING INSTRUCTIONS

---

This section provides guidance on operating the JDS2900, including navigating the interface and generating various waveforms.

#### 3.1 Front Panel Overview

The JDS2900 features a user-friendly front panel with a 2.4-inch high-definition LCD screen, an adjusting knob, function menu buttons, and shortcut buttons for quick access to common settings.

# Signal Generator Panel Parameters




Figure 3.1: Labeled front panel of the JDS2900.

## 3.2 Waveform Generation

The JDS2900 can generate a wide variety of waveforms. Use the 'WAVE' button to cycle through available waveform types and the adjusting knob to modify parameters such as frequency, amplitude, and offset.

- **Sine Wave:** Smooth, continuous oscillation.
- **Square Wave:** Alternating between two fixed levels.
- **Triangle Wave:** Linear rise and fall.
- **Pulse Wave:** Adjustable duty cycle, pulse width, and cycle time.
- **Partial Sine Wave:** A portion of a sine wave.
- **CMOS Wave:** Digital logic level compatible waveform.
- **DC Level:** Constant voltage output (bias adjustable).
- **Half Wave / Full Wave:** Rectified sine waves.
- **Step Wave:** Positive and negative step functions.
- **Noise Wave:** Random signal.
- **Index Up / Index Down:** Exponential rise and fall.
- **Sonic Wave, Sinc Pulse, Lorentz Pulse:** Specialized waveforms.
- **User-Defined Waveforms:** Up to 60 custom waveforms can be stored and generated.

## NEW AND OLD MODELS ARE SHIPPED RANDOMLY



Figure 3.2: Examples of various waveform types.

### 3.3 Advanced Functions

The JDS2900 supports advanced functions such as frequency sweep, burst mode, and modulation. Refer to the on-screen menu options and the detailed software manual for comprehensive instructions on these features. The device can be controlled via PC software for more complex operations and arbitrary waveform drawing.

## 4. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your JDS2900 DDS Function Generator.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Avoid using abrasive cleaners or solvents that could damage the casing or screen.
- **Storage:** Store the device in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Handling:** Handle the device with care to prevent physical damage. Avoid dropping or subjecting it to strong impacts.
- **Ventilation:** Ensure the ventilation slots on the device are not obstructed to prevent overheating.

## 5. TROUBLESHOOTING

---

This section provides solutions to common issues you might encounter with your JDS2900.

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty; power switch is OFF.	Ensure power adapter is securely connected. Check if the power switch is in the ON position. Test with another compatible power adapter if available.
No signal output.	Output channel disabled; incorrect waveform parameters; faulty cable.	Verify that the desired output channel (CH1/CH2) is enabled on the display. Check frequency, amplitude, and offset settings. Ensure BNC cables are properly connected and not damaged.
Display is blank or frozen.	Software glitch; temporary error.	Turn off the device, wait a few seconds, then turn it back on. If the issue persists, contact customer support.

For issues not listed here, or if the suggested solutions do not resolve the problem, please refer to the official Walfront support resources.

## 6. SPECIFICATIONS

---

Detailed technical specifications for the JDS2900 DDS Function Generator.

Parameter	Value
Display	2.4 inch TFT color LCD display
Waveform Types	Sine, Square, Pulse, Triangle, Partial Sine, CMOS, DC Level, Half Wave, Full Wave, Step Wave, Noise, Index Up/Down, Sonic, Sinc Pulse, Lorentz Pulse, 60 user-defined
Waveform Sampling Rate	266MSa/s
Waveform Vertical Resolution	14 bit
Frequency Minimum Resolution	0.01 $\mu$ Hz (0.00000001Hz)
Frequency Accuracy	$\pm$ 20ppm
Frequency Stability	$\pm$ 1ppm/3hours

Parameter	Value
Sine Wave Frequency Range	0.01μHz - 60MHz (model dependent)
Square Wave Frequency Range	0.01μHz - 15MHz
Pulse Width Adjusting Range	25nS - 4000S
Bias Adjustment Range	-9.99V to +9.99V
Harmonic Suppression	≥45dBc (<1MHz); ≥40dBc (1MHz~20MHz)
Total Harmonic Distortion	<0.8% (20Hz~20kHz, 0dBm)
Storage Quantity	100 groups
Product Dimensions	3.94 x 1.57 x 3.94 inches
Weight	1.76 Pounds (approx. 933g)

# Signal Generator

Vertical resolution of waveform is optimized to 14bit, 266MSa/s sampling rate more exquisite waveform.



Figure 6.1: Detailed technical specifications table.

## 7. WARRANTY AND SUPPORT

Walfront products are designed for reliability and performance. For warranty information and technical support, please refer to the official Walfront website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For additional support, you may visit the Walfront Store on Amazon: [Walfront Store](#)