

[Manuals.plus](#) /

› [NEDIS](#) /

› NEDIS Car Tablet Holder TCMT300BK Instruction Manual

NEDIS TCMT300BK

NEDIS Car Tablet Holder TCMT300BK Instruction Manual

Model: TCMT300BK

1. SAFETY INFORMATION

Please read these safety instructions carefully before using the product to ensure safe operation and to prevent damage. Keep this manual for future reference.

- Do not obstruct your view of the road or vehicle controls when installing the tablet holder.
- Ensure the holder is securely fastened before placing a tablet in it and before driving.
- Avoid installing the holder in locations where it could interfere with airbag deployment.
- Do not adjust the holder or tablet while driving. Always pull over to a safe location before making any adjustments.
- Keep the product away from extreme temperatures and direct sunlight for prolonged periods to prevent material degradation.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- Adjustable Tablet Holder
- Suction Cup Mount
- Headrest Mount



Image: All components of the NEDIS Car Tablet Holder, including the adjustable tablet grip, the suction cup base, and the headrest attachment.

3. SETUP INSTRUCTIONS

3.1. Window Mount Installation

1. **Attach the Tablet Holder to the Suction Cup Mount:** Align the ball joint of the suction cup mount with the socket on the back of the adjustable tablet holder. Push them together until they click into place. Tighten the locking ring to secure the connection.
2. **Clean the Mounting Surface:** Choose a clean, smooth, and flat area on your windshield. Ensure the surface is free of dust, dirt, and grease.
3. **Position the Suction Cup:** Press the suction cup firmly against the chosen surface.
4. **Engage the Suction Lock:** Flip the lever on the suction cup base downwards to create a strong vacuum seal. Ensure the mount is securely attached and does not wobble.
5. **Adjust the Angle:** Loosen the adjustment knob on the suction cup arm to set the desired viewing angle. Tighten the knob firmly once the angle is set.



Image: The adjustable tablet holder connected to the suction cup mounting arm, ready for installation.



Image: Detailed view of the suction cup base, showing the lever to engage the vacuum seal and the 'PRESS' button for release.



Image: A tablet securely held in the NEDIS holder, mounted on the car's windshield, providing a clear view for the passenger.

3.2. Headrest Mount Installation

1. **Attach the Tablet Holder to the Headrest Mount:** Similar to the suction cup mount, align the ball joint of the headrest mount with the socket on the back of the adjustable tablet holder. Push them together and tighten the locking ring.
2. **Position the Headrest Mount:** Open the clamps of the headrest mount and position them around one of the metal posts of the car's headrest.
3. **Secure the Mount:** Tighten the screw system on the headrest mount until it is firmly secured to the headrest post. Ensure it does not slide or rotate freely.
4. **Adjust the Angle:** Loosen the adjustment knob on the headrest mount arm to set the desired viewing angle for the rear passenger. Tighten the knob firmly once the angle is set.



Image: The adjustable tablet holder connected to the headrest mounting arm, designed for rear-seat entertainment.



Image: A tablet mounted on the back of a car headrest using the NEDIS holder, providing entertainment for rear passengers.

4. OPERATING INSTRUCTIONS

4.1. Inserting a Tablet

1. Gently pull apart the adjustable arms of the tablet holder.
2. Carefully place your tablet into the holder, ensuring it is centered and the arms securely grip the device without obstructing buttons or ports. The holder is compatible with tablets up to 12 inches.
3. Release the arms slowly to allow them to clamp onto the tablet. Verify that the tablet is held firmly.



Image: Side view of a tablet securely held within the adjustable arms of the NEDIS holder, demonstrating its grip.



Image: Front view of a tablet in the NEDIS holder, showcasing the secure fit and unobstructed screen.

4.2. Adjusting and Rotating the Tablet

- **Angle Adjustment:** Loosen the adjustment knob on the mounting arm to tilt the tablet to your preferred viewing angle. Tighten the knob to lock it in place.
- **360° Rotation:** The tablet holder allows for full 360-degree rotation. Simply rotate the tablet to switch between portrait and landscape orientation as needed. No knob adjustment is required for rotation.

5. MAINTENANCE

- **Cleaning:** Wipe the holder with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the plastic.
- **Suction Cup Care:** If the suction cup loses its grip, clean it with warm, soapy water and let it air dry. This can restore its adhesive properties.
- **Storage:** When not in use for extended periods, detach the holder from the car and store it in a cool, dry place.

6. TROUBLESHOOTING

- **Holder not staying attached to windshield:**
 - Ensure the windshield surface is clean and dry.
 - Press the suction cup firmly against the surface before engaging the lever.
 - Check if the suction cup lever is fully engaged.
 - Clean the suction cup with water to remove any dust or debris.
- **Tablet not fitting securely:**
 - Verify your tablet's screen size is within the 12-inch maximum limit.
 - Ensure the tablet is centered between the adjustable arms.
 - Check for any obstructions preventing the arms from closing fully.
- **Holder wobbles or moves:**
 - Tighten all adjustment knobs and locking rings firmly.
 - For headrest mount, ensure the screw system is fully tightened around the headrest post.

7. SPECIFICATIONS

Brand	NEDIS
Model Name	TCMT300BK
Compatible Devices	Tablets (up to 12 inches screen diameter)
Mounting Type	Window (Suction Cup), Headrest
Material	Plastic
Special Features	Adjustable, Rotatable (360°)
Colour	Black
Item Weight	1 Grams
Item Dimensions (L x W x H)	1 x 1 x 1 millimetres

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official NEDIS website or contact your local retailer. Keep your proof of purchase for any warranty claims.