

[Manuals.plus](#) /

› [WSSROGY](#) /

› WSSROGY Round Toilet Seat Instruction Manual

WSSROGY Round

WSSROGY Round Toilet Seat Instruction Manual

Model: Round

Brand: WSSROGY

1. INTRODUCTION

Thank you for choosing the WSSROGY Round Toilet Seat. This manual provides detailed instructions for the proper installation, operation, maintenance, and troubleshooting of your new toilet seat. Designed for comfort and durability, this slow-close toilet seat features high-quality PP material and an ergonomic design for an enhanced user experience.



Figure 1: WSSROGY Round Toilet Seat (Closed)

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Keep this manual for future reference.

- Ensure all parts are present and undamaged before beginning installation.
- Do not overtighten screws, as this may damage the toilet bowl or the seat.
- Keep small parts away from children to prevent choking hazards.
- Avoid using abrasive cleaners or harsh chemicals on the toilet seat, as they may damage the finish.
- Do not stand on the toilet seat or lid.

3. PARTS LIST

Verify that all the following components are included in your package:

- Round Toilet Seat with Lid (1)
- Plastic Nuts and Screws Set (1) - for bottom installation
- Metal Screws and Rubber Nuts Set (1) - for top installation
- Rubber Pads for Hinge Protection (2)

Two sets of accessories are available



Figure 2: Included accessories for installation.

4. SETUP & INSTALLATION

Before installation, measure your toilet to ensure compatibility. This seat is designed for standard round toilets with a mounting hole distance of 5.5 inches and a length of 16.4 inches from the center of the installation hole to the front of the toilet.



Figure 3: Product dimensions and compatibility for round toilets.



Figure 4: Visual guide for measuring round vs. elongated toilets.

Installation Video Guide

Your browser does not support the video tag.

Video 1: Official installation guide for the WSSROGY toilet seat. This video demonstrates the step-by-step process for securing the seat to your toilet bowl.

Installation Methods:

Your toilet seat comes with two sets of attachments, allowing for installation from either the top or bottom of the toilet bowl. Choose the method most suitable for your toilet.

Method 1: Bottom Installation (Plastic Nuts and Screws)

1. Align the toilet seat hinges with the mounting holes on your toilet bowl.
2. Insert the plastic screws through the hinge holes and down into the toilet bowl holes.
3. From underneath the toilet bowl, thread the plastic nuts onto the screws and tighten them by hand until snug. Do not overtighten.
4. Place the rubber pads under the hinges for added protection and stability.



THE FIRST INSTALLATION METHOD

Figure 5: Step-by-step visual guide for the bottom installation method.

Method 2: Top Installation (Metal Screws and Rubber Nuts)

1. Align the toilet seat hinges with the mounting holes on your toilet bowl.
2. Insert the metal screws with the attached rubber nuts into the hinge holes and down into the toilet bowl holes.
3. Using a screwdriver, tighten the screws from the top. As you tighten, the rubber nuts will expand and secure the seat in place.
4. Place the rubber pads under the hinges for added protection and stability.



Figure 6: Step-by-step visual guide for the top installation method.

5. OPERATION

Slow-Close Feature:

The WSSROGY toilet seat is equipped with a quiet, slow-close mechanism. Simply give the lid or seat a gentle push downwards, and it will close slowly and silently on its own. This feature prevents loud slamming and accidental finger pinching, contributing to a quieter bathroom environment and extending the product's lifespan.



SLOW-CLOSE TOILET SEAT

Figure 7: Demonstration of the slow-close feature.

Your browser does not support the video tag.

Video 2: Product demonstration highlighting the slow-close functionality and overall design.

Easy-Open Design:

The lid features a small gap at the front, designed for easy and hygienic lifting without needing to touch the seat itself. This ergonomic design enhances user comfort and convenience.



*A SMALL GAP
FOR
EASY TO OPEN*

ERGONOMIC DESIGN

Figure 8: Close-up view of the small gap for easy lid opening.

6. MAINTENANCE

To ensure the longevity and cleanliness of your WSSROGY toilet seat, follow these maintenance guidelines:

- **Cleaning:** The smooth surface of the PP material effectively resists dirt. Simply wipe the seat with a soft cloth and mild soap and water. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish and cause discoloration.
- **Inspection:** Periodically check the tightness of the mounting screws. If the seat feels loose, gently tighten the screws to ensure stability.
- **Longevity:** The high-strength PP material is designed to resist yellowing, fading, and breakage, maintaining its new appearance for years with proper care.

7. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Q: How do I buy the right size?

A: Use a ruler to measure the distance from the center of the installation hole to the front of the toilet. 16.5 inches is suitable for round toilet seats, 18.5 inches is suitable for elongated toilet seats.

Q: What material is the toilet seat made of? Is it prone to breakage?

A: Made of high quality white plastic that will not fade, peel or break.

Q: What is a slow close toilet seat?

A: The toilet lid and seat will automatically close slowly with a gentle push, which will not cause loud slamming or hand pinch. It also will not wake up your family with noise during sleeping time.

Q: The toilet seat feels loose after installation.

A: Re-check the tightness of the mounting screws. Ensure they are securely fastened, but do not overtighten. If using the rubber nuts, ensure they have expanded sufficiently.

8. SPECIFICATIONS

Feature	Detail
Brand	WSSROGY
Model	Round
Color	Bright White
Material	Plastic (High-Quality PP)
Product Dimensions	16.4"L x 14"W
Item Weight	3.75 Pounds
Operation Mode	Manual (Slow Close Mechanism)
Mounting Hole Distance	5.5 inches
Special Features	Slow Close, Easy Open Gap, Durable, Non-Yellowing

9. WARRANTY & SUPPORT

WSSROGY stands behind the quality of its products. We promise to replace the soft close toilet seat for free within one year if it is damaged due to quality problems.

For any questions, concerns, or support needs, please contact WSSROGY customer service. Refer to your purchase documentation for specific contact details or visit the official WSSROGY store on Amazon.

Visit WSSROGY
Store

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question