

Joie JOI-T1112GAAPL003

Joie Litetrax 3 Travel System Stroller - User Manual

Model: JOI-T1112GAAPL003

INTRODUCTION

This manual provides detailed instructions for the safe and proper use of your Joie Litetrax 3 Travel System Stroller. Please read all instructions carefully before assembly and use, and keep this manual for future reference. The Joie Litetrax 3 is designed for children from birth up to 15kg, offering a streamlined and sporty design with full-sized features. It is perfectly paired with Joie's Gemm infant seat to create an effortless travel system.



Image Description: A Joie Litetrax 3 Travel System Stroller in dark pewter and grey, shown with a matching Joie Gemm infant car seat securely attached to the stroller frame. The stroller features a black frame, large wheels, and a storage basket underneath.

SETUP

Unpacking and Initial Inspection

- Carefully remove all components from the packaging.
- Inspect all parts for any signs of damage or missing components. If any parts are damaged or missing, do not proceed with assembly and contact customer support.
- Retain packaging for future storage or transport.

Stroller Assembly

1. **Unfolding the Stroller:** Place the stroller on a flat surface. Release the automatic fold lock. Pull the handle upwards until the frame locks into place with an audible click. Ensure all locking mechanisms are securely engaged before use.
2. **Attaching the Wheels:** Insert the front and rear wheels into their respective slots on the stroller frame until they click securely into place. Pull on the wheels to ensure they are firmly attached.
3. **Attaching the Bumper Bar:** Align the bumper bar with the attachment points on the stroller frame and push until it clicks into place. Ensure it is secure.
4. **Attaching the Infant Seat (Travel System):** Position the Joie Gemm infant seat onto the stroller frame. Ensure the connectors align and push down firmly until the infant seat clicks securely into place. Verify the infant seat is properly locked by gently pulling upwards.

OPERATING INSTRUCTIONS

Folding and Unfolding

- **Unfolding:** Release the automatic fold lock. Lift the handle until the frame is fully extended and locked.
- **Folding:** The stroller features a one-hand, quick compact fold mechanism, easily accessed in the middle of the seat. Locate the folding strap/handle in the seat, pull it upwards, and the stroller will collapse. An automatic fold lock will engage to keep it compact.



Image Description: A side view of the Joie Litetrax 3 Stroller in dark pewter and grey, featuring a footmuff for added warmth. The stroller has a large canopy, a sturdy black frame, and three wheels (two rear, one double front).

Seat Recline and Leg Rest Adjustment

- **Recline:** The stroller offers a multi-position, flat reclining seat. Use the one-hand smooth recline system, typically a lever or strap mechanism on the back of the seat, to adjust the recline angle. Ensure the child is not disturbed if sleeping.
- **Leg Rest:** The adjustable leg rest can be moved up or down to provide comfortable support for your child's legs. Locate the buttons or levers on either side of the leg rest to adjust its position.



Image Description: A side view of the Joie Litetrax 3 Stroller in dark pewter and grey, shown without the footmuff. This view highlights the full canopy, the adjustable handle, and the robust wheel design.

Harness System

- The Soft Touch, 5-point harness system ensures your child's safety. Adjust the shoulder straps to one of the three available height positions to fit your child snugly.
- To secure, insert the buckle tongues into the buckle housing until they click. To release, press the button on the buckle housing.

Canopy and Ventilation

- The large, expandable hood provides ultra shade options. Extend or retract the hood as needed for sun protection.
- A ventilated window is integrated into the canopy, allowing for airflow on warmer days.

Brakes and Wheels

- **Brakes:** The single-step, ShoeSaver brakes are located on the rear wheels. Press down on the brake pedal to

engage the brakes and lift up to release. Always engage the brakes when the stroller is stationary.

- **Swivel Wheels:** The double front swivel wheel can be locked for stability on rougher terrain or unlocked for greater maneuverability in tight spaces. Locate the locking mechanism near the front wheels.
- All-wheel suspension provides a smoother ride on various surfaces.

Storage Basket

- The large, easy-access shopping basket located under the seat provides convenient storage for essentials. Do not overload the basket beyond its recommended weight limit.

MAINTENANCE

Cleaning

- **Fabric:** Spot clean fabric parts with a damp cloth and mild soap. Allow to air dry completely. Do not use harsh detergents or bleach. Refer to care labels for specific washing instructions if removable.
- **Frame:** Wipe the frame with a soft, damp cloth. Dry thoroughly to prevent rust.
- **Wheels:** Periodically clean dirt and debris from the wheels and axles to ensure smooth operation.

Storage

- Store the stroller in a clean, dry place away from direct sunlight and extreme temperatures.
- Ensure the stroller is completely dry before storing to prevent mold or mildew.

Inspection

- Regularly check all fasteners, rivets, and joints to ensure they are secure.
- Inspect the harness system for any signs of wear or damage.
- Ensure brakes are functioning correctly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not unfold/fold smoothly.	Fold lock engaged; mechanism obstructed; lack of lubrication.	Ensure fold lock is disengaged. Check for debris obstructing the mechanism. Apply a silicone-based lubricant to moving parts if necessary.
Wheels are stiff or not turning freely.	Dirt/debris in wheel axles; wheel lock engaged.	Clean wheels and axles thoroughly. Ensure front swivel wheel lock is disengaged if free movement is desired.
Brakes not engaging or releasing.	Debris in brake mechanism; worn brake components.	Clear any debris from the brake pedal and mechanism. If issue persists, contact customer support.
Harness straps are difficult to adjust.	Straps twisted or buckle mechanism dirty.	Untwist straps and ensure they are flat. Clean the buckle mechanism if necessary.

SPECIFICATIONS



Image Description: A front-side view of the Joie Litetrax 3 Stroller with key dimensions overlaid. The height is labeled as 103.6cm, the length as 87cm, and the width as 59.5cm.

Feature	Detail
Model Number	JOI-T1112GAAPL003
Product Dimensions (Unfolded)	87 cm (L) x 59.5 cm (W) x 103.6 cm (H)
Folded Size	87 cm x 59.5 cm x 103.6 cm (Note: Dimensions are the same as unfolded, indicating a compact fold within the existing footprint)



Feature	Detail
Item Weight	10 Kilograms
Maximum Weight Recommendation	15 Kilograms
Material Type	Pewter (Fabric)
Frame Material	Aluminium
Color	Grey / Dark Pewter
Harness Type	5 Point
Seating Capacity	1
Specification Met	EN1888-1:2018

WARRANTY AND SUPPORT

For specific warranty information regarding your Joie Litetrax 3 Travel System Stroller, please refer to the documentation provided at the time of purchase or visit the official Joie website. Warranty terms and conditions may vary by region and retailer.

If you require technical assistance, have questions about product features, or need to report a defect, please contact Joie customer support or your authorized retailer. Keep your proof of purchase and model number (JOI-T1112GAAPL003) readily available when contacting support.

Related Documents

	<p>Joie Litetrax Pro / Litetrax Pro Air Stroller Instruction Manual</p> <p>Comprehensive instruction manual for the Joie Litetrax Pro and Litetrax Pro Air stroller, covering assembly, operation, safety, and maintenance. Learn how to safely use and care for your Joie stroller.</p>
	<p>Joie Litetrax Pro / Litetrax Pro Air Stroller User Manual</p> <p>Comprehensive user manual for the Joie Litetrax Pro and Litetrax Pro Air strollers, covering assembly, operation, safety, care, and maintenance. Includes multilingual instructions.</p>

Joie 15kg / 33lb - 36 months

litetrax 3

stroller

- Introduction
- Safety
- Assembly
- Operation
- Maintenance
- Troubleshooting
- Warranty
- Index



[Joie Litetrax 3 Stroller User Manual](#)

Comprehensive user manual for the Joie Litetrax 3 stroller. Learn about assembly, safe operation, maintenance, and features for this certified baby stroller suitable for children up to 15kg.

Joie

litetrax pro litetrax pro air

stroller

- Introduction
- Safety
- Assembly
- Operation
- Maintenance
- Troubleshooting
- Warranty
- Index



[Joie Litetrax Pro / Litetrax Pro Air Stroller Instruction Manual](#)

Comprehensive instruction manual for the Joie Litetrax Pro and Litetrax Pro Air strollers, covering assembly, operation, safety warnings, and maintenance.