

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Joie](#) /
- › [Joie Mirus Lightweight Baby Stroller S1703AALYC000 Instruction Manual](#)

## Joie Mirus S1703AALYC000

# Joie Mirus Lightweight Baby Stroller Instruction Manual

Model: Mirus S1703AALYC000

## INTRODUCTION

This manual provides essential instructions for the safe and proper use, assembly, and maintenance of your Joie Mirus Lightweight Baby Stroller. Please read this manual thoroughly before using the product and retain it for future reference.



## SAFETY INFORMATION

---

Always ensure the safety of your child by following these guidelines:

- Never leave your child unattended in the stroller.
- Always use the 5-point harness system to secure your child.
- Ensure all locking devices are engaged before use.
- Do not overload the stroller or the storage basket. The maximum weight capacity for the child is 17.5 kg.
- Do not use accessories or replacement parts other than those approved by the manufacturer.
- Avoid placing hot liquids or heavy objects in the storage basket.
- Be aware of the risk of open fires and other sources of strong heat, such as electric bar fires, gas fires, etc., in the near vicinity of the stroller.
- Always engage the brakes when the stroller is stationary.
- Ensure that children are kept clear of moving parts when making adjustments.

## SETUP AND INITIAL ASSEMBLY

---

The Joie Mirus stroller comes largely pre-assembled. Follow these steps for initial setup:

1. **Unfolding the Stroller:** Release the one-hand fold lock. The stroller will automatically lock into the open position. Ensure all frame locks are securely engaged.
2. **Attaching Wheels (if necessary):** If wheels are not pre-attached, push them onto the axles until they click into place.
3. **Adjusting the Canopy:** Extend the canopy to provide shade for your child.
4. **Harness Adjustment:** The SoftTouch 5-point harness system adjusts to 3 heights. Adjust the shoulder straps to the appropriate height for your child.



Image: Front view of the Joie Mirus Stroller, showing the canopy and harness.

## OPERATING INSTRUCTIONS

---

### Reversible Handle

The reversible handle allows you to switch between rear-facing (parent-facing) and forward-facing modes. To reverse the handle, locate the release mechanisms on both sides of the handle and engage them, then swing the handle to the desired position until it locks securely.



Image: Side view of the stroller with the handle in the forward-facing position.

## Seat Recline

The seat offers a smooth, one-hand recline function, suitable from birth with a flat reclining seat. To recline the seat, locate the recline lever or strap mechanism behind the seat and adjust to the desired angle. Ensure the seat is securely locked in position before placing your child in it.



Image: Diagram illustrating the lie-flat recline feature and adjustable footrest of the stroller.

## Brake System

The stroller features a single-step, ShoeSaver brake. To engage the brake, press down firmly on the brake pedal located near the rear wheels until it locks. To release, lift the pedal. Always ensure the brake is fully engaged when the stroller is stationary.

## Folding the Stroller

The stroller can be folded with one hand, and it automatically locks. To fold, ensure the seat is in the forward-facing

position. Locate the one-hand fold mechanism (usually a button or lever on the handle) and activate it while pushing the stroller forward to collapse. The automatic lock will engage, leaving your other hand free.





Image: The Joie Mirus Stroller in its compact, folded position.

## Using with Infant Car Seat

The Joie Mirus stroller pairs perfectly with all Joie group 0+ infant seats without the need for adapters. To attach an infant car seat, ensure the stroller seat is in an upright position. Align the car seat with the stroller's attachment points and press down firmly until it clicks securely into place. Always check that the car seat is properly secured before use.



Joie Gemm infant car seat sold separately

## MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your stroller:

- **Cleaning Fabric:** The removable seat pad may be washed in cold water and drip-dried. Do not use bleach.
- **Cleaning Frame:** To clean the stroller frame, use only household soap and warm water. Do not use bleach or detergent.
- **Post-Beach/Dusty Use:** When using your stroller at the beach or areas of high dust/sand, completely clean your stroller after use to remove sand and salt from brake mechanisms and wheel assemblies.
- **Drying:** If the stroller becomes wet, open the canopy and allow it to dry thoroughly before storing.
- **Regular Checks:** From time to time, check your stroller for loose screws, worn parts, torn material, or stitching. Replace or repair parts as needed.
- **Wheel Lubrication:** If wheels squeak, use a light oil (e.g., Silicon Spray, anti-rust oil, or sewing machine oil). It is important to get the oil into the axle and wheel assembly.
- **Brake Maintenance:** If the brake pedal is stiff or hard to fully engage, flush any debris from the brake system with clean water first before lubricating.
- **Environmental Exposure:** Excessive exposure to sun or heat could cause fading or warping of parts.

## TROUBLESHOOTING

If you encounter issues with your Joie Mirus Stroller, refer to the following common solutions:

- **Stroller not unfolding/folding smoothly:** Ensure all locking mechanisms are disengaged before attempting to fold/unfold. Check for any obstructions in the folding mechanism.
- **Wheels squeaking:** Apply a light lubricant (e.g., silicone spray) to the wheel axles. Refer to the Maintenance section for details.
- **Brakes not engaging/disengaging:** Check for debris in the brake mechanism. Clean thoroughly and lubricate if necessary. Ensure the pedal is fully pressed or lifted.
- **Harness difficult to adjust:** Ensure the harness straps are not twisted. Refer to the setup section for proper adjustment.
- **Stroller feels unstable:** Verify that all frame locks are securely engaged after unfolding. Do not exceed the maximum weight capacity.

## SPECIFICATIONS

Feature	Detail
Model Name	Mirus
Model Number	S1703AALYC000 (Also referred to as S0942 in some documentation)
Product Type	Lightweight Baby Stroller / Pram
Recommended Age	Birth to 3 years
Maximum Child Weight	17.5 kg

Feature	Detail
Harness Type	5-Point SoftTouch Harness
Frame Material	Aluminium
Material Composition	Fabric, Metal, Plastic
Open Size (L x W x H)	101 cm x 48 cm x 79 cm
Folded Size (L x W x H)	48 cm x 31 cm x 99 cm
Item Weight	7.49 kg
Reversible Handle	Yes
Recline Positions	Multi-position, including lie-flat
Brake System	Single-step, ShoeSaver brake
Compatibility	Pairs with all Joie group 0+ infant seats (no adapters needed)
Testing Certification	EN 1888:2012

### WARRANTY INFORMATION

A 3-month warranty is available on your purchase. This warranty is valid only on products sold by TRUCAREKIDZ INDIA PRIVATE LIMITED (Brand Authorized Distributor). Please retain your proof of purchase for warranty claims.

### CUSTOMER SUPPORT

For further assistance, spare parts, or warranty claims, please contact your authorized Joie retailer or the distributor:  
**TRUCAREKIDZ INDIA PRIVATE LIMITED**  
Please refer to your purchase documentation for specific contact details.



## Joie Nitro™ Stroller: User Manual & Safety Guide

Comprehensive instruction manual for the Joie Nitro™ stroller. Learn about assembly, safe usage, features, and maintenance for this lightweight and compact baby stroller, compliant with EN 1888-1:2018+A1:2022 standards.



## Joie Muze LX Stroller - Instruction Manual

Comprehensive guide for the Joie Muze LX stroller, covering assembly, operation, safety, and care instructions. Suitable for children up to 15kg (birth to 36 months). Visit [Joiebaby.com](https://www.joiebaby.com) for more information.



Joie Finiti Stroller Instruction Manual - Assembly, Operation, and Safety

Comprehensive instruction manual for the Joie Finiti stroller, covering assembly, operation, safety warnings, maintenance, and accessories. Learn how to safely use and care for your Joie Finiti stroller.



## Joie Nitro Stroller: Instruction Manual, Safety, and Care Guide

Comprehensive instruction manual for the Joie Nitro stroller, covering assembly, operation, safety warnings, and maintenance. Suitable for children up to 22kg.



## Joie Estrella Stroller User Manual and Guide

Comprehensive user manual for the Joie estrella™ double stroller, covering assembly, operation, safety guidelines, and care instructions. Approved to EN 1888-2:2018+A1:2022 standards.



Detailed instruction manual for the Joie Signature Parcel stroller. Learn about assembly, operation, safety features, and maintenance for this high-quality, certified baby stroller. Visit [joiebaby.com](http://joiebaby.com) for more information.