



Manuals.plus /

› Esperanza /

› Esperanza Nutri Blender Instruction Manual - Model B07K66VG1K

Esperanza B07K66VG1K

Esperanza Nutri Blender Instruction Manual

Model: B07K66VG1K

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Esperanza Nutri Blender. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid. Clean only with a damp cloth.
- Keep hands and utensils out of the blending jar while blending to prevent personal injury and damage to the blender.
- Ensure the blade assembly is securely fastened to the blending jar before placing it on the motor base.
- Do not blend hot liquids, as pressure buildup can cause the lid to eject and result in burns.
- Never operate the blender with an empty jar.
- Do not overfill the blending jar. Refer to the maximum fill line.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- Keep out of reach of children.
- Do not use attachments not recommended or sold by the manufacturer.
- Inspect the power cord and plug regularly for any damage. Do not operate if damaged.

PACKAGE CONTENTS

Carefully unpack all components and ensure all items are present. Retain packaging for future storage or transport.

- Motor Base (900W)
- Large Blending Jar (1 Liter capacity, Acrylic, BPA Free)

- Small Blending Jar (Acrylic, BPA Free)
- Stainless Steel Blade Assembly (for blending)
- Travel Lid with spout
- Storage Lids (2 units)



Image: All components of the Esperanza Nutri Blender, including the motor base, two blending jars, the stainless steel blade assembly, a travel lid, and two storage lids.

SETUP AND ASSEMBLY

Follow these steps to assemble your Nutri Blender before first use.

1. **Clean Components:** Before initial use, wash all blending jars, lids, and blade assemblies in warm, soapy water. Rinse thoroughly and dry. The jars, lids, and blade assemblies are dishwasher safe.
2. **Prepare Ingredients:** Add your desired ingredients to either the large or small blending jar. Do not

exceed the maximum fill line indicated on the jar.

3. **Attach Blade Assembly:** Screw the stainless steel blade assembly firmly onto the open end of the blending jar until it is tightly sealed. Ensure there are no leaks.
4. **Place on Motor Base:** Invert the assembled jar (with blade assembly facing down) and place it onto the motor base. Align the tabs on the jar with the slots on the motor base.
5. **Secure Jar:** Twist the jar clockwise until it locks into place. The blender will not operate unless the jar is correctly secured.



Image: The Esperanza Nutri Blender motor base with the large blending jar and blade assembly attached, alongside the small blending jar and a travel lid.

OPERATING INSTRUCTIONS

Your Esperanza Nutri Blender is designed for simple, push-button operation.

1. **Connect Power:** Plug the power cord into a standard 220V electrical outlet.
2. **Start Blending:** Press and hold the power button on the motor base to begin blending. The blender operates at a single speed (900 watts).
3. **Continuous Blending:** For continuous blending, you may need to hold the button down. Refer to the product's specific button mechanism for pulse or continuous operation.
4. **Stop Blending:** Release the power button to stop blending.
5. **Remove Jar:** Once blending is complete, twist the blending jar counter-clockwise to unlock it from the motor base.
6. **Serve:** Carefully remove the blade assembly from the jar. You can then attach a travel lid or storage lid for convenience.

Tips for Best Results:

- For thicker mixtures, add a small amount of liquid to aid blending.
- Cut larger ingredients into smaller pieces before blending.
- Do not operate the blender for more than 1 minute continuously to prevent overheating. Allow a short break between cycles if needed.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Esperanza Nutri Blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Clean Jars and Lids:** The blending jars, lids, and blade assemblies are dishwasher safe. Alternatively, wash them by hand with warm, soapy water. Use a brush to clean around the blades carefully.
3. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
4. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing.
5. **Storage:** Store the blender in a dry place, away from direct sunlight and heat.

TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; Jar not properly secured; Power outage.	Ensure power cord is securely plugged in; Twist jar clockwise until locked; Check household power supply.
Ingredients are not blending smoothly.	Too little liquid; Too many ingredients; Ingredients are too large.	Add more liquid; Reduce ingredient quantity; Cut ingredients into smaller pieces.
Blender leaks from the bottom of the jar.	Blade assembly not tightened properly; Seal is damaged or missing.	Ensure blade assembly is screwed on tightly; Check the rubber seal for proper placement and condition.
Motor smells or overheats.	Overloaded; Operated for too long.	Reduce ingredients; Do not operate continuously for more than 1 minute. Allow to cool down.

SPECIFICATIONS

Feature	Detail
Brand	Esperanza
Model	B07K66VG1K
Power	900 Watts
Voltage	220 Volts
Capacity	1 Liter (Large Jar)
Number of Speeds	1
Controls Type	Push Button
Blade Material	Stainless Steel
Jar Material	Acrylic
Material Type Free	BPA Free
Dishwasher Safe Parts	Yes (Jars, Lids, Blade Assembly)
Item Weight	2.47 Kilograms

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Esperanza customer service directly. Keep your proof of purchase for warranty claims.