

[Manuals.plus](#) /

› [Deerma](#) /

› Deerma NU05 Rechargeable Personal Power Blender With 400 ml Tritan Jar, Rose Gold Instruction Manual

Deerma DEM-NU05

Deerma NU05 Rechargeable Personal Power Blender Instruction Manual

MODEL: DEM-NU05

1. Introduction

Thank you for choosing the Deerma NU05 Rechargeable Personal Power Blender. This compact and portable blender is designed for convenient preparation of fresh juices, smoothies, and other blended beverages. Featuring a 400 ml Tritan jar and a powerful motor, it offers a simple and efficient blending experience. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

2. Safety Information

- **Read all instructions:** Before operating the blender, carefully read and understand all instructions provided in this manual.
- **Electrical Safety:** Do not immerse the motor base in water or other liquids. Ensure the charging port is dry before connecting the charging cable.
- **Blade Safety:** The blades are sharp. Handle with extreme care when assembling, disassembling, or cleaning the unit. Avoid contact with moving parts.
- **Child Safety:** Keep the blender out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities unless supervised.
- **Proper Use:** Do not operate the blender without the jar securely attached. Do not overfill the jar.
- **Temperature:** Do not blend hot liquids. Allow hot ingredients to cool before blending.
- **Hard Ingredients:** Avoid blending extremely hard ingredients such as whole nuts, coffee beans, or large ice cubes, as this may damage the blades or motor.
- **Charging:** Use only the provided charging cable. Do not attempt to charge the blender with damaged cables or chargers.
- **Maintenance:** Do not attempt to repair or modify the blender yourself. Contact customer support for any issues.

3. Product Overview

The Deerma NU05 Personal Power Blender consists of a motor base, a blending jar, and a blade assembly integrated into the lid. It features a simple one-button operation and indicator lights for status feedback.



Figure 3.1: Deerma NU05 Personal Power Blender, showcasing its compact design and rose gold finish.

8 MAJOR UPGRADES DEERMA JUICER CUP NU05



1. Wireless Juicing
2. Sports Cup Cover
3. Powerful Serrated Blade
4. 6-leaf Blade
5. 15-day Long Battery Life
6. 2-press Open System
7. Fast Charging
8. PCTG Food Grade Materials

Figure 3.2: Key features of the Deerma NU05, including wireless juicing, sports cup design, powerful serrated 6-leaf blade, 15-day battery life, 2-press open system, fast charging, and PCTG food-grade materials.



Figure 3.3: Indicator Light Meanings:

Blue Light: Indicates the cup is installed properly and the device has sufficient charge, ready for use.

Red Light: Indicates the cup is not installed correctly or the battery charge is too low. Check the device before use.

4. Setup

1. **Initial Cleaning:** Before first use, wash the blending jar and lid with warm soapy water. Rinse thoroughly and dry all parts. Do not immerse the motor base in water.
2. **Charging:** Ensure the blender is fully charged before first use. Connect the charging cable to the charging port on the motor base and plug it into a suitable USB power source. The indicator light will show charging status (refer to Figure 3.3).
3. **Assembly:** Place the blade assembly (integrated into the lid) onto the motor base. Ensure it is securely twisted and locked into place. Then, attach the Tritan jar to the blade assembly, twisting until it clicks securely.

5. Operating

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1-2 cm) to ensure optimal blending.
2. **Add Ingredients:** Place your desired ingredients into the Tritan jar. For best results, add liquids first, then soft ingredients, and finally harder ingredients. Do not exceed the maximum fill line (400 ml).
3. **Secure the Lid:** Ensure the lid with the blade assembly is securely fastened onto the jar, and the jar is securely attached to the motor base. The blue indicator light should illuminate, confirming proper assembly and readiness.
4. **Start Blending:** Double-press the power button to start the blending cycle. The blender will operate for a preset duration (typically 30-40 seconds) or until you press the button again to stop.
5. **Blending Tips:**
 - If ingredients are stuck, gently shake the blender while it is operating.
 - For thicker mixtures, add more liquid.
 - Do not continuously operate the blender for more than 1 minute to prevent overheating. Allow it to cool down if multiple cycles are needed.
6. **After Blending:** Once blending is complete, carefully unscrew the jar from the motor base. You can drink directly from the jar or pour the contents into another container.



Figure 5.1: The Deerma NU05 blender filled with fresh berries and strawberries, ready for blending.



Figure 5.2: The Deerma NU05 blender containing avocado and pineapple chunks, demonstrating its capacity for various ingredients.

6. Maintenance

Regular cleaning and proper storage will extend the life of your Deerma NU05 blender.

- **Cleaning the Jar and Lid:** After each use, rinse the jar and blade assembly immediately to prevent food residue from drying. You can fill the jar with water and a drop of dish soap, then run a short blending cycle to clean the blades. Disassemble the jar and lid, wash with warm soapy water, and rinse thoroughly.
- **Cleaning the Motor Base:** Wipe the motor base with a damp cloth. Do not immerse it in water or place it under running water. Ensure the charging port is dry before cleaning.
- **Drying:** Allow all parts to air dry completely before reassembling or storing.
- **Storage:** Store the blender in a clean, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

Problem	Possible Cause	Solution
Blender does not turn on.	Jar not properly assembled. Battery is low. Power button not double-pressed.	Ensure jar and lid are securely twisted onto the motor base until the blue light appears. Charge the blender fully. Double-press the power button quickly.
Blades are stuck or not blending effectively.	Too many ingredients. Ingredients are too large or hard. Insufficient liquid.	Reduce the amount of ingredients. Cut ingredients into smaller pieces. Add more liquid to the mixture. Gently shake the blender during operation.
Red indicator light is on.	Jar not properly installed. Battery is low.	Re-secure the jar and lid. Charge the blender.
Leakage from the jar.	Lid not properly sealed. Overfilling.	Ensure the lid is tightly screwed onto the jar. Do not exceed the maximum fill line.

8. Specifications

- **Model:** DEM-NU05
- **Capacity:** 400 ml
- **Body Material:** Tritan
- **Blade Material:** Stainless Steel
- **Power Source:** Battery Powered (Rechargeable)
- **Voltage:** 220 Volts
- **Product Dimensions:** 32D x 11W x 10H Centimeters
- **Item Weight:** 820 g
- **Included Components:** 1 x Juice blender
- **Special Feature:** Cordless

9. Warranty and Support

For warranty information and customer support, please contact the manufacturer or authorized importer. Keep your purchase receipt as proof of purchase.

Manufacturer: Guangdong Deerma Technology Co., Ltd., Foshan city, Guangdong Province, China

Importer (India): ALLIN IMPEX SERVICES PVT LTD, C-38, SECTOR-63, NOIDA, UP, 201301

Mobile: 9313132789

Email: sales@allinexporters.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07NCWDYB6>

More documents and user manuals: <https://manuals.plus/>