

FIGERM NA-H21B

FIGERM Electric Heated Blanket User Manual

Model: NA-H21B (Queen Size, 84" x 90")

1. INTRODUCTION

Thank you for choosing the FIGERM Electric Heated Blanket. This manual provides essential information for the safe and efficient operation, care, and maintenance of your new heated blanket. Please read all instructions carefully before use and retain this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of burns, electric shock, fire, or injury, always follow these basic safety precautions:

- **DO NOT** use with an infant, child, incapacitated person, or anyone insensitive to heat.
- **DO NOT** use on areas of the body that are swollen, inflamed, or have skin eruptions.
- **DO NOT** use if the blanket is wet.
- **DO NOT** use pins or other metallic objects with this blanket. They may damage the wiring.
- **DO NOT** use if the power cord or controller is damaged. Contact customer support immediately.
- **DO NOT** dry clean. Dry cleaning solvents may damage the insulation of the heating element.
- **DO NOT** pull by the cord. Always grasp the plug to disconnect from the outlet.
- Ensure the blanket is spread flat and not bunched or folded when in use to prevent overheating.
- The blanket features an **Overheat Protection** system and an **Auto-Off Timer (1-8 hours)** for enhanced safety.

3. PRODUCT OVERVIEW

Key Features

- **Fast Heating & Auto-Off Setting:** Heats up quickly and evenly with 6 heating levels (85°F ~ 110°F). Features an auto-off timer (1~8H) and overheat protection.

- **Flexible Use & Machine Washable:** Controller is detachable, allowing the blanket to be used as a regular blanket and making it machine washable. Includes a 20ft power cord for flexible placement.
- **Soft Flannel & Superior Warmth:** Made from deluxe flannel, skin-friendly, promoting heat penetration and retention. Large 84"x 90" size for full body coverage.
- **Easy to Use & Multipurpose:** Suitable for napping, travel, knee warmth, or as a sofa blanket. ETL and FCC certified for guaranteed safety.



This diagram illustrates the double-sided flannel and internal heating elements of the FIGERM Electric Heated Blanket, along with icons for skin-friendly, auto shut-off, fast heating, machine washable, adjustable heating levels, and overheat protection.

4. SETUP

Unpacking and Initial Placement

1. Carefully remove the heated blanket from its packaging.
2. Unfold the blanket completely and lay it flat on your bed or desired surface. Ensure there are no wrinkles or folds that could cause localized overheating.

Connecting the Controller

1. Locate the connector on the blanket and the corresponding connector on the controller cord.
2. Firmly push the controller connector into the blanket connector until it clicks securely into place. Ensure a tight connection.
3. Plug the power cord into a standard 120V AC electrical outlet.

Effective & Easy to Operate



A detailed view of the soft flannel fabric of the FIGERM Electric Heated Blanket on a bed, with the controller visible, emphasizing its texture and control features.

5. OPERATING INSTRUCTIONS

Power On/Off

- To turn the blanket **ON**, press the power button on the controller. The display will illuminate.
- To turn the blanket **OFF**, press the power button again.

Adjusting Heat Levels

- The blanket offers 6 heating levels, ranging from 85°F to 110°F.
- Use the '+' and '-' buttons on the controller to increase or decrease the heat setting to your desired comfort level.

Setting the Auto-Off Timer

- The blanket has an automatic shut-off timer that can be set from 1 to 8 hours.
- Press the timer button on the controller to cycle through the available timer settings. The selected time will be displayed.

- The blanket will automatically turn off once the set time has elapsed.



The FIGERM Electric Heated Blanket is shown on a couch, accompanied by a graphic illustrating its 6 heating levels, ranging from 85°F to 110°F.

Your browser does not support the video tag.

This video demonstrates the features and usage of the FIGERM Electric Heated Blanket, including its size, soft texture, and the functionality of the controller for adjusting heat levels and setting the auto-off timer.

6. CARE AND MAINTENANCE

Washing Instructions

The FIGERM Electric Heated Blanket is machine washable for easy care. Follow these steps:

1. **Disconnect the Controller:** Before washing, always disconnect the electrical cord from the blanket by squeezing the connector locking clips with one hand and pulling firmly with the other hand.
2. **Machine Wash:** Wash the blanket in cold water on a gentle cycle or by hand.
3. **Drying:** Tumble dry on low heat or line dry. Remove promptly from the dryer. **DO NOT WRING.**
4. **DO NOT USE BLEACH.**
5. Ensure the blanket and pad connector are completely dry before plugging in and using again.



84 X 90"
Figerm Electric Heated Blanket

A woman is shown preparing to wash the FIGERM Electric Heated Blanket by placing it into a washing machine. An inset graphic reminds users to detach the controller before washing.

Storage

When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal wiring.

7. TROUBLESHOOTING

If you experience any issues with your heated blanket, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blanket does not heat.	Not properly plugged in; controller not connected securely; power outage.	Ensure power cord is fully plugged into outlet and controller is securely connected to the blanket. Check household circuit breaker.
Blanket heats unevenly.	Blanket is folded or bunched.	Spread the blanket flat, ensuring no folds or creases.
Controller display is off or flashing.	Overheat protection activated; internal error.	Unplug the blanket from the wall outlet for 10-15 minutes, then plug it back in. If the issue persists, contact customer support.

8. PRODUCT SPECIFICATIONS

Specification	Detail
Brand	FIGERM
Model Number	NA-H21B
Size	Queen (84"L x 90"W)
Material	100% Polyester Flannel
Heating Levels	6 (85°F ~ 110°F)
Auto-Off Timer	1-8 Hours
Special Feature	Skin Friendly, Overheat Protection
Power Cord Length	20 ft
Certifications	ETL, FCC
Product Weight	1.4 Pounds

9. WARRANTY AND CUSTOMER SUPPORT

FIGERM is committed to providing high-quality products and excellent customer service. We offer the following support:

- **30-Day Warranty:** Your purchase is covered by a 30-day warranty from the date of purchase. This warranty

covers manufacturing defects and malfunctions under normal use.

- **24/7 Customer Support:** For any questions, concerns, or warranty claims, please contact our customer support team. We are available 24/7 to assist you.

Please visit our official website or contact the retailer for detailed warranty information and contact methods.