

Targus AMW610AP

Targus W610 AMW610AP Wireless 4-Key Optical Mouse User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Targus W610 AMW610AP Wireless 4-Key Optical Mouse. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Image: Side view of the Targus W610 AMW610AP Wireless Optical Mouse, showcasing its ergonomic design.

SETUP

1. Battery Installation

The Targus W610 AMW610AP mouse requires two AAA batteries for operation. These are included with your purchase.

1. Locate the battery compartment cover on the underside of the mouse.
2. Slide the cover open.
3. Insert two AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.



Image: The underside of the Targus W610 mouse, illustrating the battery compartment and the storage slot for the USB receiver.

2. USB Receiver Connection

The wireless USB receiver enables communication between the mouse and your computer.

1. Remove the USB receiver from its storage slot on the underside of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Your computer should automatically detect and install the necessary drivers. This may take a few moments.



Image: The Targus W610 Wireless Optical Mouse displayed alongside its compact USB receiver.

3. Powering On

After installing the batteries and connecting the USB receiver, turn on the mouse.

1. Locate the On/Off switch on the underside of the mouse.
2. Slide the switch to the 'On' position.
3. The mouse is now ready for use.

OPERATING INSTRUCTIONS

Basic Functions

The Targus W610 AMW610AP mouse features standard controls for navigation and interaction.

- **Left Click:** Primary action, typically used for selecting items or opening links.
- **Right Click:** Secondary action, typically used for opening context menus.
- **Scroll Wheel:** Used for vertical scrolling through documents and web pages. Can also function as a

middle click button.

- **2.4 GHz Wireless Technology:** Provides a reliable and stable connection to your computer.



Image: The Targus W610 Wireless Optical Mouse positioned next to a laptop, demonstrating its use in a typical computing environment.

DPI Adjustment

The mouse features a 3-level DPI adjustment button, allowing you to change the cursor sensitivity.

- Press the DPI button (located near the scroll wheel) to cycle through the available sensitivity settings: 800, 1200, and 1600 DPI.
- Select the DPI setting that best suits your preference and task.

MAINTENANCE

Cleaning

To maintain the performance and appearance of your mouse:

- Use a soft, dry cloth to wipe the exterior of the mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- Do not allow liquids to enter the mouse casing.

Battery Replacement

When the mouse performance degrades or stops responding, it may be time to replace the batteries.

- Follow the battery installation steps outlined in the Setup section.
- Dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

If you encounter issues with your Targus W610 AMW610AP mouse, refer to the following common problems and solutions:

Problem	Solution
Mouse not responding	<ul style="list-style-type: none">◦ Ensure the mouse is switched 'On'.◦ Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.◦ Verify the USB receiver is securely plugged into a working USB port. Try a different USB port.◦ Restart your computer.
Cursor movement is erratic or slow	<ul style="list-style-type: none">◦ Clean the optical sensor on the underside of the mouse.◦ Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).◦ Adjust the DPI setting using the DPI button.
Wireless connection issues	<ul style="list-style-type: none">◦ Move the mouse closer to the USB receiver.◦ Ensure there are no large metal objects or other wireless devices interfering with the signal.◦ Unplug and re-plug the USB receiver.

SPECIFICATIONS

Key technical specifications for the Targus W610 AMW610AP Wireless Optical Mouse:

- **Model Number:** AMW610AP
- **Connectivity:** 2.4 GHz Wireless (USB Receiver)
- **Sensor Type:** Optical
- **DPI Settings:** 800, 1200, 1600 (Adjustable)
- **Number of Buttons:** 4 (Left, Right, Scroll Wheel/Middle Click, DPI)
- **Power Source:** 2 x AAA Batteries (Included)
- **Average Battery Life:** Approximately 12 Months
- **Dimensions (LxWxH):** 110 x 66.4 x 38 mm
- **Weight:** 70 g
- **Compatible Operating Systems:** Linux, Windows XP (and newer versions)
- **Hardware Platform:** Laptop, Personal Computer

WARRANTY AND SUPPORT

Warranty Information

The Targus W610 AMW610AP Wireless Optical Mouse comes with a **3-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, warranty claims, or further inquiries, please visit the official Targus website or contact their customer support. Refer to the packaging or the Targus website for the most current contact information.