

Petwant PF-105

Petwant PF-105 Automatic 5-Meal Pet Feeder User Manual

Model: PF-105

1. INTRODUCTION

Thank you for choosing the Petwant PF-105 Automatic 5-Meal Pet Feeder. This device is designed to provide scheduled meals for your cat or small dog, ensuring they are fed consistently even when you are away. Please read this manual thoroughly before operating the feeder to ensure proper use and maintenance.

2. PRODUCT FEATURES

- **5 Separate Food Trays:** Allows for up to 5 scheduled meals.
- **User-Defined 24-Hour Feeding Time Setting:** Customize meal schedules.
- **10-Second Voice Recording:** Record a message to call your pet at meal times.
- **Dual Power Supply System:** Operates with an adapter or batteries for reliability.
- **Suitable for Dry and Semi-Wet Food:** Versatile for various pet food types.
- **Automatic Standby Mode:** Conserves power when not in operation.
- **Memory Function:** Retains settings even after power interruption.



Figure 2.1: The Petwant PF-105 Automatic 5-Meal Pet Feeder, showcasing its compact design and a visible food

3. PACKAGE CONTENTS

Please check the package for the following items:

- Petwant PF-105 Automatic Pet Feeder Unit
- Power Adapter
- User Manual (this document)

4. SETUP

4.1 Power Supply

The feeder can be powered by the included AC adapter or by 4 x C-size batteries (not included). For optimal performance, it is recommended to use both power sources as a backup.

1. **Adapter:** Plug the AC adapter into the power port on the feeder and then into a standard wall outlet.
2. **Batteries:** Open the battery compartment on the bottom of the feeder and insert 4 C-size batteries, ensuring correct polarity.

4.2 Filling Food Trays

The feeder has five separate compartments for food. Lift the lid to access the trays.



Figure 4.1: A hand demonstrating how to open the lid of the Petwant PF-105 feeder to access the food compartments.

1. Gently press the release button (if present) or lift the lid to expose the rotating tray.
2. Fill each of the five compartments with dry or semi-wet pet food. Do not overfill.
3. Close the lid securely.



Figure 4.2: A detailed view of the five individual food compartments within the Petwant PF-105 feeder, each containing pet kibble.

5. OPERATING INSTRUCTIONS

5.1 Setting the Clock

Refer to the display and control panel on the feeder. Typically, there will be buttons for 'SET', 'UP', and 'DOWN'.

1. Press the 'SET' button until the hour digit flashes.
2. Use 'UP'/'DOWN' buttons to adjust the hour.
3. Press 'SET' again to move to the minute digit and adjust.
4. Press 'SET' to confirm and exit clock setting mode.

5.2 Programming Meal Times

The feeder allows you to set up to 5 distinct meal times.

1. Press 'SET' repeatedly until 'MEAL 1' (or similar indicator) appears and the time flashes.
2. Use 'UP'/'DOWN' to set the desired feeding time for Meal 1.
3. Press 'SET' to confirm Meal 1 and move to Meal 2.
4. Repeat for Meals 2 through 5. If a meal is not needed, set its time to 'OFF' or an invalid time (e.g., 00:00 if it means off).
5. After setting all desired meals, press 'SET' to exit programming mode.

5.3 Recording a Voice Message

The feeder includes a 10-second voice recorder to call your pet at meal times.

1. Locate the 'REC' (Record) button.
2. Press and hold the 'REC' button. Speak clearly into the microphone for up to 10 seconds.
3. Release the 'REC' button to save the message.
4. To play back the message, press the 'PLAY' button (if available) or wait for the next scheduled meal.



Figure 5.1: A small dog enjoying a meal dispensed by the Petwant PF-105 automatic feeder, demonstrating its use in a pet's daily routine.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your feeder.

1. **Unplug and Remove Batteries:** Always disconnect the power adapter and remove batteries before cleaning.
2. **Remove Food:** Empty any remaining food from the trays.
3. **Clean Trays:** The food tray can typically be removed for washing. Wash with mild soap and water. Rinse thoroughly and dry completely before reassembling.
4. **Clean Main Unit:** Wipe the main unit with a damp cloth. Do not immerse the main unit in water, as it contains electronic components.
5. **Dry Completely:** Ensure all parts are completely dry before reassembling and adding food.

7. TROUBLESHOOTING

- **Feeder Not Dispensing Food:**
 - Check if meal times are correctly set.
 - Ensure the feeder has power (adapter plugged in, batteries installed and charged).
 - Verify that the food trays are not jammed or obstructed.
- **Display Not Working:**
 - Check power supply. Replace batteries if using battery power.
 - Ensure the adapter is securely connected.
- **Voice Recording Not Playing:**
 - Ensure a message was successfully recorded. Try re-recording.
 - Check volume settings if available.

- **Food Getting Stuck:**
 - Ensure food is dry and not clumping.
 - Clean the trays and dispensing mechanism.



8. SPECIFICATIONS





Attribute	Detail
Brand	Petwant
Model	PF-105
Capacity	5 Liters
Operation Mode	Automatic
Target Species	Cat, Dog
Power Supply	AC Adapter, 4 x C-size Batteries (not included)

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact the manufacturer directly using the contact details provided with your purchase or visit the official Petwant website. Please retain your proof of purchase for warranty claims.

Related Documents - PF-105

 <p>The image shows the cover of the PetWant F11-L Automatic Pet Feeder User Manual. It features the PetWant logo at the top, followed by the product name 'PetWant F11-L' and 'Használati utasítás' (User Manual) in Hungarian. Below the text is a small illustration of the white automatic pet feeder.</p>	<p>PetWant F11-L Automatic Pet Feeder User Manual</p> <p>This user manual provides detailed instructions for the PetWant F11-L automatic pet feeder, covering setup, operation, maintenance, troubleshooting, and safety guidelines. Learn how to program feeding schedules, use the voice recording feature, and ensure optimal performance for your pet.</p>
 <p>The image shows the cover of the PETWANT 102 Automatic Pet Feeder User Manual and Instructions. It features the product name 'PETWANT 102' and 'HASZNÁLATI UTASÍTÁS' (User Manual) in Hungarian. Below the text is a small illustration of the white automatic pet feeder.</p>	<p>PETWANT 102 Automatic Pet Feeder User Manual and Instructions</p> <p>Detailed user manual for the PETWANT 102 automatic pet feeder. Learn how to set up, program feeding schedules, record voice messages, clean, and maintain your pet's automatic food dispenser. Includes specifications and troubleshooting tips.</p>

<div><div>User Manual</div><div>Smart Pet Feeder</div><div></div><div><small>Petwant® ist ein Markenname und kein Produkt.</small></div></div>	<div>Petwant F17-C Smart Pet Feeder User Manual Setup, Operation & Safety</div> <div>Comprehensive user manual for the Petwant F17-C Smart Pet Feeder. Learn about setup, components, features, operation, cleaning, safety precautions, and troubleshooting.</div>
<div><div>petwant</div><div>Intelligenter Futterspender mit 6 Fächern</div><div>PetWant F13</div><div>Gebrauchsanweisung</div><div></div><div><small>Bitte lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie dieses Produkt verwenden.</small></div></div>	<div>PetWant F13 Intelligent Pet Feeder with 6 Compartments - User Manual</div> <div>Comprehensive user manual for the PetWant F13 intelligent pet feeder, detailing setup, operation, safety guidelines, maintenance, and troubleshooting for this 6-compartment automatic pet food dispenser.</div>
<div><div>petwant</div><div>User Manual</div><div>6 Meal Pet Feeder</div><div></div><div><small>Please read the manual carefully before using this product.</small></div></div>	<div>Petwant 6 Meal Pet Feeder User Manual</div> <div>Comprehensive user manual for the Petwant 6 Meal Pet Feeder (Model F13-L), covering device placement, safety information, components, display panel functions, parameters, installation, setup, cleaning, maintenance, and troubleshooting.</div>
<div><div>GERAUCHSANWEISUNG</div><div>FUTTERSPENDER PETWANT F5</div><div><small>Bitte lesen Sie die vollständigen Anweisungen, bevor Sie dieses Produkt verwenden. Beachten Sie, dass Änderungen von unautorisierten Dritten vorgenommen wurden, die den nicht autorisierten Hersteller beeinträchtigen. Die Verantwortung für Schäden, die durch die Verwendung dieses Produkts entstehen, liegt bei Ihnen. Bitte lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie dieses Produkt verwenden.</small></div><div><small>Stellen Sie sicher, dass das Produkt korrekt montiert ist. Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie das Produkt verwenden. Das Produkt kann nur für die Verwendung mit Gefäßen von 3 bis 20 cm Durchmesser verwendet werden. Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie das Produkt verwenden. Das Produkt kann nur für die Verwendung mit Gefäßen von 3 bis 20 cm Durchmesser verwendet werden. Lesen Sie die Bedienungsanleitung sorgfältig durch, bevor Sie das Produkt verwenden.</small></div><div>PACKUNGSINHALT</div><div></div></div>	<div>Petwant F5 Automatic Pet Feeder User Manual</div> <div>Comprehensive user manual for the Petwant F5 automatic pet feeder, covering setup, features, cleaning, and technical specifications.</div>

Documents - Petwant – PF-105



РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ

Кормушка автоматическая Petwant PF-105 для собак и кошек на 5 кормлений



[\[pdf\]](#) User Manual

Инструкция для Кормушки автоматической Petwant PF 105 собак и кошек на 5 кормлений

руководство как настроить Менеджер Minicam24 ru Кормушка автоматическая ПОЛЬЗОВАТЕЛЯ

Page 2 Версия 1 0 minicam24 СОДЕРЖАНИЕ Внешний вид kormushka avtomaticheskaja pf dlja

sobak i koshek na kormlenijj srsltid AfmBOoo Z52Ow27K 31hH6ikApvAQbiK0zVqO3JG00lcbD upload

content manual 31hH6ikApvAQbiK0zVqO3JG00lcbDIPG4gUCjqN |||

Petwant **PF-105** 5 1.0 minicam24.ru 1.

..... 3 2.

..... 4 2.1

..... 4 2.2

lang:i-klinglon score:28 filesize: 441.13 K page_count: 10 document date: 2022-03-16

