

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Oxygenics](#) /

› [Oxygenics Marvel Chrome 6-Spray Handheld Shower User Manual](#)

Oxygenics 55189

Oxygenics Marvel Chrome 6-Spray Handheld Shower User Manual

Model: 55189

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Oxygenics Marvel Chrome 6-Spray Handheld Shower. Please read these instructions carefully before use and retain them for future reference to ensure optimal performance and longevity of your product.



Image: Oxygenics Marvel Chrome 6-Spray Handheld Shower in its retail packaging, showcasing the product and its features.

INSTALLATION GUIDE

Before You Begin

- Ensure you have an adjustable wrench and plumber's tape (Teflon tape) readily available.
- Turn off the main water supply to your shower area to prevent water flow during installation.
- Carefully remove your existing showerhead by turning it counter-clockwise.

- Clean any old sealant or debris from the shower arm threads to ensure a proper seal.

Step-by-Step Installation

1. Wrap plumber's tape clockwise around the threads of your shower arm 3-4 times. This helps create a watertight seal.
2. Screw the Oxygenics Marvel handheld shower bracket onto the shower arm by hand until it is snug.
3. Tighten the bracket an additional quarter turn with an adjustable wrench, being careful not to overtighten, which could damage the threads.
4. Attach the shower hose to both the bracket and the handheld showerhead, ensuring that the rubber washers are properly seated in each connection. Hand-tighten these connections securely.
5. Place the handheld showerhead into its designated holder on the bracket.
6. Turn on the main water supply and carefully check all connections for any leaks. If leaks are present, tighten the connections slightly until they stop.

OPERATING INSTRUCTIONS

Your Oxygenics Marvel handheld shower features 6 distinct spray settings, allowing you to customize your showering experience to your preference.

Changing Spray Settings

To change the spray pattern, simply rotate the spray face of the handheld showerhead clockwise or counter-clockwise until the desired setting clicks firmly into place.

Available Spray Settings

- **Full Coverage Spray:** A wide, invigorating spray ideal for daily rinsing.
- **Massage Spray:** Concentrated, pulsating streams designed for muscle relaxation.
- **Mist Spray:** A fine, gentle mist for a soothing and calming experience.
- **Drench Spray:** A powerful, high-flow spray for quick rinsing.
- **Rinse Spray:** A focused, steady stream for targeted cleaning.
- **Combo Spray:** A combination of full coverage and massage for a dynamic shower.

The showerhead is designed for an efficiency of 2.5 Gallons Per Minute (GPM) at standard water pressure, providing a balance of performance and water conservation.



Image: A person holding the Oxygenics Marvel handheld showerhead, demonstrating its use with water spraying from both the handheld unit and a fixed showerhead, set against a wooden wall outdoors.

CARE AND MAINTENANCE

Regular cleaning is essential to ensure optimal performance and extend the life of your Oxygenics Marvel showerhead. Proper maintenance prevents mineral buildup and keeps the spray nozzles clear.

Cleaning the Showerhead

- To prevent mineral buildup, periodically wipe the rubber nozzles on the spray face with your finger or a soft cloth. This helps dislodge any deposits.
- For more stubborn mineral deposits, you may soak the showerhead in a solution of equal parts white vinegar and water for approximately 30 minutes.
- After soaking, thoroughly rinse the showerhead with clean water to remove any vinegar residue.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the chrome finish and the internal components of the showerhead.

TROUBLESHOOTING GUIDE

This section addresses common issues you might encounter with your Oxygenics Marvel handheld showerhead

and provides solutions.

Problem	Possible Cause	Solution
Low Water Pressure	Clogged nozzles or partially closed water supply.	Clean showerhead nozzles as described in the Maintenance section. Ensure the main water supply valve is fully open.
Leaking Connections	Loose connections or insufficient plumber's tape.	Tighten all connections securely. If leaks persist, reapply plumber's tape to the threads and reassemble.
Inconsistent Spray Pattern	Mineral buildup or debris in the spray nozzles.	Clean showerhead nozzles thoroughly as detailed in the Maintenance section.

PRODUCT SPECIFICATIONS

- **Brand:** Oxygenics
- **Model:** 55189
- **Material:** Chromium
- **Finish Type:** Polished
- **Color:** Silver
- **Number of Settings:** 6
- **Efficiency:** 2.5 GPM (Gallons Per Minute)
- **Item Weight:** 1.96 pounds
- **Product Dimensions:** 13.07 x 6.3 x 4.57 inches
- **UPC:** 010147551891

WARRANTY AND CUSTOMER SUPPORT

For specific warranty details, terms, and conditions related to your Oxygenics Marvel Chrome 6-Spray Handheld Shower, please refer to the documentation included with your product at the time of purchase. For additional customer support, technical assistance, or to inquire about replacement parts, please visit the official Oxygenics website or contact their customer service department directly.

Official Website: www.oxygenics.com