

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Foundations](#) /

› [Foundations Ultra Horizontal Wall Mounted Baby Diaper Changing Station \(Model 200-EH-04\) Instruction Manual](#)

Foundations 200-EH-04

Foundations Ultra Horizontal Wall Mounted Baby Diaper Changing Station

Model: 200-EH-04 | Brand: Foundations

1. SAFETY INFORMATION

WARNING: Failure to follow these instructions and warnings could result in serious injury or death. Always supervise children when using the changing station. Never leave a child unattended on the changing station. This product is intended for infants and toddlers up to 3.5 years of age and weighing up to 50 lbs (22.7 kg). The unit has been durability tested to 350 lbs (158.8 kg) for static load, but the recommended user weight limit is 50 lbs (22.7 kg).

- Ensure the changing station is securely mounted to a structural wall capable of supporting the unit and the child's weight.
- Always use the safety strap provided. Adjust the strap snugly around the child's waist.
- Keep all necessary changing supplies within reach before placing the child on the station to avoid leaving the child unattended.
- Be cautious of sharp edges and heavy components during installation and use.
- Do not use the changing station if it is damaged or broken. Contact customer service for replacement parts.
- Keep children away from the changing station during opening and closing to prevent pinching or crushing injuries.

2. PRODUCT OVERVIEW

The Foundations Ultra Horizontal Wall Mounted Baby Diaper Changing Station is designed for safe and convenient diaper changes in commercial and public environments. This unit features a durable construction, an oversized changing surface, and an easy-to-install design. It is engineered to meet the needs of architects, facility managers, and caregivers, combining aesthetic appeal with robust functionality.



Image: The Foundations Ultra Horizontal Wall Mounted Baby Diaper Changing Station in Metallic, shown in its open position, ready for use.



Image: The changing station installed in a contemporary public restroom, demonstrating its sleek, closed profile.

3. FEATURES

- **One-Person Installation:** The changing station includes all mounting hardware and an exclusive EZ Mount Backer Plate, designed to eliminate the need for structural blocking and allow for quick and efficient installation by a single person.
- **Durable Construction:** Engineered to exceed safety standards, this unit is durability tested to 350 lbs, surpassing the required ASTM 50 lb. weight rating. It features strong steel-to-steel hinges for lasting confidence and peace of mind.

Tough Where It Matters



Holds Up to 350 lbs.

Heavy-duty design
for dependable
daily use



Built For High Use

Sturdy steel on steel
hinge provides increased
strength and support

Image: A detailed view of the robust steel-to-steel hinge, highlighting the unit's durable construction.

- **Spacious Changing Surface:** Features a smooth interior and an extra-wide and deep changing surface constructed of hygienic polyethylene. This design provides ample room for the child and changing essentials, meeting all global safety standards.

Because Bigger Really is Better



The Largest Tray in Its Class

Extra-large tray provides more room
for baby and changing essentials.

Image: The extra-large changing tray, designed to provide more space for the child and changing supplies.

- **Adjustable Safety Strap:** A semi-permeable vinyl safety belt can be adjusted with one hand, offering ease of use and sanitization.

One-Hand Adjustments. Zero Hassle.



Easy to Adjust, Easier to Clean

The one-hand adjustable strap features a smooth, flat design that's easier to sanitize and more user-friendly than braided nylon straps.

Image: The easily adjustable safety strap, designed for one-hand operation and simple cleaning.

- **Integrated Bag Hooks and Liner Dispenser:** The unit includes disposable liner dispensers that sit flush with the frame, and two integrated bag hooks to keep diaper bags and purses off the floor and within reach.

EZ MOUNT BACKER PLATE REDUCES INSTALLATION
TIME AND ENABES CHANGING UNIT TO BE
ATTACHED TO THE WALL BY ONE INSTALLER



INTEGRATED HOOK GIVES
PARENTS A PLACE TO
HANG THEIR DIAPER BAG

Image: The integrated bag hooks and liner dispenser, providing convenience and hygiene during diaper changes.

- **Compact Design:** When closed, the changing station measures 37.5"W x 4"D x 21"H, offering a space-saving solution.

- **Aesthetic Options:** Available in five stylish color options to complement any decor, paired with a stainless steel placard featuring an identifiable international logo.

4. INSTALLATION (SETUP)

The Foundations Ultra changing station is designed for straightforward installation. The exclusive EZ Mount Backer Plate simplifies the process, allowing for one-person installation without the need for structural blocking. All necessary mounting hardware is included for common building substrates.

Installation Steps:

1. **Select Location:** Choose a suitable wall location that can support the unit's weight and the maximum intended load (up to 350 lbs durability tested, 50 lbs user weight). Ensure adequate clearance for opening and closing the unit.
2. **Mount Backer Plate:** Position the EZ Mount Backer Plate at the desired height and level. Mark the drilling points. Drill pilot holes as per the instructions provided with the mounting hardware. Secure the backer plate firmly to the wall using the supplied fasteners.



Image: An installer securing the EZ Mount Backer Plate to the wall, a key step for one-person installation.

3. **Attach Changing Unit:** Align the changing station with the mounted backer plate. Secure the changing unit to the backer plate using the remaining hardware. Ensure all screws are tightened to prevent movement.
4. **Test Stability:** After installation, thoroughly test the stability of the changing station by applying downward pressure. Ensure it is firmly attached to the wall and does not wobble.

Installation Video:

Your browser does not support the video tag.

Video: Official product video demonstrating the features and installation process of the Foundations Ultra Baby Changing Station.

5. OPERATION

Operating the Foundations Ultra changing station is simple and designed for user convenience.

Using the Changing Station:

1. **Open the Unit:** Gently pull down the front panel of the changing station until it is fully extended and locked into the horizontal position.
2. **Prepare for Change:** Retrieve a disposable liner from the integrated dispenser and place it on the changing surface. Ensure all necessary changing supplies (diapers, wipes, etc.) are within arm's reach.
3. **Place Child:** Carefully place the child onto the center of the changing surface.
4. **Secure Child:** Fasten the adjustable safety strap snugly around the child's waist. Always keep one hand on the child while changing.



SAFETY STRAP ADJUSTS WITH
ONE HAND AND COMPOSITE
MATERIAL IS EASY TO SANITIZE



Image: An adult securing a baby on the changing station using the adjustable safety strap, demonstrating proper use.

5. **Utilize Bag Hooks:** Hang diaper bags or personal items on the two integrated bag hooks to keep them off the floor and easily accessible.
6. **Close the Unit:** After the change, remove the child from the station. Dispose of the used liner and any waste. Gently push the changing surface upwards until it clicks securely into its closed, vertical position.

6. MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygienic condition of your Foundations Ultra changing station.

- **Cleaning:** Wipe all surfaces, especially the changing surface and safety strap, with a damp cloth and a mild, non-abrasive cleaner. The hygienic polyethylene surface is naturally bacteria-resistant.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical disinfectants, as these can damage the finish and material.
- **Inspect Regularly:** Periodically check all mounting hardware, hinges, and the safety strap for any signs of wear, damage, or looseness. Tighten any loose fasteners immediately.
- **Liner Dispenser:** Refill the disposable liner dispenser as needed.

7. TROUBLESHOOTING

If you encounter any issues with your changing station, refer to the following common troubleshooting tips:

- **Unit Does Not Open/Close Smoothly:** Check for any obstructions in the hinge mechanism or along the moving parts. Ensure the unit is clean and free of debris.

- **Unit Feels Unstable:** Re-check all mounting hardware to ensure it is securely fastened to the wall. If the issue persists, consult a qualified installer to verify the wall's structural integrity.
- **Safety Strap Issues:** If the safety strap is damaged or not functioning correctly, discontinue use immediately and contact customer service for a replacement.

For issues not resolved by these steps, please contact Foundations customer support.

8. SPECIFICATIONS

Specification	Detail
Model Number	200-EH-04
Dimensions (Closed)	37.5" L x 4" D x 21" H (95.25 cm L x 10.16 cm D x 53.34 cm H)
Item Weight	12 Kilograms (26.46 lbs)
Material Type	Metal (frame), Hygienic Polyethylene (changing surface)
Weight Capacity (User)	50 lbs (22.7 kg)
Durability Tested To	350 lbs (158.8 kg)
Required Assembly	Yes
Product Care Instructions	Wipe with Damp Cloth
Color	Metallic
UPC	849801010173

9. WARRANTY AND SUPPORT

The Foundations Ultra Horizontal Wall Mounted Baby Diaper Changing Station is backed by a **5-year limited warranty**. This warranty covers defects in materials and workmanship under normal use and service.

We've Got You Covered

5 Years
Limited
Warranty

**Made in
the USA**



Protection That Lasts

Backed by a 5-year limited warranty and responsive customer service—just call for fast replacement parts. Proudly made in the USA for quicker delivery and lasting support.

Image: Visual representation of the 5-year limited warranty and the 'Made in the USA' designation.

For warranty claims, replacement parts, or technical support, please contact Foundations customer service. Please have your model number (200-EH-04) and date of purchase available when contacting support.