

Himimi 000199

Himimi Universal Toilet Seat Instruction Manual

Model: 000199 | Brand: Himimi

1. INTRODUCTION

Thank you for choosing the Himimi Universal Toilet Seat. This manual provides essential information for the safe and correct installation, operation, and maintenance of your new toilet seat. Please read these instructions thoroughly before installation and retain them for future reference.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before installation.
- Do not overtighten screws during installation, as this may damage the product or toilet bowl.
- This toilet seat is designed for a maximum weight capacity of 170 kg. Do not exceed this limit.
- Keep small parts away from children to prevent choking hazards.
- Use only mild cleaning agents as specified in the maintenance section to avoid damaging the surface.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all the following items are included:

- 1 x Himimi Universal Toilet Seat (U-Shape, White)
- 2 x Double Mounting Kits (hinges, screws, expansion bolts, cover caps)
- 1 x Instruction Manual



Image: The Himimi Universal Toilet Seat shown with its complete set of mounting hardware and the instruction manual.

4. PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Himimi
Model Number	000199
Material	Plastic (Polyethylene)
Color	White
Shape	U-Shape
Product Dimensions (L x W x H)	45 cm x 36.1 cm x 2.51 cm (approx. 450 x 361 x 53 mm including hinges)
Hole Spacing	120 - 216 mm (adjustable)
Item Weight	1.8 Kilograms
Maximum Weight Capacity	170 Kilograms
Features	Quick Release, Antibacterial Surface, Soft Close Function, 360° Adjustable Hinges



Image: Detailed diagram illustrating the dimensions of the Himimi Universal Toilet Seat, including length, width, and hinge spacing.

5. SETUP AND INSTALLATION

The Himimi Universal Toilet Seat is designed for simple and quick installation. Please follow these steps:

1. **Prepare the Toilet Bowl:** Ensure the toilet bowl surface where the seat will be installed is clean and dry. Remove any old toilet seat and hardware.
2. **Insert Expansion Bolts:** Place the expansion bolts into the toilet bowl's mounting holes.
3. **Attach Hinges:** Position the hinges over the expansion bolts. The Himimi toilet seat features 360° adjustable hinges, allowing you to rotate them to align perfectly with your toilet's mounting holes (hole spacing 120-216mm).
4. **Secure Hinges:** Insert the screws through the hinges and into the expansion bolts. Tighten the screws until the hinges are firmly secured to the toilet bowl. Do not overtighten.
5. **Attach Toilet Seat:** Align the toilet seat with the secured hinges and press down firmly until it clicks into place. The quick-release mechanism ensures a secure fit.
6. **Cover Caps:** Place the decorative cover caps over the hinge bases for a clean finish.



Image: A visual guide demonstrating the three main steps for installing the toilet seat: preparing the seat, aligning the hinges, and securing the seat to the toilet bowl.



Image: Illustration showing the 360-degree adjustable hinges, allowing for precise alignment with various toilet bowl hole spacings.

6. OPERATING INSTRUCTIONS

The Himimi Universal Toilet Seat is designed for ease of use and comfort.

- **Soft Close Function:** The toilet seat and lid are equipped with a soft-close mechanism. This feature ensures that the seat and lid close slowly and quietly, preventing slamming and reducing noise. Gently push the seat or lid downwards, and it will close automatically.
- **Quick Release for Cleaning:** For thorough cleaning, the toilet seat can be easily removed. Locate the two quick-release buttons (often near the hinges) and press them to detach the seat from the mounting posts. Reattach by aligning and pressing down until it clicks.



Image: Close-up view of the quick-release buttons located on the toilet seat, enabling easy removal for cleaning.

7. MAINTENANCE

Proper maintenance will ensure the longevity and hygiene of your Himimi Universal Toilet Seat.

- **Regular Cleaning:** Clean the toilet seat regularly with a soft cloth and mild, non-abrasive soap or a dedicated toilet seat cleaner.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong acids, alkalis, or chlorine-based products, as these can damage the antibacterial surface and cause discoloration or corrosion of the hinges.
- **Drying:** After cleaning, wipe the seat dry with a clean, soft cloth to prevent water spots.
- **Hinge Care:** Periodically check the tightness of the hinge screws. If they become loose, gently tighten them to ensure stability.

8. TROUBLESHOOTING

If you encounter any issues with your Himimi Universal Toilet Seat, please refer to the following common solutions:

- **Seat is Loose:** Check if the hinge screws are securely tightened. If the seat still feels loose, ensure the expansion bolts are properly seated in the toilet bowl holes and the hinges are correctly aligned.
- **Soft Close Not Working:** Ensure the hinges are clean and free from debris. If the issue persists, the soft-close mechanism may be worn and require replacement.
- **Difficulty Removing Seat:** Ensure you are pressing both quick-release buttons simultaneously and firmly. If the

seat is new, it might require a bit more force initially.

- **Seat Discoloration:** This is often caused by using harsh cleaning chemicals. Refer to the maintenance section for recommended cleaning practices.

If these steps do not resolve your issue, please contact customer support.

9. WARRANTY AND SUPPORT

For warranty information, please refer to your purchase documentation or the retailer's website where the product was acquired. Himimi is committed to providing high-quality products and customer satisfaction.

For further assistance or inquiries, please contact Himimi customer support through the contact information provided with your purchase or on the official Himimi website.

© 2025 Himimi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question