

[Manuals.plus](#) /

› [ARMODD](#) /

› ARMODD Smartwatch User Manual

ARMODD cbccf4b6-dcf5-4687-80d8-9af46562e778

ARMODD Smartwatch User Manual

Model: cbccf4b6-dcf5-4687-80d8-9af46562e778

1. INTRODUCTION

Thank you for choosing the ARMODD Smartwatch. This elegant and functional device is designed to seamlessly integrate into your daily life, offering advanced health monitoring, activity tracking, and smart notifications. This manual provides essential information for setting up, operating, and maintaining your smartwatch to ensure optimal performance and longevity.



Figure 1.1: The ARMODD Smartwatch in gold, featuring a vibrant jellyfish watch face. This image showcases the elegant design and the full touchscreen display.

2. SAFETY INFORMATION

Please read the following safety guidelines carefully before using your ARMODD Smartwatch:

- Do not attempt to disassemble or modify the device.
- Keep the device away from extreme temperatures and direct sunlight.
- Avoid exposing the device to strong impacts or drops.
- Consult a medical professional before starting any new exercise regimen, especially if you have pre-existing health conditions.

- The heart rate and blood pressure measurements are for reference only and should not be used for medical diagnosis.
- Ensure the charging contacts are clean and dry before charging to prevent corrosion.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- ARMODD Smartwatch (Gold)
- Charging Cable (USB)
- User Manual (this document)

4. PRODUCT OVERVIEW

The ARMODD Smartwatch features a full touchscreen display and a durable stainless steel body. It is available in both gold and silver variants, crafted from high-quality steel and glass.

**EXTREM LANGE
AKULATUFZEIT**



bis 5 Tage
bei normalen Verbrauch

Figure 4.1: A close-up view of the ARMODD Smartwatch, highlighting the detailed craftsmanship of the gold casing and the vibrant display.



Figure 4.2: Both gold and silver variants of the ARMODD Smartwatch, demonstrating the refined style and material quality.

Key Components:

- **Touchscreen Display:** For all interactions and information display.
- **Heart Rate/Blood Pressure Sensor:** Located on the back of the watch for health monitoring.
- **Charging Contacts:** On the back for connecting the charging cable.
- **Magnetic Strap:** For secure and comfortable fit.

5. SETUP

5.1 Charging the Smartwatch

Before first use, fully charge your smartwatch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a power adapter (not included) or a computer USB port.

- A full charge typically takes 2-3 hours.
- The battery indicator on the screen will show charging progress.
- Under normal use, the watch can last up to 5 days on a single charge, with a standby time of up to 15 days.



Figure 5.1: The smartwatch display indicating a full 100% battery charge, demonstrating the long battery life.

5.2 App Installation and Pairing

To unlock the full potential of your ARMODD Smartwatch, you need to install the companion mobile application on your smartphone (compatible with 3G smartphones). The app allows for data synchronization, notification management, and watch face customization.

1. **Download the App:** Search for the official ARMODD companion app in your smartphone's app store (Google Play Store for Android, Apple App Store for iOS).
2. **Create Account:** Open the app and follow the on-screen instructions to create a new user account or log in if you already have one.
3. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
4. **Pair the Device:** In the app, navigate to the "Device" or "Add Device" section. The app will search for nearby smartwatches. Select your ARMODD Smartwatch from the list (it may appear as "ARMODD" or a similar name).
5. **Confirm Pairing:** A pairing request may appear on both your phone and the watch. Confirm the pairing on both devices.
6. **Initial Synchronization:** Once paired, the watch will synchronize time, date, and other settings with your phone.

6. OPERATING THE SMARTWATCH

6.1 Basic Navigation

The ARMODD Smartwatch features a full touchscreen for intuitive navigation:

- **Swipe Up/Down:** To scroll through menus or notifications.
- **Swipe Left/Right:** To access different functions or widgets (e.g., activity data, heart rate).
- **Tap:** To select an item or confirm an action.
- **Press and Hold:** On the main watch face to change watch faces.



Figure 6.1: The smartwatch displaying a butterfly watch face, illustrating the customization options available through the touchscreen.

6.2 Smart Notifications

Once paired with your smartphone, the smartwatch will alert you to incoming calls, SMS messages, and notifications from other applications (e.g., social media, email). You can manage which notifications appear on your watch through the companion app settings.

6.3 Activity Tracking

The smartwatch automatically tracks your daily activities, including steps taken, distance covered, and calories burned. This data can be viewed directly on the watch or in more detail within the companion app.



Figure 6.2: The ARMODD Smartwatch is designed to assist in improving fitness and health, tracking activities during exercise.

6.4 Sleep Monitoring

Wear your smartwatch to bed to monitor your sleep patterns. The watch records sleep duration and quality, providing insights into your sleep health through the app.

6.5 Heart Rate and Blood Pressure Measurement

The advanced sensor on the smartwatch can measure your current heart rate and blood pressure. To take a measurement, ensure the watch is snugly fitted on your wrist and navigate to the respective function on the watch. Remain still during the measurement for accurate results.

Note: These measurements are for general fitness and wellness purposes only and are not intended for medical use or diagnosis.

6.6 Customization

Personalize your smartwatch experience by changing watch faces. You can select from pre-installed faces by pressing and holding the main screen, or download more options via the companion app.



Figure 6.3: The smartwatch displaying an elegant floral watch face, showcasing the variety of available designs.

7. MAINTENANCE

7.1 Cleaning

To keep your smartwatch in optimal condition:

- Wipe the screen and body with a soft, lint-free cloth.
- For stubborn stains, dampen the cloth slightly with water.
- Avoid using harsh chemicals or abrasive materials.
- Regularly clean the charging contacts to ensure proper connection.

7.2 Water Resistance (IP68)

The ARMODD Smartwatch is IP68 water-resistant, meaning it is protected against dust ingress and can withstand

immersion in water up to 1.5 meters for up to 30 minutes. While it is resistant to splashes, rain, and brief immersion, it is not recommended for swimming, diving, or hot showers/saunas as steam and hot water can compromise the seals.

7.3 Battery Care

- Avoid fully discharging the battery frequently.
- Charge the watch regularly, even if not in constant use, to maintain battery health.
- Store the watch in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

If you encounter issues with your ARMODD Smartwatch, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Watch not turning on	Low battery; device frozen.	Charge the watch for at least 30 minutes. If still unresponsive, try a forced restart (refer to specific model instructions if available, otherwise, let battery drain and recharge).
Cannot pair with phone	Bluetooth off; app issue; watch not discoverable.	Ensure Bluetooth is on for both devices. Restart both the watch and phone. Clear app cache/data or reinstall the app. Make sure the watch is in pairing mode.
Notifications not appearing	App permissions; notification settings.	Check app notification permissions on your phone. Verify notification settings within the ARMODD companion app. Ensure the watch is connected to the phone.
Inaccurate health data	Improper fit; sensor obstruction.	Ensure the watch is snugly fitted on your wrist, not too loose or too tight. Clean the sensor on the back of the watch. Avoid movement during measurements.
Short battery life	Frequent use of power-intensive features; too many notifications.	Reduce screen brightness. Limit background app refresh. Disable unnecessary notifications. Charge fully before use.

If the problem persists, please contact ARMODD customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	ARMODD
Model Number	cbccf4b6-dcf5-4687-80d8-9af46562e778
ASIN	B086X56KFB
Memory Storage Capacity	1 GB
Digital Memory Capacity	1 GB

Feature	Detail
Operating System	Symbian
Compatible Devices	3G-smartphones
Special Features	Activity Tracker, Notifications, Sleep Monitor
Display Type	OLED
Wireless Type	Bluetooth
Mobile Technology	HSDPA
Input Device	Touchscreen
Package Dimensions	10.92 x 8.64 x 6.35 cm; 160 g
First Available Date	January 15, 2020
Water Resistance	IP68
Shape	Round
Color	Gold (also available in Silver)
Target Audience	Women
Battery Life (Normal Use)	Up to 5 days
Standby Time	Up to 15 days

10. WARRANTY AND SUPPORT

ARMODD products are designed for quality and reliability. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official ARMODD website. Please have your model number (cbccf4b6-dcf5-4687-80d8-9af46562e778) and ASIN (B086X56KFB) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question