

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [JODSONE](#) /

› [JODSONE UV LED Nail Lamp \(Model X5M-LAMP\) Instruction Manual](#)

JODSONE X5M-LAMP

JODSONE UV LED Nail Lamp (Model X5M-LAMP) Instruction Manual

Brand: JODSONE | Model: X5M-LAMP

1. INTRODUCTION

This instruction manual provides comprehensive guidance for the safe and effective operation of your JODSONE UV LED Nail Lamp, Model X5M-LAMP. This device is designed for professional and home use to cure various types of gel nail polishes, including UV gels, LED gels, hard gels, and sculpture gels. Please read this manual thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Keep out of the reach of children.
- Do not look directly into the UV/LED light when the lamp is operating. Prolonged exposure may cause eye damage.
- Do not use this appliance near water or in wet environments.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been dropped or damaged. Contact customer service for repair.
- Use this appliance only for its intended use as described in this manual.
- Do not insert any object into any opening.
- Keep the cord away from heated surfaces.
- Ensure proper ventilation during use.

3. PRODUCT FEATURES

The JODSONE UV LED Nail Lamp is equipped with advanced features for efficient and convenient gel nail

curing:

- **Dual UV/LED Light Source:** Features 24 strategically placed UV+LED lamp beads for comprehensive and fast curing of all gel types without dead spots.
- **Automatic Sensor:** Equipped with an intelligent infrared sensor that automatically turns the lamp on when hands or feet are inserted and off when removed.
- **Multiple Timer Settings:** Four preset timer options (30s, 60s, 90s, 120s) to accommodate different gel types and curing requirements.
- **LCD Display:** A clear digital display shows the selected curing time countdown.
- **Detachable Base:** The magnetic detachable base allows for easy cleaning and convenient use for both manicures and pedicures.
- **Wide Compatibility:** Effectively cures UV gel, LED gel, acrylic gel, hard gel extension, sculpture gel, gem glue, and more.



Figure 3.1: Overview of the JODSONE UV LED Nail Lamp in Milky White.

4. SETUP

1. **Unpack:** Carefully remove the nail lamp and all accessories from the packaging.

2. **Inspect:** Check the device for any signs of damage. If damaged, do not use and contact customer service.
3. **Placement:** Place the nail lamp on a stable, flat, and dry surface. Ensure there is adequate space around the device for ventilation.
4. **Connect Power:** Insert the power adapter into the DC input port on the back of the lamp. Plug the power adapter into a suitable electrical outlet. The LCD display will illuminate briefly, indicating the device is ready.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

The lamp powers on automatically when plugged in. To turn off, simply unplug the power adapter. The lamp will enter standby mode when not in use.

5.2 Using the Automatic Sensor

The JODSONE nail lamp features an intelligent infrared sensor for hands-free operation:

- Simply place your hand or foot into the lamp opening. The sensor will detect its presence, and the UV/LED lights will automatically turn on.
- The default curing time when using the automatic sensor without pressing a timer button is 120 seconds (low heat mode).
- Remove your hand or foot from the lamp, and the lights will automatically turn off.



Figure 5.1: Illustration of the Smart Auto Sensor in operation, showing the lamp activating when a hand is inserted and deactivating when removed.

5.3 Selecting Timer Settings

For specific curing times, use the timer buttons located on the top of the lamp:

- **30s:** Press the "30s" button for 30 seconds of curing. Ideal for thin gel polish or regular colors.
- **60s:** Press the "60s" button for 60 seconds of curing. Suitable for darker colors or standard gel applications.
- **90s:** Press the "90s" button for 90 seconds of curing. Recommended for thicker gel polish layers.
- **120s (Low Heat Mode):** Press the "120s" button for 120 seconds of curing. This mode gradually increases power to minimize heat spikes, providing a more comfortable experience for sensitive nails or specific gel types.

Once a timer button is pressed, the lamp will start, and the LCD display will show a countdown. The lamp will automatically turn off when the selected time expires.

Advanced Touch Screen Comes In Four Modes And An LCD Display



Figure 5.2: Close-up of the control panel showing the LCD display and the 30s, 60s, 90s, and 120s timer buttons.

5.4 Curing Process

1. Apply a thin, even layer of gel polish to your nails according to the gel manufacturer's instructions.
2. Place your hand or foot fully into the lamp. Ensure all nails are positioned directly under the UV/LED beads for even curing.
3. Select the appropriate timer setting (30s, 60s, 90s, or 120s) or allow the automatic sensor to activate for 120s.
4. Once the curing cycle is complete, remove your hand or foot.
5. Repeat for subsequent layers of gel polish (base coat, color coats, top coat) as required.

Curing All Gel Polish

Include UV Nail Gel, Led Gel, Acrylic Gel, Hard Gel Extension, Etc



Figure 5.3: The JODSONE lamp is compatible with a wide range of nail gels, including UV gel, LED gel, acrylic gel, and hard gel extensions.

5.5 Using the Detachable Base for Pedicures

The magnetic detachable base allows for easy conversion for pedicure use:

- Gently pull the bottom plate of the lamp to detach it from the main body.
- Place the main body of the lamp over your foot for comfortable pedicure curing.
- After use, reattach the base by aligning it with the magnets and pushing it back into place.

Detachable Base Design

Larger and more practical space after disassembly



Figure 5.4: The detachable base design provides flexibility for both manicure and pedicure applications.

6. MAINTENANCE

- **Cleaning:** Always unplug the device before cleaning. Use a soft, dry cloth to wipe the exterior of the lamp. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lamp in a cool, dry place away from direct sunlight and moisture when not in use.
- **Lamp Beads:** The UV/LED lamp beads are designed for long-term use and generally do not require replacement. Avoid touching them directly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Power adapter not connected or faulty outlet.	Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet. Try a different outlet.

Problem	Possible Cause	Solution
Gel polish is not curing properly.	Incorrect curing time, too thick gel layer, or incompatible gel type.	<p>Ensure you are using the correct curing time for your specific gel polish (refer to gel manufacturer's instructions).</p> <p>Apply gel in thin, even layers.</p> <p>Verify that your gel polish is compatible with UV/LED lamps.</p> <p>Ensure your hand/foot is fully inserted and all nails are under the lights.</p>
Automatic sensor not working.	Obstruction or improper hand placement.	Ensure there is no obstruction blocking the sensor. Place your hand/foot fully into the lamp opening.
Lamp feels hot during use.	Normal operation or prolonged use.	<p>A slight warmth is normal. If the lamp becomes excessively hot, discontinue use and allow it to cool down.</p> <p>Ensure proper ventilation.</p>

8. SPECIFICATIONS

Feature	Detail
Model Number	X5M-LAMP
Light Source	UV + LED Dual Light Source (24 beads)
Timer Settings	30s, 60s, 90s, 120s (Low Heat Mode)
Display	LCD Digital Display
Sensor	Automatic Infrared Sensor
Product Dimensions	9.06 x 9.06 x 3.94 inches (L x W x H)
Item Weight	0.4 Kilograms (14.11 ounces)
Material	Plastic
Color	Milky White
Manufacturer	JODSONE
UPC/GTIN	673169579948



24 UV/LED Beads Coverage

Fast curing with no dead spots in all directions

Figure 8.1: Internal view of the lamp showing the 24 UV/LED dual light source beads for efficient curing.

9. WARRANTY AND SUPPORT

JODSONE is committed to providing quality products and customer satisfaction. If you encounter any issues or have questions regarding your JODSONE UV LED Nail Lamp, please contact JODSONE customer service. We aim to respond to all inquiries within 24 hours.

For support, please visit the official JODSONE store on Amazon or refer to the contact information provided with your product packaging.

Please retain your purchase receipt for warranty purposes.