

HLS COMMERCIAL Automatic Sanitizer Dispenser with Floor Stand

HLS COMMERCIAL Automatic Sanitizer Dispenser with Floor
Stand User Manual

Model: Automatic Sanitizer Dispenser with Floor Stand

INTRODUCTION

This manual provides comprehensive instructions for the HLS COMMERCIAL Automatic Sanitizer Dispenser with Floor Stand. Designed for high-traffic areas, this touchless, sensor-activated dispenser offers a hygienic solution for hand sanitization. It is compatible with various sanitizer types, including gel, liquid, and alcohol. Please read this manual thoroughly before installation and operation to ensure proper use and maintenance.

PRODUCT FEATURES

- **Touchless Operation:** 100% sensor-activated for hygienic use, minimizing contact.
- **Versatile Compatibility:** Accommodates sanitizer gel, liquid, or alcohol.
- **Large Capacity:** 1000 ml reservoir reduces the frequency of refills.
- **Freestanding Design:** Includes a sturdy floor stand for easy placement in various locations.
- **Integrated Sign Board:** Removable sign board for displaying important messages or instructions.
- **Battery Operated:** Powered by 4 C-size batteries (not included) for cordless operation.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Automatic Sanitizer Dispenser Unit (1)
- Floor Stand (Base, Pole, Dispenser Mounting Plate) (1 set)
- Removable Sign Board (1)
- Mounting Hardware (Screws, Wall Anchors - for optional wall mounting)
- Instruction Manual (This document)

Note: 4 C-size batteries are required for operation and are not included in the package.

SETUP INSTRUCTIONS

1. Assemble the Floor Stand:

- Attach the pole to the heavy base using the provided screws. Ensure it is securely tightened.
- Mount the dispenser mounting plate to the top of the pole.

2. Install Batteries:

- Open the battery compartment located on the back or top of the dispenser unit.
- Insert 4 new C-size batteries, ensuring correct polarity (+/-).
- Close the battery compartment securely.

3. Fill the Dispenser:

- Open the dispenser's top cover or reservoir access point.
- Carefully pour your chosen hand sanitizer (gel, liquid, or alcohol) into the reservoir, up to the maximum fill line. Do not overfill.
- Close the cover securely to prevent leaks and contamination.

4. Mount the Dispenser:

- Align the dispenser unit with the mounting plate on the floor stand.
- Secure the dispenser to the plate using the designated screws or locking mechanism.

5. Attach the Sign Board:

- Slide the sign board into the designated slot above the dispenser unit.
- Ensure it is firmly in place. You may customize the message on the sign board if desired.



Image 1: The HLS COMMERCIAL Automatic Sanitizer Dispenser with Floor Stand. The image shows the full assembly on the left, and a close-up on the right demonstrating the touchless dispensing of sanitizer into a hand.

OPERATING INSTRUCTIONS

1. **Power On:** Ensure batteries are installed and the dispenser is properly assembled. The unit should be ready for use.

2. Dispensing Sanitizer:

- Place your hand flat beneath the dispenser nozzle.

- The infrared sensor will detect your hand and automatically dispense a measured amount of sanitizer.
- Remove your hand once sanitizer is dispensed.

3. **First Use / Priming:** For the first use or after refilling, you may need to activate the sensor a few times to prime the pump and ensure sanitizer flows smoothly.

MAINTENANCE

• Cleaning:

- Wipe the exterior of the dispenser and stand with a soft, damp cloth.
- Do not use abrasive cleaners or immerse the unit in water.
- Regularly clean the sensor window to ensure proper operation.

• Refilling:

- Monitor the sanitizer level through the transparent window (if available) or by opening the reservoir.
- Refill as per the "Fill the Dispenser" step in the Setup Instructions.

• Battery Replacement:

- When the dispenser's performance diminishes or the indicator light (if present) signals low battery, replace all 4 C-size batteries simultaneously.
- Follow the "Install Batteries" step in the Setup Instructions.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dispenser not working / No sanitizer dispensed.	• Low or dead batteries. • Sanitizer reservoir is empty. • Sensor is obstructed or dirty. • Sanitizer is too thick or clogged.	• Replace with new C-size batteries. • Refill the dispenser with sanitizer. • Clean the sensor window with a soft cloth. • Ensure appropriate sanitizer consistency. Clear any clogs from the nozzle.
Sanitizer leaks from the nozzle.	• Reservoir cap not sealed properly. • Dispenser unit not seated correctly.	• Ensure the reservoir cap is tightly closed. • Re-seat the dispenser unit firmly onto its mounting plate.
Sensor is overly sensitive or not sensitive enough.	• Environmental factors (e.g., strong light). • Sensor dirty.	• Relocate the dispenser if possible, or clean the sensor. • Clean the sensor window.

SPECIFICATIONS

Brand	HLS COMMERCIAL
Model	Automatic Sanitizer Dispenser with Floor Stand
Capacity	1000 Milliliters
Material	Metal, Plastic
Color	White
Power Source	4 x C-size Batteries (not included)
Item Weight	14 pounds
Package Dimensions	14.2 x 13.4 x 7.5 inches
UPC	814839025376

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided at the point of purchase or visit the official HLS COMMERCIAL website. Keep your purchase receipt as proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08C7867MV>

More documents and user manuals: <https://manuals.plus/>