

## OTO HS-900V

# OTO Handy Spa HS-900V Wireless Back Massager User Manual

### IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the OTO Handy Spa HS-900V Wireless Back Massager. Retain this manual for future reference.

- Consult your physician before using this product if you have any medical conditions, are pregnant, or have a pacemaker.
- This device is for personal, non-medical use only. Do not use it as a substitute for medical treatment.
- Do not use the massager in wet environments or near water.
- Keep out of reach of children.
- Do not disassemble, modify, or attempt to repair the device yourself. Contact authorized service personnel for assistance.
- Unplug the device when not in use or during cleaning.
- Avoid prolonged use on a single area to prevent discomfort or skin irritation.
- Do not use on swollen, inflamed, or injured skin areas.

### PRODUCT OVERVIEW

The OTO Handy Spa HS-900V is a wireless, rechargeable massager designed for targeted relief on the back and neck. It features deep-kneading massage nodes with optional soothing heat therapy, an ergonomic design, and a convenient auto-timer function.



Figure 1: The OTO Handy Spa HS-900V massager, showcasing its four illuminated red massage nodes and power button.

### Key Features:

- **Wireless & Rechargeable:** Provides convenience and portability.
- **Deep Kneading Massage:** Features forward and backward rotation for effective muscle relief.
- **Soothing Heat Therapy:** Optional heat function at approximately 36 degrees Celsius to enhance relaxation.
- **15-Minute Auto-Timer:** Automatically shuts off after 15 minutes to prevent overuse.
- **Ergonomic Design:** Contours to the body for comfortable and effective application on various areas.
- **Multi-Application:** Suitable for use on the back, neck, and other areas requiring massage.

### PACKAGE CONTENTS

- 1 x OTO Handy Spa HS-900V Massager Unit
- 1 x Charging Cable
- 1 x User Manual

## SETUP

---

### Charging the Device

Before first use, fully charge the massager. The device is battery-powered and rechargeable.

1. Locate the charging port on the side of the massager.
2. Connect the provided charging cable to the massager and a suitable power adapter (not included) or USB port.
3. The charging indicator light will illuminate (color may vary) to show that the device is charging.
4. Once fully charged, the indicator light will change or turn off. Disconnect the charger.

### Positioning the Massager

The ergonomic design allows for versatile placement. Position the massager comfortably on the desired area of your body, such as your lower back, upper back, or neck.



Figure 2: Side profile of the OTO Handy Spa HS-900V massager, illustrating its contoured shape for body placement.

The massager may include an adjustable strap on the back for securing it to a chair or car seat (check for strap presence on your model).





Figure 3: Back view of the OTO Handy Spa HS-900V massager, showing the integrated securing strap.

## OPERATING INSTRUCTIONS

The OTO Handy Spa HS-900V features a simple one-button operation for ease of use.



Figure 4: Top view of the OTO Handy Spa HS-900V massager, highlighting the power/mode button.

Power On/Off and Mode Selection

1. **Power On & Initial Mode:** Press the power button once to turn on the massager. It will typically start with a default kneading direction and heat function activated.
2. **Change Kneading Direction:** Press the power button a second time to reverse the kneading direction.
3. **Deactivate Heat:** Press the power button a third time to turn off the heat function while the massage continues.
4. **Power Off:** Press the power button a fourth time to turn off the massager completely.

Auto-Timer Function

For your safety and to prevent overuse, the OTO Handy Spa HS-900V is equipped with a 15-minute auto-timer. The device will automatically shut off after approximately 15 minutes of continuous operation. If you wish to continue your massage, simply press the power button again to restart the cycle.

MAINTENANCE AND CARE

Cleaning

- Ensure the massager is turned off and unplugged before cleaning.
- Wipe the surface of the massager with a soft, slightly damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the device.
- Do not immerse the massager in water or any other liquid.
- Allow the massager to air dry completely before storing or next use.

Storage

- Store the massager in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on top of the massager.
- Keep the charging cable neatly coiled to prevent damage.

TROUBLESHOOTING

If you encounter any issues with your OTO Handy Spa HS-900V, please refer to the following table before contacting customer support.

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided cable.
	Power button not pressed correctly.	Ensure a firm press on the power button.

Problem	Possible Cause	Solution
No heat is felt.	Heat function is not activated.	Press the power button until the heat function is active (refer to Operating Instructions). Allow a few minutes for heat to build.
Massage feels weak or ineffective.	Improper positioning.	Adjust the massager's position to ensure the massage nodes are making proper contact with the desired area.
Device stops unexpectedly.	15-minute auto-timer activated.	This is normal operation. Press the power button to restart the massage cycle.
	Low battery.	Charge the device.






## SPECIFICATIONS

Feature	Detail
Model	HS-900V
Brand	OTO
Power Source	Battery Powered (Rechargeable)
Special Features	Rechargeable, Wireless, Heat Therapy, Auto-Timer
Massage Form	Massage Pillow
Recommended Use Areas	Back, Neck
Auto-Timer Duration	15 minutes
Heat Therapy Temperature	Approximately 36 degrees Celsius
Approximate Package Dimensions	39 x 33.5 x 5 cm

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or contact OTO customer service directly. Contact details can typically be found on the official OTO website or product packaging.

## Related Documents - HS-900V

	<p><a href="#">OTO Readi-Spa RS-1000 Wireless Back Massager User Manual</a></p> <p>User manual for the OTO Readi-Spa RS-1000 Wireless Back Massager, covering safety precautions, operation, care, troubleshooting, and specifications.</p>
	<p><a href="#">OTO Ultra Back UB-68: Your Comprehensive User Manual</a></p> <p>Comprehensive user manual for the OTO Ultra Back UB-68 back massager, detailing features, operation, safety, and maintenance for optimal use and relaxation.</p>
	<p><a href="#">OTO Ultra Foot Plus UF-838 User Manual - Foot Massager</a></p> <p>Comprehensive user manual for the OTO Ultra Foot Plus UF-838 foot massager, covering safety precautions, operation, troubleshooting, care, and specifications.</p>
	<p><a href="#">OTO Ultra Foot UF-830 User Manual: Safety, Operation, and Maintenance</a></p> <p>Comprehensive user manual for the OTO Ultra Foot UF-830 foot massager. Learn about safety precautions, how to operate the device, troubleshooting common issues, care and maintenance tips, and detailed product specifications.</p>
	<p><a href="#">OtO Smart Lawn Sprinkler: Getting Started Guide and Installation</a></p> <p>Comprehensive guide to installing and setting up your OtO Smart Lawn Sprinkler, covering setup, Wi-Fi connection, zone creation, troubleshooting, and maintenance. Learn how to optimize your lawn watering.</p>
	<p><a href="#">OTO Prestige PE-09</a></p> <p>OTO Prestige PE-09</p>