

Recaro 00089020300080

Recaro Salia Elite Newborn Child Seat ISOFIX R129 Rotary Travel System Instruction Manual

1. INTRODUCTION AND OVERVIEW

This instruction manual provides essential information for the safe and proper use of your Recaro Salia Elite Newborn Child Seat. Please read this manual thoroughly before installation and use, and keep it in a safe place for future reference.

The Recaro Salia Elite is an ISOFIX 360° rotating child seat that meets the latest R129 safety standard. It features a unique design that includes a detachable baby carrier, allowing for seamless integration into a travel system with compatible strollers and docking stations (a dedicated adapter set is required for docking). Key safety features include side protection to mitigate impacts from the side, and a central indicator system that visually confirms correct ISOFIX attachment, support leg deployment, and rotation operation by turning green. The horizontal lever ensures easy rotation of the seat, even with a child already placed inside. Its seat-type design is engineered to distribute impact across the entire back in the event of a collision, providing enhanced protection for your baby. The head support and shoulder belt are linked, enabling simple height adjustment with a single lever pull.

2. KEY FEATURES

- **R129 Safety Standard:** Complies with the latest European safety regulations for enhanced child protection.
- **ISOFIX Installation:** Ensures secure and stable attachment to your vehicle's ISOFIX anchor points.
- **360° Rotation:** Allows for easy access to your child and effortless switching between rear-facing and forward-facing positions.
- **Integrated Travel System:** Includes a detachable baby carrier for use with compatible strollers and docking stations (adapter sold separately).
- **Advanced Side Impact Protection:** Designed to absorb and disperse energy from side collisions.
- **Visual Installation Indicators:** Green indicators confirm correct installation of ISOFIX, support leg, and rotation.
- **Linked Headrest & Harness Adjustment:** Simplifies adjusting the seat to your child's growing height.

- **Suitable from Birth:** Designed for newborns (0 months and up) with appropriate inserts.

3. SETUP AND INSTALLATION

3.1 Installing the Base and Seat

1. Position the child seat on the vehicle seat. Ensure the vehicle is parked on a level surface.
2. Extend the ISOFIX connectors from the base of the child seat. Align them with the ISOFIX anchor points in your vehicle. Push the seat firmly until the connectors click into place and the indicators turn green.
3. Extend the support leg until it firmly touches the vehicle floor. The indicator on the support leg should also turn green, confirming correct deployment.
4. Verify all indicators are green to ensure a secure installation.

3.2 Adjusting Recline and Rotation

1. To recline the seat, locate the recline adjustment lever (refer to product images for location) and adjust to the desired position.
2. To rotate the seat, pull the rotation lever (located horizontally on the base) and turn the seat to the desired orientation (rear-facing or forward-facing). Release the lever to lock the seat in place.

4. OPERATING INSTRUCTIONS

4.1 Securing Your Child (Rear-Facing for Newborns)

1. Ensure the seat is in the fully reclined, rear-facing position for newborns.
2. Place your child gently into the seat, ensuring their back is flat against the seatback.
3. Fasten the 5-point harness. Insert both buckle tongues into the buckle until they click securely.
4. Tighten the harness straps so they are snug against your child's body, with no slack. Ensure the chest clip is at armpit level.
5. Adjust the headrest and shoulder straps simultaneously by pulling the adjustment lever at the top of the seat to ensure they are at the correct height for your child.

4.2 Transitioning to Forward-Facing (for older children)

The Recaro Salia Elite can be used forward-facing once your child meets the minimum height and weight requirements specified by the R129 standard (typically around 15 months and 76 cm tall, but always refer to the specific labels on your seat and local regulations).

1. Rotate the seat to the forward-facing position using the rotation lever.
2. Adjust the recline to an appropriate upright position for forward-facing use.
3. Secure your child using the 5-point harness as described above.

5. MAINTENANCE

5.1 Cleaning Instructions

- **Fabric Covers:** The fabric covers are removable and machine washable. Please refer to the care label on the covers for specific washing instructions (e.g., temperature, detergent).
- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.

- **Harness System:** Wipe the harness straps with a damp cloth. Do not machine wash or tumble dry the harness straps, as this may weaken them.

5.2 Inspection

Regularly inspect the child seat for any signs of wear, damage, or loose parts. Pay close attention to the harness straps, buckles, ISOFIX connectors, and support leg. If any damage is found, discontinue use and contact customer support.

6. TROUBLESHOOTING

- **ISOFIX Indicators Not Green:** Ensure the ISOFIX connectors are fully engaged with the vehicle's anchor points. Push the seat firmly against the vehicle seatback. Check that the support leg is correctly extended and locked.
- **Seat Not Rotating:** Ensure the rotation lever is fully pulled before attempting to rotate the seat. Check for any obstructions around the base.
- **Harness Too Loose/Tight:** Adjust the harness straps using the central adjustment mechanism. Ensure the headrest and shoulder straps are at the correct height for your child.
- **Child Appears Uncomfortable:** Recheck the recline angle, harness tension, and headrest height. Ensure all infant inserts are correctly positioned for smaller babies.

If you encounter any issues not covered here, please refer to the full product manual or contact Recaro customer support.

7. SPECIFICATIONS

Product Model Number	00089020300080
Package Dimensions	83 x 76 x 47 cm
Product Weight	22.6 kg
Gender	Unisex
Recommended Max. Weight	18 kg
Recommended Min. Height	40 cm
Recommended Max. Height	105 cm
Batteries Required	No
Harness Type	5-point
Safety Standard	R129
Installation Type	ISOFIX
Color	Black
Orientation	Forward-facing, Rear-facing
Target Age	0 months ~

8. WARRANTY AND SUPPORT

For warranty information, after-sales support, or any product-related inquiries, please contact Recaro customer service or the retailer from whom you purchased the product. Keep your proof of purchase for warranty claims.

9. VISUAL AIDS



Figure 1: Recaro Salia Elite child seat in a reclined, rear-facing position, showing the side profile and support leg.



Figure 2: Front view of the Recaro Salia Elite child seat in a reclined position, highlighting the harness system and infant padding.



Figure 3: Side view of the Recaro Salia Elite child seat in an upright, forward-facing position.



Figure 4: The Recaro Salia Elite child seat separated from its ISOFIX base, illustrating the modular design.



Figure 5: A close-up view of the detachable baby carrier component of the Recaro Salia Elite.



Figure 6: The Recaro Salia Elite baby carrier attached to a compatible stroller frame, demonstrating its travel system functionality.



Figure 7: The infant insert and head support components, designed for comfort and safety of newborns.



Figure 8: A comprehensive view of the Recaro Salia Elite child seat in an upright position, ready for use.

9.2 Official Product Videos

No official product videos directly related to the Recaro Salia Elite model were found from the brand's seller account. Please refer to the images and written instructions for guidance.