

Fisher-Price Sterilizer

Fisher-Price Steam Sterilizer User Manual

Model: Sterilizer

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Fisher-Price Steam Sterilizer. Please read all instructions carefully before operating the appliance and retain this manual for future reference. This steam sterilizer is designed to sanitize baby bottles and accessories using high-temperature steam, ensuring a hygienic environment for your baby's essentials.

Important Safety Information:

- Always keep the appliance out of reach of children.
- Do not immerse the main unit in water or other liquids.
- Use only distilled or purified water to prevent mineral buildup on the heating plate.
- Exercise caution when handling hot steam and sterilized items. Use the provided tongs.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- The product is made from food-grade, high-temperature resistant, fluorescent-free, and BPA-free materials.

2. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Fisher-Price Steam Sterilizer:

- **Main Unit:** Contains the heating element and control dial.
- **Disinfection Holder (Large Cabinet):** For sterilizing up to 6 baby bottles.
- **Nipple/Teeth/Teethers Holder (Small Cabinet):** For sterilizing smaller accessories.

- **Top Cover Handle:** For safe removal of the lid.
- **Tongs:** To safely handle hot, sterilized items.



*Bottles and nipples are only for illustration purpose. They are not part of the standard product.

Image: Overview of the Fisher-Price Steam Sterilizer components, showing the main unit, large bottle basket, small accessory tray, lid, and tongs.

Your browser does not support the video tag.

Video: This video demonstrates the assembly of the Fisher-Price Steam Sterilizer, showing how to place the disinfection holder and nipple/teether holder, and how to add water to the main unit. It also highlights the one-dial control and auto shut-off feature.

3. SETUP INSTRUCTIONS

Follow these steps to set up your sterilizer:

1. **Prepare the Main Unit:** Place the main unit on a clean, flat, and heat-resistant surface.
2. **Add Water:** Pour exactly 100ml of purified or distilled water onto the heating plate of the main unit. Using

the correct amount of water is crucial for effective sterilization and to prevent dry heating.

3. Load Items:

- For bottles: Place the large disinfection holder (cabinet) onto the main unit. Invert clean bottles over the bottle pegs.
- For accessories: Place the small nipple/teether holder (cabinet) onto the main unit. Arrange nipples, pacifiers, teethers, or other small accessories.
- You can also use both cabinets together for a combination of bottles and accessories.

4. Secure the Lid: Place the transparent lid securely over the loaded cabinets.



Image: The sterilizer loaded with 6 bottles and various accessories, demonstrating its large capacity and flexible stacking options.

4. OPERATING INSTRUCTIONS

The Fisher-Price Steam Sterilizer features a simple one-dial control for ease of use:

1. **Connect to Power:** Plug the sterilizer into a suitable power outlet.
2. **Select Sterilization Time:** Rotate the control dial to your desired sterilization duration. The dial typically has settings like 'MAX', '9', and '12' (representing minutes or cycles). Select the appropriate setting based on the items being sterilized and desired intensity.
3. **Start Sterilization:** The sterilization process will begin automatically once the dial is set. Steam will be generated to sanitize the contents.
4. **Automatic Shut-Off:** The sterilizer is equipped with an auto shut-off feature. If the machine runs out of water during sterilization, it will automatically switch off to prevent dry heating and ensure safety.
5. **Completion:** Once the cycle is complete, the appliance will turn off. Allow the unit to cool down before

opening the lid.

6. **Remove Items:** Carefully remove the lid and use the provided tongs to retrieve the sterilized items. Be aware of residual steam and hot surfaces.



One-Dial Operation : Just rotate the knob to select Sterilization time

Image: A close-up view of the one-dial operation, indicating how to rotate the knob to select the sterilization time.

Your browser does not support the video tag.

Video: This video demonstrates the one-dial control for setting sterilization time and highlights the automatic shut-off safety feature of the Fisher-Price Steam Sterilizer.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your sterilizer:

- **Unplug and Cool:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Clean Heating Plate:** To prevent mineral buildup (scaling), regularly clean the heating plate. Use a damp cloth to wipe away any residue. For stubborn deposits, a solution of white vinegar and water can

be used, followed by rinsing with clean water.

- **Wash Components:** The disinfection holder, nipple/teether holder, and lid can be washed with warm soapy water and rinsed thoroughly. They are also top-rack dishwasher safe.
- **Wipe Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- **Storage:** Store the clean and dry sterilizer in a cool, dry place.

6. TROUBLESHOOTING

If you encounter any issues with your sterilizer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Sterilizer does not turn on.	No power supply or dial not set.	Ensure the power cord is securely plugged in and the control dial is rotated to a sterilization setting.
Sterilizer stops mid-cycle.	Water has run out (auto shut-off activated).	This is a safety feature. Allow the unit to cool, then add 100ml of water and restart the cycle if necessary.
White or brown residue on heating plate.	Mineral buildup from tap water.	Clean the heating plate as described in the Maintenance section. Use only purified or distilled water to prevent this.
Steam leakage from the lid.	Lid not properly seated.	Ensure the lid is placed firmly and correctly on the top of the sterilizer.

7. SPECIFICATIONS

Feature	Detail
Model	Sterilizer
Material	Plastic (Food-grade, BPA-free)
Capacity	6 Bottles + Accessories
Power	500W
Product Dimensions (LxWxH)	24 x 17 x 34 cm
Item Weight	2 kg

Feature	Detail
Safety Features	Auto Shut-Off, High-Temperature Resistance
Compatibility	Compatible with wide neck and narrow neck feeding bottles of all popular brands.



Compatible with
feeding bottles of
all popular brands



Image: The sterilizer is compatible with feeding bottles from various popular brands, including Fisher-Price, Philips Avent, Dr. Brown's, Medela, Pigeon, Chicco, and Comotomo.

8. WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please refer to the contact details provided with your purchase documentation or visit the official Fisher-Price website. Keep your proof of purchase for warranty claims.

