

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [migo](#) /
- › [Migo O3 LITE I-Size 360° Swivel Car Seat User Manual](#)

migo O3 LITE

Migo O3 LITE I-Size 360° Swivel Car Seat User Manual

Model: O3 LITE

1. PRODUCT OVERVIEW

The Migo O3 LITE I-Size 360° Swivel Car Seat is designed to provide optimal safety and comfort for children from 40 to 105 cm in height. This car seat is approved according to the R129 I-Size standard, ensuring high safety performance. Its 360° swivel function allows for easy placement of the child and effortless transition between rear-facing and forward-facing positions.





Image: The Migo O3 LITE car seat in red, illustrating its 360-degree swivel feature for easy access and position changes.

2. SAFETY INFORMATION

Always prioritize your child's safety. Read and understand all instructions before installing and using the car seat. Failure to follow these instructions can result in serious injury or death.

- This car seat is approved according to the **R129 I-Size standard**.
- Ensure the car seat is correctly installed using the **ISOFIX connectors and support leg**
- Always secure your child with the **5-point harness system**.
- Never leave your child unattended in the car seat.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage.



Image: A baby comfortably and securely seated in the Migo O3 LITE car seat, demonstrating proper harness use.

3. INSTALLATION

3.1 ISOFIX Installation

The O3 LITE car seat is designed for secure installation using your vehicle's ISOFIX anchor points and the adjustable support leg.

1. Locate the ISOFIX anchor points in your vehicle's back seat.
2. Extend the ISOFIX connectors from the car seat base until they click into the vehicle's anchor points. Ensure the indicators turn green.
3. Push the car seat firmly against the vehicle's seat back to remove any slack.
4. Extend the support leg until it firmly touches the vehicle's floor. Ensure the indicator on the support leg turns green.
5. Verify that the car seat is securely installed and does not move excessively.

3.2 Rear-Facing Use (40-105 cm)

For optimal safety, it is recommended to use the car seat in the rear-facing position for as long as possible, up to 105 cm (approximately 4 years old).



Image: The Migo O3 LITE car seat positioned for rear-facing use, suitable for children from 40 to 105 cm.

3.3 Forward-Facing Use (76-105 cm)

The car seat can be used in the forward-facing position once your child reaches 76 cm in height, up to 105 cm.

1. Ensure the car seat is securely installed using ISOFIX and the support leg.
2. Rotate the car seat to the forward-facing position using the 360° swivel mechanism.
3. Adjust the headrest and harness to fit your child's height.

4. OPERATING INSTRUCTIONS

4.1 360° Swivel Function

The 360° swivel function allows you to easily rotate the car seat for placing your child in or taking them out, and for switching between rear-facing and forward-facing positions.

1. Locate the swivel release lever, usually at the front of the base.
2. Press the lever and rotate the seat to the desired position until it locks into place.
3. Ensure the seat is securely locked before driving.



Image: The Migo O3 LITE car seat illustrating its full 360-degree rotation capability.

4.2 Headrest and Harness Adjustment

The headrest is adjustable in 6 positions, and the harness adjusts automatically with the headrest, adapting to your child's growth.

1. Locate the headrest adjustment lever, typically at the top or back of the headrest.
2. Squeeze the lever and slide the headrest up or down to the appropriate height.
3. Ensure the shoulder straps are at or just below your child's shoulders for rear-facing, and at or just above for forward-facing.



Image: The Migo O3 LITE car seat demonstrating its adjustable headrest and integrated harness system, designed to grow with the child.

4.3 Recline Positions

The car seat offers 3 recline positions for your child's comfort during travel.

1. Locate the recline adjustment lever, usually at the front or side of the seat base.
2. Press the lever and adjust the seat to the desired recline angle.
3. Ensure the seat is securely locked in the chosen recline position.



Image: The Migo O3 LITE car seat illustrating its excellent recline capability for child comfort.

5. MAINTENANCE

Regular maintenance ensures the longevity and safety of your car seat.

- **Cleaning:** The fabric covers are removable and washable. Refer to the care label for specific washing instructions (usually gentle cycle, cold water). Do not use harsh detergents or bleach.
- **Harness:** Wipe the harness straps with a damp cloth. Do not machine wash or submerge the harness straps, as this can weaken the material.
- **Plastic Parts:** Clean plastic parts with a mild soap and water solution.
- **Storage:** Store the car seat in a cool, dry place away from direct sunlight when not in use for extended periods.

6. TROUBLESHOOTING

If you encounter any issues with your Migo O3 LITE car seat, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Car seat feels loose after installation.	ISOFIX connectors not fully engaged or support leg not extended properly.	Ensure ISOFIX indicators are green and support leg indicator is green. Push seat firmly against vehicle seat.
Harness straps are difficult to tighten or loosen.	Straps may be twisted or buckle tongue not fully inserted.	Untwist straps. Ensure buckle tongues click securely into the buckle. Check for obstructions.
Seat does not swivel.	Swivel release lever not fully pressed or mechanism obstructed.	Ensure the release lever is fully engaged. Check for any debris obstructing the swivel mechanism.

7. SPECIFICATIONS

- **Product Name:** Migo O3 LITE I-Size 360° Swivel Car Seat
- **Model:** O3 LITE
- **Child Height Range:** 40 - 105 cm
- **Installation Type:** ISOFIX with Support Leg
- **Harness Type:** 5-point harness
- **Headrest Positions:** 6 adjustable positions
- **Recline Positions:** 3 adjustable positions
- **Safety Standard:** R129 I-Size
- **Manufacturer:** Teamtex
- **Color:** Red (as per this variant)

8. WARRANTY AND SUPPORT

Your Migo O3 LITE car seat comes with a manufacturer's warranty. Please retain your proof of purchase for warranty claims. For detailed warranty information, product support, or to purchase replacement parts, please contact Migo customer service through their official website or the retailer where the product was purchased. For further assistance, please visit the official Migo brand store or contact their support team directly. Thank you for choosing Migo for your child's safety.

