

Cornat KSTASC100

Cornat Tarox Plus Toilet Seat

Model: KSTASC100

Instruction Manual

1. INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your Cornat Tarox Plus KSTASC100 toilet seat. Please read these instructions carefully before installation and retain them for future reference.

The Cornat Tarox Plus toilet seat is designed for comfort and hygiene, featuring durable Duroplast material, a soft-close mechanism, and a Quick Up & Clean function for easy removal and cleaning.

2. SAFETY INFORMATION

- Ensure all components are present and undamaged before installation.
- Do not stand on the toilet seat or lid. This product is designed for sitting only.
- Avoid using abrasive cleaners or harsh chemicals, as these can damage the Duroplast material and hinges.
- Keep small children supervised around the toilet to prevent injury. The soft-close mechanism reduces slamming but is not a substitute for supervision.
- Maximum load capacity: 150 kg. Do not exceed this weight.

3. PACKAGE CONTENTS

Verify that all the following items are included in your package:

- 1 x Cornat Tarox Plus Toilet Seat
- Mounting accessories (hinges, screws, washers, nuts)

4. PRODUCT FEATURES

- **Durable Duroplast Material:** Provides a robust, scratch-resistant, and shatterproof surface.

- **Antibacterial Surface:** Promotes hygiene by preventing germ accumulation.
- **Soft-Close Mechanism:** Ensures a gentle and quiet closing of both the seat and lid, preventing slamming.
- **Quick Up & Clean Function:** Allows for easy removal of the entire toilet seat with a push of a button for thorough cleaning.
- **Top Mounting System:** Facilitates convenient installation from above the toilet bowl.
- **Chemical Resistance:** Withstands common disinfectants and cleaning agents.

5. SETUP AND INSTALLATION

The Cornat Tarox Plus toilet seat features a convenient top-mounting system, suitable for most standard wall-mounted and freestanding toilets.

Installation Steps:

1. **Prepare the Toilet:** Ensure the toilet bowl is clean and dry. Remove any old toilet seat and hardware.
2. **Insert Mounting Bolts:** Place the rubber expansion bolts (part of the mounting accessories) into the mounting holes on the toilet bowl.
3. **Position Hinges:** Place the hinge bases over the expansion bolts. Adjust their position to align with the mounting points on the toilet seat.
4. **Secure Hinges:** Insert the screws through the hinge bases and into the expansion bolts. Tighten the screws from above using a screwdriver until the hinges are firmly secured. Do not overtighten.
5. **Attach Toilet Seat:** Align the toilet seat's attachment points with the hinge pins. Press down firmly until the seat clicks into place. Ensure it is securely fastened.



Image: Underside view of the Cornat Tarox Plus toilet seat, illustrating the hinge attachment points for top mounting.



Image: Side view of the Cornat Tarox Plus toilet seat with the lid open, demonstrating the hinge mechanism.

6. OPERATING INSTRUCTIONS

Soft-Close Function:

To engage the soft-close function, simply push the toilet seat and/or lid downwards gently. The integrated mechanism will automatically lower them slowly and quietly until they rest on the toilet bowl. Do not force the seat or lid down, as this can damage the soft-close mechanism.



Image: Top view of the Cornat Tarox Plus toilet seat with the lid open, ready for use, highlighting the smooth design.

Quick Up & Clean Function:

For thorough cleaning of the toilet bowl and seat, the Quick Up & Clean function allows for easy removal of the entire seat. Locate the release buttons (usually near the hinges) and press them simultaneously. Gently lift the toilet seat straight up from the hinges. To reattach, align the seat with the hinge pins and press down until it clicks securely into place.

7. MAINTENANCE AND CLEANING

Regular cleaning will maintain the hygiene and appearance of your toilet seat.

- **Daily Cleaning:** Use a soft cloth with mild soap and water. Wipe the entire surface of the seat and lid.
- **Deep Cleaning:** Utilize the Quick Up & Clean function to remove the seat. Clean the hinges and the

area around the mounting holes on the toilet bowl.

- **Approved Cleaners:** The Duroplast material is resistant to many common disinfectants and detergents. However, avoid abrasive cleaners, scouring pads, or strong acid/alkaline solutions, as these can damage the surface finish.
- **Drying:** Always dry the seat and hinges thoroughly after cleaning to prevent water spots and maintain hinge integrity.



Image: Top view of the Cornat Tarox Plus toilet seat with the lid closed, showcasing its classic white design.

8. TROUBLESHOOTING

If you encounter any issues with your Cornat Tarox Plus toilet seat, refer to the following common solutions:

Problem	Possible Cause	Solution
Toilet seat is loose.	Mounting screws are not tight enough.	Remove the seat using the Quick Up & Clean function. Tighten the mounting screws on the hinge bases from above. Reattach the seat.

Problem	Possible Cause	Solution
Soft-close function not working or closing too fast.	Hinges may be dirty or damaged.	Remove the seat and clean the hinge mechanisms thoroughly. If the issue persists, contact customer support.
Seat does not attach securely after cleaning.	Seat not properly aligned with hinge pins.	Ensure the seat is correctly aligned over the hinge pins before pressing down. You should hear a click when it locks into place.

9. SPECIFICATIONS

Feature	Detail
Model	Tarox Plus KSTASC100
Shape	Oval
Material (Seat)	Duroplast
Material (Hinges)	Stainless Steel
Color	White
External Dimensions (L x W)	45 cm x 37.5 cm (17.7 in x 14.8 in)
Internal Dimensions (L x W)	28 cm x 23 cm (11.0 in x 9.1 in)
Item Weight	1.98 kg (4.37 lbs)
Maximum Load Capacity	150 kg (330 lbs)
Mounting Type	Top Mounting
Special Features	Soft-Close, Quick Up & Clean, Antibacterial

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the purchase documentation or contact Cornat customer service directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Conmetall Meister GmbH