

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [XL](#) /

> [XL premium Silicone Oil Lubricant for Treadmill Belt 500 ML with Free Dispenser Bottle and Easy Applicator User Manual](#)

### XL ISHU0029

# XL Treadmill Belt Lubricant User Manual

Model: ISHU0029

## 1. INTRODUCTION

---

This user manual provides essential information for the proper use, maintenance, and troubleshooting of your XL premium Silicone Oil Lubricant for Treadmill Belt. Please read this manual thoroughly before using the product to ensure optimal performance and longevity of your treadmill.

## 2. PRODUCT OVERVIEW

---

The XL premium Silicone Oil Lubricant is specifically formulated for all types of manual and motorized treadmills. It is a 100% pure silicone lubricant designed to extend the service life of your treadmill's motor, belt, and rollers, ensuring smoother and quieter operation.



Figure 2.1: XL Treadmill Belt Lubricant 500 ML bottle with a free dispenser bottle and easy applicator.

### Key Features:

- **Enhanced Performance:** Extends the service life of the treadmill and enhances overall performance.
- **Component Protection:** Helps to increase the life of the motor, belt, and rollers.
- **Smooth & Quiet Operation:** Ensures trouble-free, smoother workouts and adds silent operation to your treadmill.
- **Non-Sticky Formula:** Prevents frequent wear and tear of the belt due to its excellent consistency and purity.
- **Recommended by Experts:** 100% silicone lubricant, ideal for fitness centers and recommended by most fitness equipment manufacturers globally.
- **Protective Properties:** Anti-static, dust, and water-resistant.

### 3. SETUP AND PREPARATION

---

Before applying the lubricant, ensure your treadmill is clean and powered off. Proper preparation is crucial for effective

lubrication.

### 3.1 Unpacking and Inspection

1. Carefully unpack the XL Treadmill Belt Lubricant bottle and the included dispenser bottle with applicator.
2. Inspect all components for any signs of damage. If any damage is found, do not use the product and contact customer support.

### 3.2 Preparing the Treadmill

1. **Power Off:** Ensure the treadmill is completely powered off and unplugged from the electrical outlet.
2. **Clean the Belt:** Use a clean, damp cloth to wipe down the treadmill belt and deck surface to remove any dust or debris. Allow it to dry completely.
3. **Access the Deck:** Depending on your treadmill model, you may need to slightly loosen the belt tension to lift the belt and access the deck underneath. Refer to your treadmill's specific user manual for instructions on how to do this.



## 4. OPERATING INSTRUCTIONS (LUBRICATION PROCESS)

---

Follow these steps to properly lubricate your treadmill belt using XL Silicone Oil Lubricant.

1. **Fill Dispenser Bottle:** Pour a small amount of XL Silicone Oil Lubricant from the main 500 ML bottle into the smaller, clear dispenser bottle.
2. **Attach Applicator:** Securely attach the easy applicator nozzle to the dispenser bottle.
3. **Apply Lubricant:** Lift one side of the treadmill belt. Insert the applicator nozzle underneath the belt, reaching towards the center of the deck. Apply a thin, continuous line of lubricant along the deck, from the front to the back.
4. **Repeat on Other Side:** Repeat the process on the other side of the treadmill belt. Aim for an even distribution of lubricant across the entire width of the deck.
5. **Center the Belt:** If you loosened the belt, re-tension it according to your treadmill's manual.
6. **Spread Lubricant:** Plug in the treadmill and turn it on at a slow speed (e.g., 1-2 km/h) for 3-5 minutes without anyone on it. This will help spread the lubricant evenly under the belt.
7. **Wipe Excess:** After the spreading cycle, wipe off any excess lubricant that may have seeped out from the edges of the belt with a clean cloth.

**Important Note:** The frequency of lubrication depends on your treadmill usage. For typical home use, lubricating every 3-6 months or after 40-60 hours of use is generally recommended. Consult your treadmill's manual for specific lubrication guidelines.

## 5. MAINTENANCE AND STORAGE

---

### 5.1 Product Storage

- Store the XL Treadmill Belt Lubricant in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep the bottle tightly sealed when not in use to prevent contamination and evaporation.
- Keep out of reach of children and pets.

### 5.2 General Treadmill Maintenance

- Regularly clean your treadmill to remove dust and sweat.
- Check belt tension and alignment periodically.
- Ensure all bolts and screws are tightened.

## 6. TROUBLESHOOTING

---

This section addresses common issues related to treadmill lubrication. For other treadmill-related problems, refer to your treadmill's specific user manual.

| Problem                               | Possible Cause                                  | Solution  |
|---------------------------------------|---|---|
| Treadmill belt feels sticky or rough. | Insufficient lubrication or uneven application. | Reapply lubricant following the operating instructions, ensuring even distribution. |

| Problem                        | Possible Cause                                 | Solution   |
|--------------------------------|--|--|
| Squeaking noise from the belt. | Lack of lubrication or worn belt/deck.         | Apply lubricant. If the noise persists, inspect the belt and deck for wear and consider replacement if necessary.  |
| Treadmill motor overheating.   | Excessive friction due to lack of lubrication. | Immediately power off the treadmill. Allow it to cool down. Apply lubricant generously and evenly. If the problem persists, consult a professional technician. |

## 7. SPECIFICATIONS

---

| Attribute           | Detail   |
|---------------------|--|
| Product Name        | XL premium Silicone Oil Lubricant for Treadmill Belt               |
| Brand               | XL   |
| Model Number        | ISHU0029   |
| Liquid Volume       | 500 ML (0.5 Liters)  |
| Material            | 100% Silicone  |
| Product Dimensions  | 3 x 3 x 14 cm  |
| Item Weight         | 365 Grams  |
| Package Information | Bottle (includes main bottle and dispenser bottle with applicator) |

## 8. WARRANTY AND SUPPORT

---

For any product-related inquiries, technical support, or warranty claims, please contact the manufacturer or seller directly. Refer to your purchase documentation for specific contact details.

- **Manufacturer:** xl
- **ASIN:** B08RPBV9ML
- **Date First Available:** 28 April 2021

Please retain your proof of purchase for warranty purposes.

