

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Sakar](#) /

> [Graco Digital Baby Audio Monitor User Manual](#)

## Sakar GRCOM103T

# Graco Digital Baby Audio Monitor

## USER MANUAL

### 1. INTRODUCTION

Thank you for purchasing the Graco Digital Baby Audio Monitor. This monitor is designed to provide parents with a reliable and convenient way to monitor their baby, offering clear audio transmission, two-way communication, a gentle night light, and a room temperature sensor. Please read this manual thoroughly before use to ensure proper operation and safety.

### 2. SAFETY INFORMATION

#### **WARNING: STRANGULATION HAZARD**

- Keep all cords out of reach of children. Never place the baby unit or cords within 3 feet (1 meter) of the crib or playpen.
- Do not place the monitor in or near water.
- Do not use the monitor if it has been damaged.
- Use only the power adapter supplied with the product.
- This product is not a substitute for responsible adult supervision.
- Ensure batteries are inserted with correct polarity. Do not mix old and new batteries.

### 3. PACKAGE CONTENTS

- 1 x Parent Unit
- 1 x Baby Unit
- 1 x USB Charging Cable
- 1 x Lithium Ion Battery (pre-installed or included for Parent Unit)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Graco Digital Baby Audio Monitor.

### 4.1 Parent Unit



The parent unit features a display screen, volume controls (+/-), power/night light button, and a two-way talk button. The back includes a belt clip and a USB charging port.

### 4.2 Baby Unit



The baby unit includes a microphone, night light, and a USB charging port. On the back, there is a channel selector switch (A/B) and a power button.



Both units are compact and designed for easy portability.

## 5. SETUP

### 5.1 Charging the Units

- Connect the included USB charging cable to the USB port on both the Parent Unit and Baby Unit.
- Plug the other end of the USB cable into any standard USB power outlet (e.g., wall adapter, computer USB port).
- The units will indicate charging status on their displays. Fully charge both units before first use.

### 5.2 Powering On and Channel Selection

- Ensure both the Parent Unit and Baby Unit have sufficient battery charge or are connected to power.
- On the back of the Baby Unit, locate the channel selector switch (A or B). Set it to either A or B.
- On the back of the Parent Unit, locate the corresponding channel selector switch. Ensure it is set to the **same channel (A or B)** as the Baby Unit for proper connection.
- Press and hold the power button on both units until they turn on.
- The units should automatically connect. If not, ensure they are on the same channel and within range.

### 5.3 Placement



Place the Baby Unit in the baby's room, at least 3 feet (1 meter) away from the crib or playpen, but close enough to clearly pick up sounds. Ensure it is on a stable, flat surface. The Parent Unit can be carried with you throughout your home.

## 6. OPERATION

### 6.1 Monitoring Audio

Once both units are powered on and connected, the Parent Unit will automatically receive audio from the Baby Unit. Adjust the volume using the '+' and '-' buttons on the Parent Unit.

## 6.2 Two-Way Communication

To speak to your baby through the Baby Unit, press and hold the talk button on the Parent Unit. Release the button to return to listening mode.

## 6.3 Night Light Function

The Baby Unit features a gentle night light. Press the night light button on the Parent Unit to activate or deactivate it. This provides soft illumination without disturbing your baby's sleep.

## 6.4 Room Temperature Sensor

The Parent Unit displays the room temperature detected by the Baby Unit. The monitor will alert you if the temperature goes above 86°F (30°C) or below 61°F (16°C), helping you maintain a comfortable environment for your baby.

## 6.5 Out-of-Range Alert

The Parent Unit will automatically alert you if it loses connection with the Baby Unit due to being out of range. Move closer to the Baby Unit to re-establish connection.

# 7. MAINTENANCE

## 7.1 Cleaning

Wipe the monitor units with a dry, soft cloth. Do not use abrasive cleaners or solvents. Do not immerse units in water.

## 7.2 Battery Care

To prolong battery life, avoid extreme temperatures. If storing the monitor for an extended period, fully charge the battery before storage and recharge every few months.

# 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound or static from Parent Unit	Units not paired; out of range; low battery; incorrect channel.	Ensure both units are powered on and on the same channel (A or B). Charge both units. Move Parent Unit closer to Baby Unit. <b>Note: Parent Unit requires its internal battery to be present and charged for proper operation, even when plugged in.</b>
Short battery life	Battery not fully charged; old battery.	Ensure units are fully charged before use. If battery life remains short, the internal battery may need replacement (contact support).

Problem	Possible Cause	Solution
Temperature alert constantly active	Room temperature is outside the set range.	Adjust room temperature to be between 61°F (16°C) and 86°F (30°C).
Two-way talk not working	Talk button not pressed or held correctly.	Press and hold the talk button on the Parent Unit firmly while speaking. Release to listen.

## 9. SPECIFICATIONS

Feature	Detail
Model Number	GRCOM103T
Product Dimensions	3 x 3 x 5 inches
Item Weight	13.2 ounces (0.38 Kilograms)
Power Source	Battery Powered (USB Rechargeable)
Battery Type	1 Lithium Ion battery (included)
Material Composition	Plastic
Special Features	Lightweight, Wireless, Two-Way Audio, Night Light, Room Temperature Sensor, Out-of-Range Alert
Tuner Technology	UHF
Manufacturer	Sakar International Inc
UPC	021331016126

## 10. WARRANTY AND SUPPORT

This Graco Digital Baby Audio Monitor is manufactured by Sakar International Inc. For warranty information and customer support, please refer to the warranty card included with your product or visit the official Sakar International Inc. website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, you may also contact the retailer where the product was purchased.

