

Babyono 839/05

Babyono HONEY NATURAL NURSING Electronic Food Warmer and Sterilizer Instruction Manual

1. INTRODUCTION

Thank you for choosing the Babyono HONEY NATURAL NURSING Electronic Food Warmer and Sterilizer. This versatile appliance is designed to safely and efficiently warm baby milk and food, as well as sterilize baby bottles and accessories. Please read this instruction manual carefully before first use and keep it for future reference. Proper use ensures the safety and longevity of the product.

2. IMPORTANT SAFETY INFORMATION

- Always ensure the appliance is placed on a stable, level, heat-resistant surface, away from children.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Unplug the appliance from the power outlet when not in use and before cleaning.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way. Contact customer support for assistance.
- Use only distilled or purified water for sterilization to prevent limescale buildup.
- Always check the temperature of warmed milk or food before feeding your baby to prevent burns.
- Keep out of reach of children. This appliance is not a toy.
- Do not touch hot surfaces. Use handles or knobs.

3. PRODUCT COMPONENTS

The Babyono Electronic Food Warmer and Sterilizer consists of the following main parts:

- **Main Unit:** The primary body housing the heating element and control panel.
- **Digital Control Panel:** Features a display, power button, menu button, and temperature adjustment buttons.
- **Heating Chamber:** The internal compartment where bottles or food containers are placed.

- **Lid:** Covers the heating chamber during operation.



This image shows the front of the Babyono Electronic Food Warmer and Sterilizer. The digital display clearly indicates 'Set Temp' and 'Current Temp' at 40°C, along with icons for different functions. Below the display are the power button, plus and minus buttons for adjustment, and a menu button.



This image provides a top-down perspective of the warmer/sterilizer, highlighting the spacious heating chamber designed to accommodate various bottle sizes or food containers. The smooth, white interior is visible.

4. SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the exterior of the main unit with a damp cloth. Wash the lid and any removable accessories (if included) with warm soapy water, rinse thoroughly, and dry. Do not immerse the main unit in water.
3. **Placement:** Place the appliance on a dry, stable, and heat-resistant surface, ensuring it is out of reach of children and away from direct sunlight or heat sources.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet. The display may light up briefly.

5. OPERATING INSTRUCTIONS

5.1 General Operation

- Press the **Power button** () to turn the unit on or off.

- Use the **Menu button** to cycle through different functions (e.g., milk warming, food warming, sterilization).
- Use the **Plus (+)** and **Minus (-)** buttons to adjust temperature or time settings.

5.2 Warming Milk

1. Place the baby bottle containing milk into the heating chamber.
2. Add water to the heating chamber, ensuring the water level is below the bottle's rim and covers the milk level.
3. Place the lid on the unit.
4. Press the **Power button** to turn on the unit.
5. Press the **Menu button** until the milk warming icon is selected.
6. Use the **Plus (+)** or **Minus (-)** buttons to set the desired temperature (e.g., 37-40°C for body temperature).
7. The unit will begin heating. The display will show the current temperature.
8. Once the desired temperature is reached, the unit will maintain it. Carefully remove the bottle, shake gently, and check the milk temperature on your wrist before feeding.

5.3 Warming Food

1. Place the baby food jar or container into the heating chamber.
2. Add water to the heating chamber, ensuring the water level is below the container's rim.
3. Place the lid on the unit.
4. Press the **Power button** to turn on the unit.
5. Press the **Menu button** until the food warming icon is selected.
6. Use the **Plus (+)** or **Minus (-)** buttons to set the desired temperature.
7. The unit will begin heating. Stir the food occasionally during warming for even heating.
8. Once warmed, carefully remove the container and check the food temperature before serving.

5.4 Sterilization



Here, the warmer/sterilizer is shown with a standard baby bottle placed within its heating chamber, covered by the protective lid. This demonstrates how the unit appears during operation.

1. Ensure bottles and accessories are thoroughly washed and rinsed before sterilization.
2. Place the clean bottles (upside down) and accessories into the heating chamber.
3. Add approximately 80-100ml of distilled or purified water to the heating chamber. Do not overfill.
4. Place the lid securely on the unit.
5. Press the **Power button** to turn on the unit.
6. Press the **Menu button** until the sterilization icon is selected.
7. The unit will automatically heat the water to boiling point, creating steam for sterilization.
8. Once the sterilization cycle is complete, the unit will automatically turn off or enter a standby mode.

9. Allow the unit to cool down before carefully removing the lid and sterilized items. Use tongs to avoid touching hot surfaces.

6. MAINTENANCE AND CLEANING

6.1 Daily Cleaning

- Always unplug the appliance and allow it to cool completely before cleaning.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or solvents.
- Empty any remaining water from the heating chamber. Wipe the interior with a soft, damp cloth.
- Wash the lid and any removable accessories with warm soapy water, rinse, and dry thoroughly.

6.2 Descaling

Over time, mineral deposits (limescale) may build up in the heating chamber, especially if tap water is used. Descale the unit regularly (e.g., monthly or as needed) to maintain efficiency.

1. Ensure the unit is unplugged and cool.
2. Mix 50ml of white vinegar with 100ml of cold water. Pour the solution into the heating chamber.
3. Do not turn on the appliance. Let the solution soak for 30 minutes to 1 hour, or longer for heavy buildup.
4. Pour out the solution and rinse the heating chamber thoroughly with clean water several times until the vinegar smell is gone.
5. Wipe dry with a clean cloth.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet issue; unit malfunction.	Check power cord connection. Try a different outlet. If problem persists, contact customer support.
Milk/food not warming.	Insufficient water; incorrect temperature setting; unit malfunction.	Ensure adequate water level. Verify temperature setting. Contact customer support if issue continues.
Sterilization not effective.	Insufficient water; lid not properly sealed; excessive limescale.	Ensure correct water volume. Check lid for proper placement. Descale the unit as per instructions.
White residue in heating chamber.	Limescale buildup from hard water.	Descale the unit using vinegar solution. Use distilled or purified water for future use.

8. SPECIFICATIONS

- **Model:** 839/05
- **Brand:** Babyono
- **Dimensions (L x W x H):** Approximately 50 x 50 x 28 cm
- **Weight:** Approximately 630 grams
- **Power Supply:** (Information not provided, refer to product label for details)

- **Functions:** Milk warming, food warming, sterilization

9. WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or contact Babyono customer service directly. Keep your proof of purchase for warranty claims.