

[Manuals.plus](#) /

> [KITOART](#) /

> KITOART Masticating Juicer Attachment for KitchenAid Stand Mixers (Model MJA) Instruction Manual

## KITOART MJA

# KITOART Masticating Juicer Attachment

## INSTRUCTION MANUAL FOR KITCHENAID STAND MIXERS (MODEL MJA)

Brand: KITOART | Model: MJA

### Introduction

The KITOART Masticating Juicer Attachment is designed to upgrade your KitchenAid Stand Mixer into an efficient juicing machine. This attachment helps separate pomace from juice, extracting nutrients from fruits and vegetables. It features an upgraded 7-segment spiral system for maximum juice yield and minimal oxidation, ensuring your juice retains its original taste and flavor with less pulp.

This manual provides detailed instructions for assembly, operation, and maintenance to ensure optimal performance and longevity of your juicer attachment.



*KITOART Masticating Juicer Attachment connected to a red KitchenAid stand mixer.*

## **Product Components**

Familiarize yourself with the components of your KITOART Masticating Juicer Attachment:

# EASY INSTALLATION



**ATTENTION!** Before assembling turn the stand mixer off and unplug first.

*Diagram illustrating the components of the juicer attachment.*

- **Food Pusher:** Used to gently push fruits and vegetables into the feed tube.
- **Food Tray:** Holds prepared ingredients before feeding into the juicer.
- **Housing:** The main body of the attachment that connects to the mixer.
- **Auger:** The spiral component that crushes and presses produce.
- **Fine Strainer:** Separates juice from pulp.
- **Lock:** Secures the front components of the juicer.
- **Juice Cup (not always included):** Collects extracted juice.
- **Pomace Cup (not always included):** Collects discarded pulp.

*Note: Due to product version updates, some packages may not include the two plastic cups. This does not affect the juicing process.*

## Setup and Assembly

The KITOART Masticating Juicer Attachment is designed for quick and easy assembly onto your KitchenAid Stand Mixer.

1. **Preparation:** Ensure your KitchenAid Stand Mixer is turned off and unplugged before assembly.
2. **Remove Mixer Hub Cover:** Locate the power hub on the front of your KitchenAid Stand Mixer.

Unscrew the attachment hub knob and remove the hub cover.

3. **Attach Juicer:** Insert the drive shaft of the juicer attachment into the attachment hub of your mixer. Rotate the attachment slightly until it fits securely into the square hub socket.
4. **Secure Attachment:** Tighten the attachment hub knob until the juicer attachment is firmly in place.
5. **Position Cups:** Place the juice collecting cup under the juice spout and the pomace collecting cup under the pulp outlet.



*The juicer attachment securely connected to a KitchenAid stand mixer.*

## Operating Instructions

Follow these steps to extract fresh juice using your KITOART Masticating Juicer Attachment:

1. **Prepare Produce:** Wash and cut fruits and vegetables into pieces small enough to fit into the

feed tube. For best results, remove hard seeds, pits, and thick peels (e.g., citrus rinds) to prevent bitterness and potential clogging.

2. **Select Speed:** Plug in your KitchenAid Stand Mixer. Set the mixer speed to 1 or 2 for optimal juicing. Higher speeds are generally not recommended for masticating juicers.
3. **Begin Juicing:** Turn on the mixer. Gradually feed the prepared fruits and vegetables into the feed tube. Use the food pusher to gently guide the produce down. Do not force the produce.
4. **Collect Juice and Pulp:** The juicer will automatically separate the juice and pulp into their respective collecting cups.
5. **Continuous Juicing:** Continue feeding produce until you have the desired amount of juice.
6. **Finish:** Once juicing is complete, turn off the KitchenAid Stand Mixer and unplug it.



*Woman feeding carrots into the KITOART Masticating Juicer Attachment.*

# 7 Segment Spirals - Upgraded

Stages for squeezing the fruits & vegetables to achieve over 90% juice yield!



*The 7-segment spiral system efficiently extracts juice.*

## Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your juicer attachment. The attachment is **NOT dishwasher safe** and should only be hand washed.

1. **Disassembly:** After unplugging the mixer, reverse the assembly steps to detach the juicer from the mixer and separate all its components (food pusher, food tray, housing, auger, fine strainer, lock).
2. **Rinse:** Rinse all detachable parts under warm running water to remove any large pulp residue.
3. **Clean with Brush:** Use the provided cleaning brush to thoroughly clean the fine strainer and other components, paying special attention to small crevices where pulp might accumulate.
4. **Wash with Soap:** Wash all parts with warm, soapy water.
5. **Rinse and Dry:** Rinse all parts thoroughly to remove soap residue. Allow them to air dry completely before reassembling or storing.



*Hand washing the juicer attachment components.*

## Troubleshooting

If you encounter any issues while using your KITOART Masticating Juicer Attachment, consider the following common solutions:

- **Clogging:** If the juicer clogs, turn off the mixer immediately. Disassemble the attachment and clear any blockages in the auger or strainer. Ensure produce is cut into appropriate sizes and hard elements are removed.
- **Low Juice Yield:** Ensure the mixer speed is set to 1 or 2. Overly fibrous or dry ingredients may yield less juice. Pre-soaking some fibrous vegetables can sometimes help.
- **Attachment Not Fitting Securely:** Double-check that the attachment hub knob is fully tightened and the drive shaft is correctly aligned with the mixer's hub socket.
- **Excessive Pulp in Juice:** Ensure the fine strainer is clean and properly installed.

For persistent issues, please refer to the support information provided by KITOART.

## Specifications

Feature	Detail
Brand	KITOART

Model Name	MJA White
Item Model Number	MJA
Color	White For All KA Mixers
Product Dimensions	3.94 x 7.09 x 10.24 inches
Item Weight	2.46 pounds
Blade Material	Stainless Steel
Is Dishwasher Safe	No (Hand Wash Only)
Recommended Uses	Juice, Sauce

## Warranty and Support

KITOART is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, KITOART offers exclusive after-sales service and addresses replacement concerns.

For any questions, support, or warranty inquiries regarding your Masticating Juicer Attachment, please contact KITOART Direct through their official channels or the retailer where the product was purchased.