

## ThermoPro TP510

# ThermoPro TP510 Waterproof Digital Instant Read Thermometer User Manual

Model: TP510



## 1. INTRODUCTION

Thank you for purchasing the ThermoPro TP510 Waterproof Digital Instant Read Thermometer. This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your device. The TP510 is designed for precise temperature measurement in various cooking applications, including candy making, deep frying, grilling, and smoking.



Figure 1: ThermoPro TP510 Digital Instant Read Thermometer with included accessories.

## 2. PRODUCT OVERVIEW

### Key Features:

- **Backlit 90° Rotating Display:** Large, adjustable screen for optimal visibility in any lighting.
- **Accurate Readings:** Delivers precise temperatures within 4-5 seconds with an accuracy of  $\pm 0.9^{\circ}\text{F}$  ( $\pm 0.5^{\circ}\text{C}$ ).
- **IPX5 Waterproof Design:** Allows for easy cleanup under running water.
- **Durable Construction:** Made from sturdy plastic and food-grade stainless steel.
- **Wide Temperature Range:** Measures from  $-58^{\circ}\text{F}$  to  $572^{\circ}\text{F}$  ( $-50^{\circ}\text{C}$  to  $300^{\circ}\text{C}$ ).
- **10-inch Long Probe with Pot Clip:** Ensures safe and hands-free temperature monitoring.
- **Temperature Reference Chart:** Printed on the device for quick access to common cooking temperatures.

### What's in the Box:

- 1 x Candy Thermometer

- 1 x AAA Battery (included)
- 1 x Pot Clip
- 1 x User Manual

Ultra-Clear LCD Display

Easy to Read Quick Temp References

Stainless Steel Pot Clip

8" Super Long Stainless Steel Probe

Touch Backlit

ON/OFF/°C/°F Button




Figure 2: Detailed view of the ThermoPro TP510 components and controls.

### 3. SETUP

1. **Battery Installation:** The TP510 comes with one AAA battery. Locate the battery compartment on the back of the device, open it, insert the AAA battery ensuring correct polarity (+/-), and close the compartment securely.
2. **Attaching the Pot Clip:** Slide the stainless steel pot clip onto the thermometer probe. Adjust its position along the probe to ensure the probe tip is immersed in the food without touching the bottom of the pot.
3. **Initial Power On:** Press the ON/OFF/°C/°F button to power on the thermometer. The display will light up.

# 10" SUPER-LONG PROBE & POT CLIP

Perfect for any sized pot!



Figure 3: The 10-inch long probe with an adjustable pot clip for secure placement.

## 4. OPERATING INSTRUCTIONS

### 4.1 Temperature Measurement

1. Insert the stainless steel probe tip into the thickest part of the food or liquid, avoiding bone or gristle.
2. The temperature reading will appear on the digital display within 4-5 seconds.
3. For continuous monitoring in a pot, use the included pot clip to secure the thermometer.

### 4.2 Temperature Unit Conversion (°C/°F)

Press the ON/OFF/°C/°F button to toggle between Celsius (°C) and Fahrenheit (°F) temperature units.

### 4.3 Backlight Function

The display features a backlight for easy reading in dimly lit conditions. The backlight will automatically activate when the thermometer is in use and will turn off after a short period of inactivity to conserve battery life.

## 4.4 90° Adjustable Head

The thermometer head can be rotated up to 90 degrees, allowing you to adjust the viewing angle for optimal readability without needing to reposition the probe or your body.




Figure 4: The thermometer head can be adjusted for various viewing angles.

## 4.5 Auto-Off Feature

To conserve battery power, the thermometer will automatically turn off after 10 minutes of inactivity. Press the ON/OFF/°C/°F button to turn it back on.

## 4.6 Temperature Guide

Refer to the printed temperature reference chart on the thermometer for recommended temperatures for various foods and candy stages.



# WIDE RANGE OF APPLICATIONS



Figure 5: The ThermoPro TP510 is suitable for a wide range of cooking applications.

## 5. MAINTENANCE & CARE

- **Cleaning:** The ThermoPro TP510 is IPX5 waterproof. Clean the probe and thermometer body by rinsing under running water with mild soap. Do not immerse the entire unit in water for extended periods.
- **Storage:** Store the thermometer in a dry place at room temperature. Ensure the probe is clean and dry before storage.
- **Battery Replacement:** Replace the AAA battery when the display becomes dim or the thermometer fails to power on.
- **Do Not Disassemble:** Do not attempt to disassemble the unit, as this may void the warranty and cause damage.



# IPX5 WATERPROOF

Cleanup takes only seconds, simply wash under running water!



Figure 6: The IPX5 waterproof design allows for easy cleaning under running water.

## 6. TROUBLESHOOTING

- **No Display/Dim Display:** Replace the AAA battery. Ensure the battery is inserted with correct polarity.
- **Inaccurate Readings:** Ensure the probe tip is inserted into the thickest part of the food and not touching bone, gristle, or the bottom/sides of the cooking vessel. Calibrate the thermometer if necessary (refer to specific calibration instructions if provided with your model, or contact customer support).
- **Slow Readings:** Ensure the probe is fully inserted into the food. If the battery is low, replace it.
- **Thermometer Not Turning On:** Check battery installation. If the issue persists, contact customer support.

## 7. SPECIFICATIONS

Feature	Specification
Product Dimensions	12.91 x 2.95 x 1.34 inches



Weight	2.86 ounces
Item Model Number	TP510
Batteries	1 AAA batteries required (included)
Manufacturer	ThermoPro
Special Feature	High Accuracy
Color	Backlit-Orange
Outer Material	Plastic
Specification Met	CE, FCC, NSF
Display Type	Digital
Product Care Instructions	Hand Wash Only



Figure 7: The ThermoPro TP510 is certified by NSF, CE, and RoHS, indicating compliance with safety and quality standards.



## 8. OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

*Video 1: Official ThermoPro TP510 Digital Candy Thermometer overview. This video demonstrates the key features and uses of the thermometer.*

## 9. WARRANTY & SUPPORT

ThermoPro provides a limited warranty for this product. For detailed warranty information, product registration, or technical support, please contact ThermoPro Customer Service:

- **USA & Canada:** 1-877-515-7797
- **Germany:** 49-895-484-19011
- **UK:** 44-808-164-1683
- **France:** 61-180-057-7492
- **Email:** [service@buythermopro.com](mailto:service@buythermopro.com)

Please have your model number (TP510) and purchase date available when contacting support.