

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TimeFllys](#) /

› [TimeFllys Audio Baby Monitor Instruction Manual](#)

TimeFllys MOL1A2B220509

TimeFllys Audio Baby Monitor Instruction Manual

Model: MOL1A2B220509

Brand: TimeFllys

1. INTRODUCTION AND OVERVIEW

The TimeFllys Audio Baby Monitor is designed to provide parents with peace of mind, allowing them to monitor their baby's sounds from a distance. This portable audio monitor features two-way talk, lullabies, temperature monitoring, and a night light, ensuring comprehensive care for your child. Its long-range capability and flexible power options make it ideal for use at home or on the go.



Image: The TimeFllys Audio Baby Monitor, showing both the parent and baby units.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Adaptor
- 1 x Set of Rechargeable Battery
- Battery Compartments in both parent and baby units
- 2 x Type C USB Cables

3. PRODUCT FEATURES

3.1 USB Connection & Power Options

Both the parent and baby units are designed for portability and flexibility. They come with rechargeable battery compartments and can operate using either the included rechargeable batteries or by being plugged into a wall power supply via the provided Type C USB cables. This dual power capability makes the monitor suitable for various environments, including outdoor use like camping.




Image: Rear view of the monitor units, highlighting the battery compartments and USB-C charging port.

3.2 Lullabies & Two-Way Talk Intercom

Comfort your baby remotely with the built-in lullaby feature. The parent unit can initiate a selection of up to 8 lullabies to soothe your baby to sleep. Additionally, the two-way talk intercom allows parents to speak directly to their baby by pressing a dedicated button on the parent unit, providing reassurance and comfort.

Portable Belt Clip

Portable Belt Clip



Battery Compartment

State-of-Art Power Port - Type C

Voice Sensitivel Level

H: Starts to transmit when voice \geq 50 dB
L: Starts to transmit when voice \geq 60 dB

Image: Baby unit emitting music notes, indicating the lullaby function.



Image: Illustration of the two-way talk feature between the parent and baby units.

3.3 Night Light Control

Both the parent and baby units feature a night light that can be remotely controlled from the parent unit. This allows you to provide a soft glow in the baby's room as needed, without disturbing them.



Image: The baby unit's night light providing illumination in a dark nursery.

3.4 Temperature Monitoring & Alarm

The LCD screen on the parent unit displays the real-time temperature of the baby's room. An acoustical warning will sound if the room temperature falls outside the comfortable range of 60.8°F (16°C) to 86°F (30°C), alerting you to adjust the environment for your baby's comfort.



Image: The baby unit's screen showing the room temperature.

3.5 Long Range & FHSS Digital Technology

Experience reliable monitoring with a talking range of up to 1000 feet. The monitor utilizes FHSS (Frequency Hopping Spread Spectrum) digital technology, which provides a secure and interference-free connection, ensuring clear audio transmission between units.



Image: Visual representation of the monitor's indoor range capability.

3.6 Portable Belt Clip

Both units are equipped with a portable belt clip, allowing you to easily attach them to your clothing or hang them from a suitable location, keeping your hands free while maintaining monitoring capabilities.



Image: The monitor units showcasing their portable belt clips.

4. SETUP

4.1 Initial Charging

Before first use, fully charge both the parent and baby units. Connect the provided Type C USB cables to the charging ports on each unit and plug them into a compatible USB power adapter (not included, but compatible with most smartphone adapters). The battery indicator on the parent unit's LCD screen will show charging status.

4.2 Battery Installation (Optional)

While the units come with rechargeable batteries, you can also use standard AAA batteries if needed. To install, unscrew the battery compartment cover on the back of each unit, insert 3 AAA batteries (not included) with correct polarity, and replace the cover. Note that the rechargeable function is for the included rechargeable battery pack only.

4.3 Power On/Off

Press and hold the power button on each unit until the screen illuminates (parent unit) or the indicator light turns on (baby unit). The units are pre-paired for immediate use. If re-pairing is ever needed, refer to the troubleshooting section.

Video: An official product video demonstrating the setup and basic features of the TimeFlys Mustang Audio Baby Monitor, including battery installation and charging.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Volume

On the parent unit, use the 'Volume +' and 'Volume -' buttons located on the side to increase or decrease the listening volume. The current volume level is displayed on the LCD screen.

5.2 Using Two-Way Talk

To speak to your baby, press and hold the 'Talk' button on the parent unit. Speak clearly into the microphone. Release the button when you are finished speaking. Your voice will be transmitted to the baby unit.

5.3 Activating Lullabies

To play lullabies, press the 'Lullaby' button on the parent unit. Pressing it repeatedly will cycle through the available lullabies. Press and hold to stop the lullabies.

5.4 Controlling Night Light

To turn the night light on or off on the baby unit, press the 'Night Light' button on the parent unit. This allows for remote control of the light in your baby's room.

5.5 Understanding Temperature Display and Alarms

The parent unit's LCD screen continuously displays the temperature detected by the baby unit. If the temperature goes below 60.8°F (16°C) or above 86°F (30°C), an audible alarm will sound to alert you.

5.6 Voice Sensitivity Level

The baby unit has a voice sensitivity switch (H/L) on its back. 'H' (High) means it starts to transmit when voice is ≥ 50 dB. 'L' (Low) means it starts to transmit when voice is ≥ 60 dB. Adjust this setting based on the ambient noise level and your preference for sound detection.



Image: Detailed view of the parent unit with labels for all buttons and display features.

6. MAINTENANCE

6.1 Cleaning

Wipe the units with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure no liquid enters the units.

6.2 Battery Care

To maximize battery life, fully charge the units before extended periods of non-use. If using standard AAA batteries, remove them if the unit will not be used for a long time to prevent leakage.

6.3 Storage

Store the monitor in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

7.1 No Power / Unit Not Turning On

Ensure units are fully charged or have fresh batteries installed. Check that the power button is pressed and held until the unit activates.

7.2 No Sound / Poor Sound Quality

Check the volume level on the parent unit. Ensure both units are within range (up to 1000 ft line of sight, less indoors). Reduce interference from other electronic devices. Verify the voice sensitivity level (H/L) on the baby unit is set appropriately.

7.3 Out of Range Issues

Move the parent and baby units closer to each other. Obstacles like walls and furniture can reduce the effective range.

7.4 Temperature Alarm Issues

Ensure the baby unit is placed in an area that accurately reflects the room temperature, away from direct heat sources or drafts. The alarm range is 60.8°F - 86°F.

7.5 Re-pairing Units (If Needed)

If units lose connection, power off both. Power on the baby unit first, then the parent unit. They should automatically re-pair. If not, consult the full manual for specific re-pairing steps if available, or contact customer support.

8. SPECIFICATIONS

| Feature | Detail |
|-----------------------|---|
| Model Number | MOL1A2B220509 |
| Item Weight | 13.4 ounces |
| Package Dimensions | 8.43 x 4.17 x 2.44 inches |
| Country of Origin | China |
| Batteries | 3 AAA batteries required (included, rechargeable) |
| Number of Channels | 8 |
| Special Feature | Rechargeable & Portable |
| Frequency Range | 2.4GHz |
| Talking Range Maximum | 1000 Feet |

| | |
|------------------------|---------------------|
| Voltage | 9 Volts |
| Water Resistance Level | Not Water Resistant |

9. WARRANTY AND SUPPORT

The TimeFlys Audio Baby Monitor comes with a 1-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact TimeFlys customer service through the retailer's platform or the official TimeFlys website. Provide your product model number and a detailed description of the issue for prompt assistance.