

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Jata](#) /

> [Jata 499 Digital Bathroom Scale User Manual](#)

Jata HBAS1499

Jata 499 Digital Bathroom Scale

MODEL: HBAS1499

INTRODUCTION

Thank you for choosing the Jata 499 Digital Bathroom Scale. This scale is designed to provide precise weight measurements using its four high-precision sensors. A key feature of this model is its self-powering technology, which eliminates the need for batteries, making it an ecological and convenient choice. This manual provides essential information for the safe and effective use of your scale.

Key features include:

- **Battery-Free Operation:** Utilizes a push-button to generate sufficient energy for immediate use.
- **High Precision:** Equipped with four advanced sensors for accurate measurements.
- **Clear Display:** Large LCD screen shows results in kilograms (kg) and pounds (lb).
- **Durable Design:** Extra-flat platform made of 5 mm thick high-security tempered glass.
- **Overload Indicator:** Alerts when the weight exceeds the maximum capacity of 150 kg.

SAFETY INFORMATION

- Always place the scale on a hard, flat, and stable surface to ensure accurate readings.
- Do not use the scale on wet or slippery surfaces to prevent accidents.
- Keep the scale dry. Avoid exposure to water or excessive humidity.
- The maximum weight capacity is 150 kg (330 lb). Do not exceed this limit to prevent damage to the scale and potential injury.
- This scale is for personal use only and is not intended for medical diagnosis or commercial purposes.
- Do not jump on the scale or drop heavy objects on it.
- Keep out of reach of children.

SETUP

Unpacking and Placement

Carefully remove the scale from its packaging. Place the scale on a firm, flat, and level surface. Uneven surfaces can affect accuracy.



Image: Top view of the Jata 499 Digital Bathroom Scale, illustrating its sleek design, LCD screen, and the unique self-powering button.

Initial Activation (Battery-Free System)

The Jata 499 scale operates without batteries. To activate the scale for use, firmly press the central silver button located on the platform. This action generates the necessary power for the scale to function. The LCD display will illuminate, indicating it is ready for measurement.



Image: Close-up of the self-powering button and LCD display, showing the scale ready for use with '0.0 kg' displayed.

OPERATING INSTRUCTIONS

Taking a Measurement

1. Place the scale on a hard, flat surface.
2. Press the central silver power button to activate the scale. The display will show '0.0 kg' (or '0.0 lb').
3. Once '0.0' is displayed, step onto the scale barefoot and stand still. Distribute your weight evenly.
4. Your weight will be displayed on the LCD screen. The reading will flash or stabilize to indicate the final measurement.
5. Step off the scale. The scale will automatically turn off after a few seconds to conserve energy.

Unit Conversion (Kilograms/Pounds)

The Jata 499 scale can display measurements in both kilograms (kg) and pounds (lb). To switch between units, locate the unit conversion button, usually on the underside of the scale. Press this button while the scale is off or displaying '0.0' to toggle between kg and lb. The selected unit will be indicated on the LCD display.

MAINTENANCE

- **Cleaning:** Clean the scale with a soft, damp cloth. Do not use abrasive cleaners, chemical solvents, or immerse the scale in water.
- **Storage:** Store the scale in a dry place at room temperature. Avoid extreme temperatures or direct sunlight.
- **Handling:** Handle the scale with care. The tempered glass platform, while durable, can break if subjected to severe impact.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display shows 'Lo' or 'Err'	Insufficient power generated.	Press the central power button firmly again to generate more energy.
Display shows 'O-Ld'	Weight exceeds maximum capacity.	The maximum capacity is 150 kg (330 lb). Do not exceed this limit.
Inaccurate or inconsistent readings	Scale not on a flat, hard surface; scale moved between uses; initial calibration needed.	Ensure the scale is on a stable, level surface. For recalibration, press the power button, wait for '0.0', then step on. Avoid moving the scale frequently.
No display after pressing button	Button not pressed firmly enough or quickly enough.	Press the central power button with a quick, firm motion to ensure sufficient energy generation.

SPECIFICATIONS

Feature	Detail
Model Number	HBAS1499
Manufacturer	JATA HOGAR
Product Dimensions (L x W x H)	32 x 26 x 4 cm
Product Weight	1 Kilogram
Maximum Weight Capacity	150 Kilograms
Measurement Precision	99% (4 high-precision sensors)
Display Type	LCD

Feature	Detail
Material	Tempered Glass
Color	Black
Power Source	Self-generating (no batteries required)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact Jata customer service directly. Keep your proof of purchase for any warranty claims.