

[Manuals.plus](#) /

› [MediAcous](#) /

› MediAcous Baby Night Light User Manual

MediAcous DE-NL01-03

MediAcous Baby Night Light User Manual

Brand: MediAcous | Model: DE-NL01-03

INTRODUCTION

The MediAcous Baby Night Light (Model DE-NL01-03) is designed to provide a comforting and safe lighting solution for children's rooms. This rechargeable night light features 7 color-changing options, dimming functionality, a 1-hour timer, and intuitive touch controls. Made from baby-safe materials, it offers a gentle, eye-caring LED light perfect for nighttime feeding, diaper changes, and creating a soothing environment for sleep.



Image: The MediAcous Baby Night Light, an egg-shaped lamp emitting a warm glow.

PRODUCT FEATURES

- **Attractive LED Colors:** In RGB mode, the night light cycles through 8 velvety colors. Tap the top for 0.5 seconds to fix your preferred color.
- **Baby-safe Night Light:** Constructed from toy-grade ABS and PC material, ensuring 100% safety for children. The anti-blue LED light prevents flickering and eye strain.
- **Easy Touch Control:** Long press the top for stepless dimming. Tap the top twice to turn the light on/off. Hold the top for 1.5 seconds to activate night light mode, ideal for late-night feeding and diaper changes.
- **Long-Lasting Battery:** Equipped with a large capacity built-in battery, providing up to 100 hours of use in the

dimmest setting or 5 hours in the brightest setting. An LED indicator blinks red when the battery is low.

- **1-Hour Timer:** Press the 1H timer button on the bottom to automatically turn off the light after one hour, conserving energy. The LED indicator turns green when the timer is active.
- **Memory Function:** The light is equipped with a memory function. It will automatically recall the last brightness or color setting used when turned back on, provided the main power switch was not turned off.

SETUP

1. Unboxing and Initial Charge

Carefully remove the night light from its packaging. Before first use, fully charge the device using the provided USB cable. Connect the USB cable to the charging port located at the bottom of the light and plug the other end into a compatible USB power adapter (not included). The LED indicator will show charging status.



Image: Underside of the night light, highlighting the USB charging port and control buttons.

2. Power On/Off Switch

Locate the main power switch on the bottom of the night light. Slide the switch to the "ON" position to activate the device. Slide it to "OFF" when not in use for extended periods to conserve battery life.

OPERATING INSTRUCTIONS

1. Warm Light Mode and Brightness Adjustment

To activate the warm white light mode, ensure the switch on the bottom is set to the warm light icon. Once in warm light mode, long press the top surface of the light to adjust the brightness steplessly. Release your finger when the desired brightness is reached.



Image: Visual guide demonstrating touch controls for power, dimming, and night light mode.

2. RGB Color Changing Mode

To enter RGB color changing mode, slide the switch on the bottom to the RGB icon. The light will automatically cycle through 8 velvety colors. To fix a specific color, tap the top surface of the light for approximately 0.5 seconds when your desired color appears.

Multicolor Kids Night Light

8 velvety colors can be changed freely in color mode
Tap once to fix your favorite color



Image: The night light showcasing its range of 8 vibrant colors.

3. Power On/Off (Touch Control)

While the main switch is ON, double-tap the top surface of the light to turn it on or off.

4. Night Light Mode (1.5s Hold)

For a very dim, gentle light suitable for night feeding or diaper changes, hold the top surface for 1.5 seconds. This activates a specific low-light setting.

Warm Nursery Night Light

Perfect for breastfeeding and diaper changing at night



Breastfeeding



Diaper Change



Image: A mother feeding her baby at night, illuminated by the soft glow of the night light, demonstrating its use for breastfeeding and diaper changes.

5. 1-Hour Timer Activation

To activate the 1-hour timer, press the dedicated timer button located on the bottom of the night light. A green LED indicator will illuminate to confirm the timer is active. The light will automatically turn off after one hour.

2000 mAh Built-in Battery

Work for 100 hours in low light mode



✓ **AUTO-OFF Time**



Image: A child sleeping peacefully with the night light, illustrating its long-lasting battery and auto-off timer feature.

6. Memory Function

The night light is equipped with a memory function. It will automatically recall the last brightness or color setting used when turned back on, provided the main power switch was not turned off.

No more resetting, It remembers !

Help you remain the last setting for brightness or color



Image: A baby interacting with the night light, emphasizing the memory function that retains the last setting.

MAINTENANCE

- **Cleaning:** To clean the night light, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Recharge the light when the low battery indicator blinks red. If storing for a long period, charge the battery every 3 months to maintain its health.
- **Storage:** Store the night light in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	Main power switch is OFF. Battery is depleted.	Ensure the main power switch on the bottom is set to ON. Charge the night light using the USB cable.
Brightness adjustment not working.	Not in warm light mode. Incorrect touch gesture.	Ensure the bottom switch is set to the warm light icon. Perform a long press on the top surface to adjust brightness.
Color changing not working.	Not in RGB mode.	Ensure the bottom switch is set to the RGB icon.
1-Hour Timer not activating.	Timer button not pressed correctly.	Press the 1H timer button firmly on the bottom of the light. Look for the green LED indicator.
Short battery life.	Light used on brightest setting frequently. Battery not fully charged.	Fully charge the device. Note that brighter settings consume more power.

SPECIFICATIONS

Attribute	Detail
Brand	MediAcous
Model Number	DE-NL01-03
Product Dimensions	9.3 x 9.3 x 11.5 cm
Item Weight	220 g (0.22 Kilograms)
Battery	1 Lithium Ion battery required (built-in)
Material	Toy-grade ABS and PC (Acrylonitrile Butadiene Styrene)
Light Type	Light Emitting Diode (LED)
Switch Type	Touch
Color	Cream (Shade)
Country of Origin	China

OFFICIAL PRODUCT VIDEO

Video: An official product video demonstrating the features and usage of the MediAcous Baby Night Light, including color changing, dimming, and touch controls.

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official MediAcous website. Keep your purchase receipt as proof of purchase for any warranty claims.

Contact: For further assistance, please reach out to MediAcous customer service through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question