

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gotrax](#) /
- › [Gotrax GXL V2 Electric Scooter User Manual](#)

Gotrax GXL V2

Gotrax GXL V2 Electric Scooter User Manual

Model: GXL V2

1. PRODUCT OVERVIEW

The Gotrax GXL V2 Electric Scooter is designed for efficient and reliable personal transportation. It features a lightweight aluminum alloy frame, an 8.5-inch tire, and a 250W motor, making it suitable for adults for commuting and recreational use. This model is recognized for its classic design and robust build quality, ensuring a safe and smooth riding experience.






Figure 1: Gotrax GXL V2 Electric Scooter, showcasing its sleek design and sturdy build.

Key features include a large digital console, extended battery life, a front headlight for visibility, and UL2272 certification for safety. The scooter is also equipped with EABS and a rear disk brake system for effective stopping power.



Figure 2: Visual representation of key features including travel distance, top speed, braking system, tire size, folding system, and motor power.

2. SETUP

Initial setup of your Gotrax GXL V2 Electric Scooter involves minimal assembly and charging. Ensure all packaging materials are removed and inspect the scooter for any visible damage before proceeding.

2.1 Unfolding the Scooter

1. Place the scooter on a flat, stable surface.
2. Locate the folding mechanism near the base of the handlebar stem.
3. Carefully release the latch and lift the handlebar stem until it locks securely into the upright position. Ensure the locking mechanism is fully engaged to prevent accidental folding during operation.



Figure 3: The scooter's one-touch folding system allows for easy storage and portability.

2.2 Initial Charging

Before first use, fully charge the scooter's battery. The charging time is approximately 6 hours. Use only the charger included with your scooter.

1. Locate the charging port on the scooter.
2. Connect the charger to the scooter, then plug the charger into a standard electrical outlet.
3. The indicator light on the charger will change (e.g., from red to green) when charging is complete.



Figure 4: The scooter features a replaceable battery, offering a maximum distance range of 15 kilometers.

3. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and safety features before operating the scooter.

3.1 Powering On/Off and Digital Display

To power on the scooter, press and hold the power button located on the digital display. The display will illuminate, showing information such as speed, mileage, and battery level. To power off, press and hold the power button again.

Smart LED Display



Figure 5: The Smart LED Display provides real-time information including speedometer, Km/Mile unit, battery indicator, headlight status, and cruise control activation.

3.2 Riding the Scooter

1. Place one foot firmly on the deck and push off with the other foot to gain initial momentum.
2. Once moving, gently press the throttle (gas) lever on the right handlebar to accelerate.
3. To activate cruise control, reach a desired speed and then press the dedicated cruise control button. The scooter will maintain this speed without continuous throttle input. To disengage cruise control, simply apply the brake.
4. To slow down or stop, use the rear disk brake lever on the left handlebar.

3.3 Headlight and Bell

The scooter is equipped with a bright front headlight for enhanced visibility, especially during low-light conditions. Activate the headlight via the digital display controls. A bell is also integrated for alerting pedestrians or other vehicles to your presence.



Figure 6: The bright headlight ensures visibility and safety during night rides or in low-light environments.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Gotrax GXL V2 Electric Scooter.

4.1 Battery Care

- Always charge the battery fully before first use.
- Avoid completely draining the battery before recharging.
- Store the scooter in a cool, dry place when not in use, and ensure the battery is partially charged if storing for extended periods.
- Use only the official Gotrax charger provided with the scooter.

4.2 General Cleaning and Inspection

- Wipe down the scooter with a damp cloth after use to remove dirt and debris. Avoid using harsh chemicals or abrasive materials.

- Regularly check the tires for proper inflation and signs of wear. The 8.5-inch anti-puncture solid tires require minimal maintenance.
- Inspect the brakes for proper function and adjust if necessary.
- Ensure all screws and fasteners are tight before each ride.

5. TROUBLESHOOTING

This section provides solutions to common issues you might encounter.

5.1 Scooter Not Turning On

- Ensure the battery is sufficiently charged. Connect the charger and allow it to charge for at least 30 minutes before attempting to power on again.
- Verify that the power button is being pressed and held correctly.

5.2 Reduced Performance or Range

- Check the battery level on the digital display. Reduced performance is often an indication of a low battery.
- Consider factors such as rider weight, terrain (uphill climbs), and riding style (frequent acceleration/braking) which can affect range.
- Ensure tires are in good condition.

5.3 Braking Issues

- Inspect the rear disk brake for any obstructions or damage.
- If braking feels weak, the brake cable may need adjustment. Consult a qualified technician if you are unsure how to perform this adjustment.

For persistent issues not covered here, please contact Gotrax customer support.

6. SPECIFICATIONS

Detailed technical specifications for the Gotrax GXL V2 Electric Scooter.

Feature	Specification
Brand	Gotrax
Model Name	GXL V2
Color	Matt Black
Age Range (Description)	Adult
Weight Limit	100 Kilograms (220 lbs)
Item Weight	12 Kilograms (26.4 lbs)
Product Dimensions (L x W x H)	42.91" x 16.93" x 44.49"
Wheel Size	8.5 Inches
Wheel Type	Solid (Anti-Puncture)
Frame Material	Aluminum
Brake Style	Rear Braking (EABS and Rear Disk Brake)
Maximum Distance Range	15 Kilometers (approx. 9.3 miles)
Charging Time	6 Hours
Motor Power	250W
Top Speed	25 Km/h (approx. 15.5 mph)
Special Features	Anti-Puncture Tire, Cruise Control, Digital Display, Foldable, Lights, Lightweight, Non Slip Deck, Rechargeable, Replaceable Battery, Speedometer, Wide Platform



Figure 7: Detailed product dimensions and load capacity for the GXL V2 scooter.

7. WARRANTY AND SUPPORT

The Gotrax GXL V2 Electric Scooter comes with a **1 year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use conditions.

For warranty claims, technical support, or any inquiries regarding your scooter, please refer to the official Gotrax website or contact their customer service directly. Keep your proof of purchase for warranty validation.

For more information, visit the [Gotrax Store on Amazon](#).

