

Koss Porta Pro Utility

Koss Porta Pro Utility On-Ear Headphones Instruction Manual

Model: Porta Pro Utility | Brand: Koss

1. INTRODUCTION

Thank you for choosing the Koss Porta Pro Utility On-Ear Headphones. These headphones combine classic design with modern functionality, featuring a detachable and interchangeable cord system, a collapsible design for portability, and adjustable temporal pads for personalized comfort. This manual provides essential information for setting up, operating, and maintaining your headphones.



Figure 1: Koss Porta Pro Utility On-Ear Headphones, Stealth Grey.

2. FEATURES

- **Open-Back, On-Ear Design:** Provides a wide soundstage and allows for environmental awareness.
- **Comfort Zone - Adjustable Temporal Pads:** Customize the fit and pressure on your ears for extended listening comfort.
- **Audiophile Sound Performance:** Engineered for clear and rich audio reproduction.
- **Collapsible Design:** Folds compactly for easy storage and transport.
- **Detachable Interchangeable Cord System:** Allows for easy replacement or upgrade of the audio cable.
- **Included 3.5mm Utility Cord:** Standard audio cable for broad device compatibility.
- **Lightweight Construction:** Designed for comfortable wear during long listening sessions.



Figure 2: Detachable 3.5mm Utility Cord connection.

3. SETUP

1. **Unfolding the Headphones:** Gently unfold the headphones from their compact position. The earcups will pivot outwards, and the headband will extend.
2. **Connecting the Audio Cable:** Insert the 2.5mm end of the included 3.5mm Utility Cord into the designated port on the left earcup. Ensure it clicks securely into place. Insert the 3.5mm jack into your audio device.
3. **Adjusting the Headband:** Place the headphones on your head. Adjust the metal headband by sliding the earcup supports up or down until the earcups rest comfortably on your ears.
4. **Setting the Comfort Zone:** Locate the 'ComfortZone' sliders above each earcup. Adjust the slider to your preferred setting: 'Light' for less pressure or 'Firm' for a more secure fit.



Figure 3: Adjusting the ComfortZone for optimal fit.

4. OPERATING

- **Audio Playback:** Once connected to your audio device, begin playback. Adjust the volume using your device's controls or the inline media control on the cable (if present on your specific utility cord).
- **Using the Microphone:** If your utility cord includes an inline microphone, ensure it is positioned appropriately for clear voice capture during calls or voice commands.
- **Collapsing for Storage:** To store, slide the earcup supports inwards along the headband until the headphones fold into a compact form. Use the integrated hook to secure them.

Video 1: Product Overview of Koss Porta Pro Utility Headphones, demonstrating features and use.

Video 2: Koss Utility Series overview, highlighting the interchangeable cable system.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headphones. Avoid using harsh chemicals or abrasive materials.
- **Ear Cushion Replacement:** The foam ear cushions are replaceable. Gently remove worn cushions and snap new ones into place. Replacement cushions may be available from Koss or authorized retailers.
- **Cable Care:** The detachable cable system allows for easy replacement if the cable becomes damaged. Always handle the cable by the connectors when plugging or unplugging to prevent strain.
- **Storage:** When not in use, collapse the headphones and store them in the included carry pouch to protect them from dust and damage.



Figure 4: Headphones folded for compact storage.

6. TROUBLESHOOTING

- **No Sound:**
 - Ensure the audio cable is securely connected to both the headphones and the audio device.
 - Check the volume levels on your audio device and the inline control.
 - Test the headphones with another audio device or try a different audio cable to rule out a faulty component.
- **Poor Sound Quality:**
 - Verify the audio source is of good quality.
 - Ensure the audio cable is fully inserted and not damaged.
 - Adjust the ComfortZone sliders to ensure proper earcup placement and seal.
- **Comfort Issues:**
 - Adjust the headband length and ComfortZone sliders to find your optimal fit.
 - Ensure ear cushions are properly seated and not worn out.

7. SPECIFICATIONS

Specification	Detail
Model Name	Porta Pro Utility
Brand	Koss
Connectivity Technology	Wired
Ear Placement	On Ear
Impedance	60 Ohms
Headphones Jack	3.5 mm Jack
Frequency Response	5Hz-25kHz (from product description, not in specs table)
Item Weight	5.9 ounces (0.17 Kilograms)
Included Components	Cable, Carry Pouch
Special Feature	Microphone Included, USB connectivity (via optional cables)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Koss website. You may also contact Koss customer service directly for assistance with product inquiries, troubleshooting, or replacement parts.

Koss Customer Service: Please visit www.koss.com for contact details and support resources.

