

[Manuals.plus](#) /

› [ANFIER](#) /

› ANFIER W10 AI Voice Translator Instruction Manual

ANFIER W10

ANFIER W10 AI Voice Translator

INSTRUCTION MANUAL

Introduction

The ANFIER W10 AI Voice Translator is a state-of-the-art device designed to facilitate seamless communication across language barriers. With support for 144 online languages and accents, and 16 offline languages, it offers instant two-way translation. Its 3.0-inch touchscreen and image translation capabilities make it an indispensable tool for international travel, business, and learning.



Figure 1: The ANFIER W10 AI Voice Translator, showcasing its sleek design and touchscreen interface on the front, and the camera and speaker on the back.

Setup

Package Contents

Before first use, please ensure all items are present in the package:

- ANFIER W10 AI Voice Translator Device
- USB-C Charging Cable
- User Manual (this document)

Charging the Device

The device is equipped with a 1500mAh battery. For optimal performance, fully charge the device before initial use. Connect the provided USB-C charging cable to the device's charging port and plug the other end into a compatible USB power adapter (not included). A full charge typically takes 1-2 hours.

The battery provides up to 8 hours of continuous use and can last up to a week on standby.

Power On/Off

- **To Power On:** Press and hold the Power button located on the side of the device until the screen illuminates.
- **To Power Off:** Press and hold the Power button until a power-off menu appears on the screen. Select "Power Off" to shut down the device.

Network Connection

For online translation features, the ANFIER W10 requires an internet connection. Navigate to the "Settings" menu on the device and select "Wi-Fi Setting" to connect to an available Wi-Fi network. The device supports online translation for 144 languages and accents.

The device also supports offline translation for 16 commonly used languages. To enable offline translation, ensure the necessary language packages are downloaded via the "Offline Package Download" option in the settings menu. This allows for translation without an active internet connection.

HD Touch Screen

480*854 3.0" retina screen for easy operation and clear display



Figure 2: The device's 3.0-inch HD Touch Screen, illustrating the intuitive interface and access to settings for Wi-Fi and language options.

Operating Instructions

The ANFIER W10 offers various translation modes to suit different communication needs.

Voice Translation

This is the primary mode for real-time, two-way voice communication. Select "Voice Translation" from the main menu. Choose your source and target languages. Press and hold the designated button (often indicated by a microphone icon) to speak, then release to hear the translation. The device boasts a response time of less than 0.5 seconds and a 97% test accuracy.

Realtime Two-way Translation

97%
Accuracy

127+
Languages

0.5s
Rapid Translation



Figure 3: Real-time two-way voice translation in action, showing the rapid and accurate conversion of spoken language between two users.

Image Translation

For translating text from signs, menus, or documents, use the "Photo Translation" feature. The device supports photo translation in 42 languages and can recognize both print and handwritten fonts. Open the "Photo Translate" application, align the text within the camera frame, and capture the image. The translated text will appear on the screen.



Figure 4: The Photo Translation feature, capable of translating text from images in 42 different languages, useful for signs and documents.

Recording and Playback

The "Recording" function allows you to record conversations or speeches. These recordings can then be played back or translated. The device features dual noise-reducing microphones and an advanced speaker for clear audio capture and playback, even in noisy environments.

Additional Features

- **Text Translation:** Manually input text for translation.
- **Simultaneous Interpretation:** For continuous, real-time translation in specific scenarios.
- **Favorites:** Save frequently used phrases or translations for quick access.

Official Product Video: ANFIER Language Translator Device W10

Your browser does not support the video tag.

This video provides a comprehensive overview of the ANFIER W10 AI Voice Translator, demonstrating its key features including voice translation, photo translation, and user interface navigation. It highlights the device's ease of use and various functionalities for effective communication.

Maintenance

Cleaning the Device

To maintain the device's appearance and functionality, wipe it regularly with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these can damage the screen or casing.

Software Updates

Periodically check for software updates via the "Check update" option in the device's settings. Updates can improve performance, add new features, and enhance language accuracy.

Battery Care

To prolong battery life, avoid exposing the device to extreme temperatures. If the device will not be used for an extended period, charge it to approximately 50% before storing.



Figure 5: Overview of the device's long-lasting battery performance, offering extended use and standby times.

Troubleshooting

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Device does not power on.	Low battery; device frozen.	Charge the device for at least 30 minutes. If still unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
"Network connection failed" error.	No Wi-Fi connection; weak signal.	Check Wi-Fi settings and ensure connection. Move closer to the Wi-Fi router. For offline use, ensure language packages are downloaded.
Inaccurate translation.	Unclear speech; background noise; complex jargon.	Speak clearly and directly into the microphone. Reduce background noise. Ensure correct language pair is selected. The device is designed to understand jargon and slang terms, but complex or highly specialized vocabulary may require rephrasing.
Photo translation not working.	Poor lighting; blurry image; unsupported font.	Ensure adequate lighting. Hold the device steady to avoid blur. The device recognizes print and handwritten fonts, but highly stylized fonts may be difficult to interpret.
Device not charging.	Faulty cable/adapter; dirty charging port.	Try a different USB-C cable and power adapter. Clean the charging port gently with a dry, soft brush.

Factory Reset

If persistent issues occur, a factory reset can resolve them. Navigate to "Settings" > "Restore factory settings". **Warning:** This will erase all user data and settings on the device.

Specifications

Feature	Detail
Model	W10
Display	3.0 inch TFT (IPS) Touch-Screen (480*854 resolution)
Memory	1G RAM + 8G ROM
Camera	5.0M Pixels
Battery	1500mAh Lithium Ion (2 required, included)
Continuous Use Time	Up to 8 hours
Standby Time	Up to 7 days
Charging Time	1-2 hours (via USB-C)
Online Translation	144 Languages & Accents

Feature	Detail
Offline Translation	16 Languages
Image Translation	42 Languages
Dimensions	6.3 x 3.43 x 1.73 inches
Item Weight	9.2 ounces
Manufacturer	ANFIER
Country of Origin	China



Figure 6: Key product parameters and features of the ANFIER W10 translator.

Warranty and Support

ANFIER provides professional after-sales support for its language translators. If you encounter any questions or issues during the use of your ANFIER W10 device, please contact our customer service team. We are committed to assisting you until you are satisfied.

For additional information and resources, you may refer to the official [User Manual \(PDF\)](#) available online.

