

iFLYTEK M110

iFLYTEK A.I.Smart Mouse M110 Instruction Manual

Model: M110 | Brand: iFLYTEK

INTRODUCTION

The iFLYTEK A.I.Smart Mouse M110 is an advanced computer peripheral designed for enhanced productivity and convenience. It features multi-language online transcription, dual-device connectivity, and an ergonomic design for comfortable use. This manual provides detailed instructions for setting up, operating, and maintaining your device.



Image: Top view of the iFLYTEK A.I.Smart Mouse M110, showcasing its sleek black design and scroll wheel.

SETUP GUIDE

1. Initial Setup (USB Receiver Connection)

- Unpack the Mouse:** Carefully remove the mouse from its packaging.
- Locate the USB Receiver:** The USB receiver is stored inside the mouse. To access it, gently hold the button position on both sides of the mouse's face shell and lift the shell.
- Remove the USB Receiver:** Take out the small USB receiver from its storage compartment.

4. **Power On the Mouse:** Turn the power switch located on the back of the mouse to the "ON" position. A green Bluetooth signal light will flash slowly for a few seconds and then go out, indicating it's ready for connection.
5. **Connect to Computer:** Insert the USB receiver into an available USB port on your computer. The mouse's Bluetooth signal light will briefly turn on and then go out, indicating a successful connection. The mouse is now ready for normal use.



Image: The iFLYTEK A.I.Smart Mouse M110 positioned between a laptop and a desktop, illustrating its connectivity options.

2. Installing Voice Assistant Software

To utilize the voice typing features, you need to install the iFLYTEK Voice Assistant software. Ensure your computer's system language is set to English before proceeding, as the interface of the installed software might otherwise default to Chinese.

1. **Open Download Interface:** Long press the voice button on the mouse for 5 seconds. Your computer will automatically open the download interface for the iFLYTEK Smart Mouse/Keyboard software.
2. **Download the Software:** Click the "Win Download" button (for Windows) or "Mac Download" button (for macOS). A

download pop-up box will appear. Select "Save to desktop" and click "Save".

3. **Install the Software:** Once downloaded, locate the software file on your desktop and double-click to open it. The Voice Assistant installation wizard will appear. Follow the prompts, clicking "Next" as required. During the installation, a device driver installation wizard may pop up; click "Next" to proceed.
4. **Complete Installation:** The voice assistant software will be installed. Accept the privacy policy when prompted.

3. Bluetooth Connection Mode

The iFLYTEK A.I.Smart Mouse M110 also supports Bluetooth connection. Ensure the USB receiver is unplugged from your computer before attempting Bluetooth pairing.

1. **Enable Bluetooth on Computer:** Turn on the Bluetooth function of your computer.
2. **Activate Mouse Pairing Mode:** With the mouse powered on (green light flashing slowly), long press the "Reset" button at the bottom of the mouse for 3 seconds. The Bluetooth signal light will then flash quickly, indicating it's in pairing mode.
3. **Pair the Device:** On your computer, navigate to the Bluetooth settings. Find and click on the connection named "M110" in the list of available Bluetooth devices.
4. **Confirm Pairing:** After successful pairing, the mouse's Bluetooth signal light will be continuously on for several seconds and then go out. The mouse is now connected via Bluetooth.

OPERATING INSTRUCTIONS

1. Basic Mouse Functions

The iFLYTEK A.I.Smart Mouse M110 functions as a standard computer mouse, offering precise cursor control, left and right clicks, and smooth scrolling with its scroll wheel.

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls content vertically.
- **Mute Button:** The mouse features a mute button to eliminate click sounds, providing a quiet working environment.

2. Voice Typing Feature

The A.I.Smart Mouse M110 offers an advanced voice typing feature, supporting 27 languages with an average accuracy rate of over 85% and an input speed of up to 400 words per minute.

1. **Activate Voice Input:** Click and release the voice button on the mouse to begin speaking.
2. **Speak Clearly:** Speak clearly into the mouse's microphone. Your spoken words will be transcribed into text on your computer.
3. **End Voice Input:** After speaking, click the mouse button again to end the voice input session.

3. Dual-Device Switching

The mouse M110 has two connection channels, allowing it to connect to and switch between up to two devices. One color indicator represents one channel (e.g., green for Channel 1, pink for Channel 2).

1. **Connecting to First Device (Channel 1 - USB Receiver):**
 - Turn the power switch on the back of the mouse to the "ON" position. The green Bluetooth signal light will flash slowly.
 - Long press the "Reset" button at the bottom of the mouse for 3 seconds. The Bluetooth signal light will flash

quickly.

- Insert the USB receiver into the computer's USB port. When the Bluetooth signal light is always on for several seconds and then goes out, the mouse is successfully connected to the first device.

2. Connecting to Second Device (Channel 2 - Bluetooth):

- Ensure the USB receiver is unplugged.
- Short press the "Reset" button at the bottom of the mouse. The pink Bluetooth signal light will flash slowly.
- Long press the "Reset" button at the bottom of the mouse for 3 seconds. The Bluetooth signal light will flash quickly.
- On your computer, enable Bluetooth and find and click "M110" in the Bluetooth device list to pair. When the Bluetooth signal light is always on for several seconds and then goes out, the mouse is successfully connected to the second device.

3. Switching Between Devices:

To switch between connected devices, short press the "Reset" button at the bottom of the mouse. The Bluetooth signal light of the active channel will briefly turn on and then go out, indicating the switch. For example, if you are using the mouse on the second computer, short pressing the reset button will switch it back to the first computer.



Image: A display of iFLYTEK A.I.Smart Mouse M110 in various colors, highlighting its ergonomic design.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** The mouse features long battery endurance (up to 1 month). When the battery is low, replace it with new batteries as per the instructions.
- **Storage:** Store the mouse in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

- **Mouse Not Responding:**
 - Check if the mouse is powered on.
 - Ensure the USB receiver is properly inserted into the computer's USB port, or that Bluetooth is correctly paired.
 - Replace the batteries if they are low.
 - Try connecting the mouse to a different USB port or re-pairing via Bluetooth.
- **Voice Typing Not Working:**
 - Verify that the iFLYTEK Voice Assistant software is correctly installed and running.
 - Check your computer's microphone settings to ensure the mouse's microphone is selected and enabled.
 - Ensure a stable internet connection for online transcription.
- **Connection Issues:**
 - If using the USB receiver, ensure no other wireless devices are causing interference.
 - If using Bluetooth, ensure your computer's Bluetooth is enabled and the mouse is within range. Try unpairing and re-pairing the device.

SPECIFICATIONS

Feature	Detail
Brand	iFLYTEK
Model	M110
Color	Black
Special Feature	Ergonomic Design
Number of Buttons	3
Hand Orientation	Ambidextrous
Voice Transcription	27 languages, >85% accuracy
Input Speed	Up to 400 words per minute
Connectivity	Dual-device switch (USB receiver & Bluetooth)
Weight	86g
Battery Endurance	Up to 1 month

WARRANTY AND SUPPORT

iFLYTEK products come with a standard manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official iFLYTEK website.

For technical support, troubleshooting assistance, or any inquiries regarding your iFLYTEK A.I.Smart Mouse M110, please contact iFLYTEK customer service. Contact information can typically be found on the product packaging or the official iFLYTEK support page.

Documents - iFLYTEK – M110

no relevant documents