

[Manuals.plus](#) /

> [Joovy](#) /

> Joovy Kooper RS2 Double Stroller Instruction Manual

Joovy 08517

Joovy Kooper RS2 Double Stroller Instruction Manual

Model: 08517

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using your Joovy Kooper RS2 Double Stroller. Failure to follow these instructions could result in serious injury or death to your child.

- **ALWAYS** secure your child with the harness system.
- **NEVER** leave children unattended in the stroller.
- **ALWAYS** engage the parking brake when placing or removing children from the stroller.
- **DO NOT** overload the stroller. Adhere to the maximum weight recommendations for children and storage.
- **ENSURE** all locking mechanisms are engaged before use.
- **AVOID** placing hot liquids or heavy items on the handlebar.
- **BE AWARE** of potential pinching hazards when folding or unfolding the stroller. Keep children clear of moving parts.
- **DO NOT** use the stroller on stairs or escalators.
- **THIS STROLLER IS NOT** suitable for car seat compatibility.

2. PRODUCT FEATURES

The Joovy Kooper RS2 Double Stroller is designed for comfort, convenience, and durability. Key features include:

- **Large Wheels:** Equipped with two 9-inch rear wheels and two 7-inch all-terrain front wheels for smooth maneuverability.
- **Independent Reclining Seats:** Multiple independent recline positions and adjustable footrests allow each child to customize their comfort.
- **Dual Swing-Open Snack Trays:** Includes removable inserts for easy cleaning.
- **Spacious Seating:** Features 3-inch longer seats than the original KooperX2, accommodating growing children.
- **Magnetic Buckles:** For easy one-handed securing and releasing of children.
- **Extra-Large, Water-Repellent Canopies:** Provide UPF 50 sun protection from various angles and include peek-a-boo screens.
- **One-Handed Fold:** Simple one-handed fold with a standing auto-lock for convenient storage and transport.
- **Ample Storage:** Features a large storage basket with a 22-pound capacity and two zippered pockets for personal items.

Kooper™ RS2

THE BEST TRAVEL STROLLER - NOW FOR TWO



SWING-OPEN TRAY

Designed so kids can't kick the tray and lose their snack, the tray features extra-deep cup holders for bumpy rides



EXTRA-LARGE WATER-REPELLANT CANOPY

Provides UPF 50 sun protection from almost any angle, unzips for even more coverage and includes a peek-a-boo window!



WHEELY-GOOD WHEELS

9" rear and 7" front wheels offer incredible maneuverability! Moving two little ones around has never been so easy, thanks to an extremely smooth push and all-terrain capability.



PLENTY OF STORAGE

Stash toys, shopping, and diapers in the spacious mesh basket underneath the carriage



RECLINING SEAT WITH FOOTREST

Let little ones kick back and relax! The Kooper's customizable recline won't limit access to the storage basket below

Figure 2.1: Overview of Joovy Kooper RS2 key features.

3. SETUP AND ASSEMBLY

Follow these steps to set up your Joovy Kooper RS2 Double Stroller:

1. **Unpack the Stroller:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Unfold the Stroller:** Place the stroller on a flat surface. Release the folding latch and lift the handlebar until the frame locks into place. Ensure all frame locks are securely engaged.
3. **Attach Snack Trays:** Align the snack trays with the designated slots on the front of each seat. Press firmly until they click into place.
4. **Adjust Canopies:** Extend the canopies over each seat as desired. The canopies are extendable for maximum sun protection.



Figure 3.1: The Joovy Kooper RS2 Double Stroller ready for use.

4. OPERATING THE STROLLER

4.1 Securing Your Child

To ensure your child's safety, always use the 5-point harness system:

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
3. Connect the magnetic buckles until they click securely.
4. Adjust the straps for a snug fit, ensuring your child cannot slip out.

4.2 Adjusting Seat Recline and Footrest

Each seat can be independently reclined and its footrest adjusted:

- **Seat Recline:** Locate the recline mechanism behind each seat. Squeeze the lever and adjust the seat to the desired position.
- **Footrest Adjustment:** Press the buttons on either side of the footrest and move it up or down to the desired height.

4.3 Engaging the Brake

The stroller features a one-step linked brake system:

- To engage the brake, press down firmly on the brake pedal located near the rear wheels.
- To release the brake, lift the pedal upwards.
- Always ensure the brake is fully engaged when the stroller is stationary.

4.4 Folding the Stroller

The Kooper RS2 features a super easy one-handed fold with a standing auto-lock:

1. Ensure both canopies are retracted and seats are in an upright position.
2. Locate the folding mechanism on the handlebar.
3. Activate the mechanism and push the handlebar forward and down until the stroller folds compactly and the auto-lock engages.
4. The stroller will stand independently when folded.



Figure 4.1: The stroller in its compact, folded state, easily carried.

4.5 Using Storage

Utilize the available storage options:

- **Storage Basket:** The large basket under the seats can hold up to 22 pounds.
- **Zippered Pockets:** Two zippered pockets are located on the back of the canopies for smaller items like phones, keys, or pacifiers.

5. MAINTENANCE AND CARE

Regular maintenance ensures the longevity and safety of your stroller:

- **Cleaning Fabric:** The seat material is made from recycled fabric. Spot clean with mild soap and warm water. Do not use bleach or harsh detergents. Allow to air dry completely.
- **Cleaning Frame:** Wipe the aluminum frame with a soft, damp cloth. Avoid abrasive cleaners.
- **Wheel Maintenance:** Regularly check wheels for debris and clean as needed. Lubricate moving parts with a silicone-based lubricant if they become stiff.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight to prevent fading and material degradation.

6. TROUBLESHOOTING

If you encounter any issues with your Joovy Kooper RS2, refer to the following common solutions:

- **Stroller not unfolding/folding smoothly:** Check for any obstructions in the folding mechanism. Ensure all fabric is clear of moving parts. Apply a silicone lubricant to hinges if necessary.
- **Wheels not turning freely:** Inspect wheels for trapped debris (e.g., hair, dirt). Clean thoroughly. Ensure the brake is not partially engaged.
- **Brake not engaging/disengaging:** Check the brake mechanism for obstructions. Ensure the pedal is fully pressed or lifted. If the issue persists, contact customer support.
- **Harness difficult to buckle/unbuckle:** Ensure no fabric is caught in the magnetic buckles. Clean buckles if sticky.

7. SPECIFICATIONS

Feature	Detail
Brand	Joovy
Model Number	08517
Color	Black
Frame Material	Aluminum
Seat Material	Recycled Fabric
Canopy Material	100% recycled fabric
Tire Material	Rubber
Age Range (Description)	Baby
Seating Capacity	2

Feature	Detail
Harness Type	5 Point
Harness Feature	Magnetic Buckles
Number of Wheels	4
Front Wheel Diameter	7 Inches
Back Wheel Diameter	9 Inches
Item Weight	31.3 Pounds
Maximum Weight Recommendation	100 Pounds (50 lbs per seat)
Basket Weight Capacity Maximum	22 Pounds
Item Dimensions L x W x H	35"L x 29.7"W x 42.7"H
Folded Size	29.9"L x 29.5"W x 12.6"H
Included Components	Child Trays
Specification Met	ASTM, JPMA

joovy
Kooper™ RS2
Lightweight Double Travel Stroller

AT JUST 31 LB., THE KOOPER RS2 IS PERFECT FOR KIDS UP TO 50 LB. EACH AND FEATURES A 22 LB. STORAGE CAPACITY. PLUS, IT EASILY FOLDS DOWN ONE-HANDED, AND THE TRAYS FOLD WITH IT!



Figure 7.1: Stroller dimensions and folded size.

8. OFFICIAL PRODUCT VIDEO

Video 8.1: Official Joovy Kooper RS2 product overview, demonstrating key features and functionality.

9. WARRANTY AND SUPPORT

Joovy products are designed for quality and durability. For specific warranty information, product registration, or to contact customer support, please visit the official Joovy website or refer to the warranty card included with your purchase. Keep your proof of purchase for warranty claims.