

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Marea](#) /

› Marea Smartwatch B58010/1 User Manual

## Marea B58010/1

# Marea Smartwatch B58010/1 User Manual

Model: B58010/1 | Brand: Marea

## INTRODUCTION

This manual provides detailed instructions for the Marea Smartwatch B58010/1. It covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using your smartwatch.

## SETUP

### Initial Charging and Activation

To activate your Marea Smartwatch, connect it to electrical power using the provided charging cable. If the battery is very low or if the watch has not been used for an extended period, plug in the charging cable and charge it for at least 30 minutes to reactivate the device. When using an adapter for power, ensure it has a maximum output of 5V-1A.

### Pairing with Your Smartphone

The Marea Smartwatch B58010/1 supports Bluetooth connectivity for various functions, including calls. To pair your watch with a smartphone:

1. Ensure your smartphone's Bluetooth is enabled.
2. Turn on your Marea Smartwatch.
3. Open the companion application on your smartphone (refer to the watch's packaging or quick start guide for app details).
4. Follow the on-screen instructions in the app to search for and connect to your smartwatch.
5. Confirm the pairing request on both your phone and the watch.

## OPERATING YOUR SMARTWATCH

Your Marea Smartwatch B58010/1 offers a wide range of features designed for daily convenience and health monitoring. Below are some key functionalities:

### Communication Features

- **Phone Calls:** Dial numbers directly from the watch and make calls.
- **Messages:** View the last 10 received messages.
- **Contacts:** Store and access up to 20 contacts for quick dialing.
- **Call Recording:** Record calls directly from your watch.





This image shows the Marea Smartwatch B58010/1 with its screen active, displaying a numeric keypad for making calls. The screen is black with white numbers (1-9, 0) arranged in a standard phone dialer layout. Icons for adding a plus sign, initiating a call, and accessing the full keypad are visible at the bottom. A small 'X' icon for clearing input is at the top right. The watch has a black rubber band and a dark grey casing.

## Health and Fitness Tracking

- **Activity Data:** Track steps, distance traveled, and calories burned.
- **Sport Modes:** Access various sport modes for different activities.
- **Heart Rate:** Monitor your heart rate.
- **ECG:** Perform electrocardiogram readings.
- **Blood Pressure:** Measure your blood pressure.
- **Blood Oxygen:** Monitor blood oxygen levels.
- **Sleep Monitor:** Track your sleep patterns.

## Additional Features

- **Music Remote Control:** Control music playback on your connected device.
- **Chronograph:** Use the stopwatch function.
- **Climate/Weather:** Get real-time weather updates.
- **Calculator:** Perform basic calculations.
- **Phone Finder:** Locate your paired smartphone.
- **Breathing Guide:** Guided breathing exercises.
- **Massager:** Utilize the watch's vibration for a massage function.
- **Assistant:** Access a smart assistant.
- **Feminine Functions:** Specific features for female users.
- **Customizable Home Screen:** Personalize your watch face.

- **Password:** Set a password for enhanced security.

## MAINTENANCE

### Water Resistance (IP67)

The Marea Smartwatch B58010/1 has an IP67 resistance rating, meaning it is suitable for daily life use and can withstand splashes and brief immersion. However, it is **not** designed for:

- Diving or prolonged submersion under water.
- Use in hot showers or baths, as water vapor can damage the watch.
- Exposure to saltwater, which can also cause damage.

Avoid exposing the watch to extreme temperatures or harsh chemicals.

### Cleaning

Wipe the watch and band regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.

## TROUBLESHOOTING

### Health Data Accuracy

The heart rate, ECG, blood pressure, and blood oxygen readings provided by the Marea Smartwatch B58010/1 are for recreational use only. The optical sensor used does not achieve the precision and accuracy of a professional medical device and cannot guarantee stable, equivalent readings. This watch cannot replace a medical device for detecting or diagnosing pathologies, heart conditions, or other diseases. Factors such as skin contact level, pigmentation, tattoos, and arm movements can affect the accuracy of the sensor's data.

### Watch Not Turning On/Charging

If your watch does not turn on or charge, ensure it is connected to the charging cable and a power source (max 5V-1A adapter). If the battery is completely depleted or the watch has been unused for a long time, it may require more than 30 minutes of charging to reactivate.

## SPECIFICATIONS

Feature	Detail
Brand	Marea
Model Number	B58010/1
Color	Black Rubber

Feature	Detail
Screen Size	1.75 Inches
Screen Type	IPS Full Touch Screen, LTPS LCD
Resolution	320 x 385
Dimensions	37 x 43 mm
CPU	Realtek 8762DK
Compatible System	Android 4.4 or higher / iOS 8.0 or higher
Connectivity Technology	Bluetooth
Wireless Communication Standard	Bluetooth
Water Resistance Rating	IP67
Battery Composition	Silver Oxide (1 included)
Special Features	Calculator, Chronograph
GPS	Integrated GPS
Shape	Round
Target Audience	Unisex - adult
Manufacturer	Marea
Date First Available on Amazon.com.be	23 May 2022
Spare Parts Availability	Information not available
Software Updates Guaranteed Until	Information not available

## WARRANTY INFORMATION

Specific warranty details for the Marea Smartwatch B58010/1 are not provided in the product description. Please refer to the product packaging or contact the retailer/manufacturer directly for comprehensive warranty terms and conditions.

## CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Marea customer support or your point of purchase. Keep your purchase receipt and product model number (B58010/1) ready when contacting support.

