



Manuals.plus /

- › Colgate /
- › Colgate Advanced Electric Toothbrush User Manual

## Colgate 61024519

# Colgate Advanced Electric Toothbrush

## USER MANUAL

Model: 61024519

### Introduction

The Colgate Advanced Electric Toothbrush offers a customized brushing experience with up to 33 combinations of 4 brushing modes and 10 intensity settings. It features a responsive smart pressure sensor to prevent excessive brushing force and a built-in quad pacer to guide brushing duration. Designed for convenience, it provides up to 15 days of use on a single charge.



Image: The Colgate Advanced Electric Toothbrush alongside its retail packaging, highlighting its sleek design and presentation.

## Setup

### What's in the Box

Upon unboxing your Colgate Advanced Electric Toothbrush, please verify that all components are present:

- Electric toothbrush handle
- Brush head (Soft)
- Travel pouch
- DC charging cable

The Colgate logo is displayed in white text on a red circular background.

# What comes in a box

- Electric Toothbrush Handle
- Brush Head (Soft)
- Travel Pouch
- DC Charging Cable



Image: A visual representation of the items included in the product box: the toothbrush handle, brush heads, travel pouch, and charging cable.

## Operating Your Toothbrush

### Modes and Intensities

The Colgate Advanced Electric Toothbrush offers 4 distinct brushing modes and 10 intensity levels, allowing for a personalized brushing experience.

Colgate

**4 Brush Modes,  
10 levels of  
varying intensity**

SQUEAKY CLEAN



SPARKLE



GUM CARE



NIGHT SPA



Image: The toothbrush handle displaying the four available brushing modes: Squeaky Clean, Sparkle, Gum Care, and Night Spa.



Colgate



## Multi level vibration control

for your tailored brushing intensity

Image: A visual representation of the multi-level vibration control, indicating 1 to 10 intensity levels for tailored brushing.

To select a mode, press the mode button. To adjust intensity, use the intensity control buttons. Experiment to find the combination that best suits your oral care needs.

### Smart Pressure Sensor

The toothbrush is equipped with a responsive smart pressure sensor. This feature helps protect your gums and teeth by signaling when you are applying too much pressure during brushing. If excessive force is detected, the toothbrush will provide a visual or tactile alert.

Colgate

# Your Smile Coach

Responsive smart pressure sensor



**Sends signal when you press too hard**



Image: A close-up of the toothbrush head and handle, illustrating how the smart pressure sensor detects and signals when too much pressure is applied.

## **Built-in Quad Pacer**

To ensure thorough cleaning of all areas of your mouth, the toothbrush includes a built-in quad pacer. This timer prompts you to switch brushing quadrants every 30 seconds, ensuring an even and complete brushing cycle. The standard brushing cycle is 2 minutes, while the Night Spa mode extends to 3 minutes.



Colgate



**2 mins**  
Quad Pacer\*

\*3 mins for  
Night Spa mode



Lasts up to  
**15 days\*\***  
on a single charge

\*\*with 2.5-4 hour charge

Image: The toothbrush handle with icons indicating the 2-minute quad pacer (3 minutes for Night Spa mode) and the long-lasting battery life.

## Care and Maintenance

### Charging the Toothbrush

The Colgate Advanced Electric Toothbrush is designed for extended use, offering up to 15 days of battery life on a single charge (based on 2.5-4 hours of charging). To charge, connect the DC charging cable to the toothbrush and a suitable power source. Ensure the charging port is dry before connecting.



Colgate



**2 mins**  
Quad Pacer\*

\*3 mins for  
Night Spa mode



Lasts up to  
**15 days\*\***  
on a single charge

\*\*with 2.5-4 hour charge

Image: The toothbrush handle connected to its DC charging cable, illustrating the charging process and highlighting the 15-day battery life.

### Cleaning and Storage

- After each use, rinse the brush head thoroughly under running water to remove toothpaste residue and debris.
- Wipe the toothbrush handle with a damp cloth. Do not submerge the handle in water.
- Store the toothbrush upright in a dry place.
- Replace the brush head every 3 months, or sooner if the bristles become splayed or worn.

### Troubleshooting

If you encounter any issues with your Colgate Advanced Electric Toothbrush, please refer to the following common solutions:

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Low battery; not charged.	Charge the toothbrush for at least 4 hours.
Vibration is weak or inconsistent.	Low battery; brush head not properly attached.	Recharge the toothbrush. Ensure the brush head is securely attached.
Toothbrush stops abruptly during use.	Over-pressure detected; low battery.	Reduce brushing pressure. Recharge the toothbrush.
Charging indicator not working.	Cable not connected properly; faulty charger/cable.	Ensure cable is fully inserted. Try a different USB power adapter.

## Specifications

Feature	Detail
Model Number	61024519
Power Source	Battery Powered (1 Product Specific battery included)
Brushing Modes	4 (Squeaky Clean, Sparkle, Gum Care, Night Spa)
Intensity Settings	10 levels
Special Features	Responsive Smart Pressure Sensor, Built-in Quad Pacer, Built-in Tongue Scraper
Battery Life	Up to 15 days on a single charge
Dimensions (LxWxH)	18.5 x 24.5 x 4.8 cm
Item Weight	610 g
Country of Origin	China
Manufacturer	Ningbo Seago Electric Co. Ltd
Importer	Colgate-Palmolive (India) Ltd.

## Warranty and Support

For warranty claims, technical support, or any product-related inquiries, please contact Colgate-Palmolive (India) Ltd. as the official importer.

- **Importer:** Colgate-Palmolive (India) Ltd., Main Street, Hiranandani Gardens, Powai, Mumbai- 400080
- **Manufacturer:** Ningbo Seago Electric Co. Ltd, No 239 Jianghu road, Jiangbei district, Ningbo, China

Please retain your proof of purchase for any warranty claims. Specific warranty terms and conditions may apply and are typically outlined in the product packaging or on the manufacturer's official website.



Image: The rear view of the product packaging, showing detailed importer and manufacturer information, along with contact details for inquiries.